



SuperServer®
SYS-E300-14AR

USER'S MANUAL

Revision 1.0 (MNL-2843)

The information in this User's Manual has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, and makes no commitment to update or to keep current the information in this manual, or to notify any person or organization of the updates. Note: For the most up-to-date version of this manual, see our website at <https://www.supermicro.com>.

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software and documentation, is the property of Supermicro and/or its licensors, and is supplied only under a license. Any use or reproduction of this product is not allowed, except as expressly permitted by the terms of said license.

IN NO EVENT WILL Super Micro Computer, Inc. BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPER MICRO COMPUTER, INC. SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Supermicro's total liability for all claims will not exceed the price paid for the hardware product.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class A or Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in industrial environment for Class A device or in residential environment for Class B device. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instruction manual, may cause harmful interference with radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See <https://www.dtsc.ca.gov/hazardouswaste/perchlorate>".



WARNING: This product can expose you to chemicals including lead, known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to <https://www.P65Warnings.ca.gov>.



AVERTISSEMENT : Ce produit peut vous exposer à des agents chimiques, y compris le plomb, identifié par l'État de Californie comme pouvant causer le cancer, des malformations congénitales ou d'autres troubles de la reproduction. Pour de plus amples informations, prière de consulter <https://www.P65Warnings.ca.gov>.

The products sold by Supermicro are not intended for and will not be used in life support systems, medical equipment, nuclear facilities or systems, aircraft, aircraft devices, aircraft/emergency communication devices or other critical systems whose failure to perform be reasonably expected to result in significant injury or loss of life or catastrophic property damage. Accordingly, Supermicro disclaims any and all liability, and should buyer use or sell such products for use in such ultra-hazardous applications, it does so entirely at its own risk. Furthermore, buyer agrees to fully indemnify, defend and hold Supermicro harmless for and against any and all claims, demands, actions, litigation, and proceedings of any kind arising out of or related to such ultra-hazardous use or sale.

Manual Revision 1.0

Release Date: June 10, 2026

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2026 by Super Micro Computer, Inc.
All rights reserved.

Published in the United States of America

Preface

About This Manual

This manual is written for professional system integrators and PC technicians. It provides information for the installation and use of the SYS-E300-14AR server. Installation and maintenance should be performed by certified service technicians only.

Notes

For your system to work properly, follow the links below to download all necessary drivers/utilities and the user's manual for your server.

- Supermicro product manuals: <https://www.supermicro.com/support/manuals>
- Product drivers and utilities: <https://www.supermicro.com/wdl>
- Product safety info: https://www.supermicro.com/about/policies/safety_information.cfm
- A secure data deletion tool designed to fully erase all data from storage devices can be found on our website:
https://www.supermicro.com/about/policies/disclaimer.cfm?url=/wdl/utility/Lot9_Secure_Data_Deletion_Utility
- Frequently Asked Questions: <https://www.supermicro.com/FAQ/index.php>
- If you still have questions after referring to our FAQs, contact our support team. Region-specific Technical Support email addresses can be found at: "[Contacting Supermicro](#)" on page 12
- If you have any feedback on Supermicro product manuals, contact our writing team at: Techwriterteam@supermicro.com

This manual may be periodically updated without notice. Check the Supermicro website for possible updates to the manual revision level.

Conventions Used in the Manual

Special attention should be given to the following symbols for proper installation and to prevent damage done to the components or injury to yourself.



Warning! Indicates important information given to prevent equipment/property damage or personal injury.



Warning! Indicates high voltage may be encountered while performing a procedure.



Warning! Indicates hazardous moving parts may be encountered while handling a fan or components near a fan.

Important: Important information given to ensure proper server installation or to relay safety precautions.

Note: Additional information given to differentiate various models or to provide information for proper server setup.

Contents

| | |
|--|-----------|
| Contacting Supermicro | 12 |
| Chapter 1: Introduction | 13 |
| 1.1 System Overview | 14 |
| 1.2 System Features | 16 |
| Front View | 16 |
| Control Panel | 17 |
| Rear View | 18 |
| 1.3 System Architecture | 19 |
| Main Components | 19 |
| Motherboard Block Diagram | 20 |
| 1.4 Motherboard Quick Reference | 21 |
| Motherboard Layout | 21 |
| Motherboard Quick Reference | 24 |
| Chapter 2: Chassis Installation | 27 |
| 2.1 Unpacking the System | 28 |
| 2.2 Preparing for Setup | 29 |
| Choosing a Setup Location | 29 |
| Rack Precautions | 29 |
| System Precautions | 29 |
| Rack Mounting Considerations | 30 |
| Ambient Operating Temperature | 31 |
| Airflow | 31 |
| Mechanical Loading | 31 |
| Circuit Overloading | 31 |
| Reliable Ground | 31 |
| 2.3 Installing Rack Mounting Brackets | 32 |
| Chapter 3: Maintenance and Component Installation | 33 |
| 3.1 Removing Power | 35 |
| 3.2 Accessing the System | 36 |
| Removing the Chassis Cover | 36 |
| 3.3 Static-Sensitive Devices | 37 |

| | |
|--|-----------|
| Precautions | 37 |
| 3.4 Processor and Heatsink Installation | 38 |
| Installing an LGA 1851 Processor | 38 |
| Installing a Processor Heatsink | 42 |
| Removing the Processor Heatsink | 46 |
| 3.5 Memory Support and Installation | 47 |
| Memory Support | 47 |
| General Guidelines for Optimizing Memory Performance | 47 |
| SODIMM Installation | 47 |
| SODIMM Removal | 49 |
| 3.6 Motherboard Battery Removal and Installation | 50 |
| Battery Removal | 50 |
| Proper Battery Disposal | 50 |
| Battery Installation | 50 |
| 3.7 Storage Drives | 51 |
| Installing Drives | 51 |
| M.2 Storage Drives | 53 |
| Installing M.2 Drives | 53 |
| 3.8 System Cooling | 54 |
| Fans | 54 |
| Replacing a Fan | 54 |
| 3.9 Expansion Cards | 56 |
| Riser Card | 56 |
| 3.10 Cable Routing Diagrams | 57 |
| Cable Routing | 57 |
| Chapter 4: Motherboard Connections, Jumpers, and LEDs | 58 |
| 4.1 Power Supply and Power Connections | 60 |
| Power Supply | 60 |
| 4-Pin HDD Power Connector | 60 |
| 4-pin DC Power Source | 60 |
| 8-pin DC Power Connector | 61 |
| 4.2 Headers and Connections | 62 |
| Chassis Intrusion | 62 |
| CMOS Battery | 62 |

| | |
|--|----|
| COM Header | 62 |
| External BMC I ² C Header | 63 |
| Fan Headers | 63 |
| M.2 Slots | 64 |
| MCIO PCIe 4.0 x8 Connector | 67 |
| MCIO PCIe 4.0 x4 Connector | 67 |
| Power SMB (I ² C) Header | 67 |
| Power SMB Header | 68 |
| Speaker Header | 68 |
| TPM/Port 80 Header | 69 |
| VGA Header | 69 |
| USB Headers | 69 |
| 4.3 Jumper Settings | 71 |
| CMOS Clear | 71 |
| LAN1 Enable/Disable | 72 |
| LAN2 Enable/Disable | 72 |
| ME Manufacturing Mode | 73 |
| PCIe Bifurcation | 73 |
| Onboard TPM Enable/Disable | 73 |
| SIM Detect Option | 74 |
| VGA Enable/Disable | 74 |
| Watchdog Timer | 75 |
| 4.4 LED Indicators | 76 |
| BMC Heartbeat LED | 76 |
| Power LED | 76 |
| Unit ID (UID) LED | 76 |
| 4.5 Input/Output Ports | 78 |
| HDMI and DP Ports | 78 |
| LAN Ports | 79 |
| Unit Identifier Button | 79 |
| USB Ports | 80 |
| Front Control Panel | 80 |
| Power Button | 80 |
| Reset Button | 81 |

| | |
|--|------------|
| Overheat/Fan Fail LED | 81 |
| NIC1/NIC2 (LAN1/LAN2) | 82 |
| HDD LED | 82 |
| Power LED | 82 |
| NMI Button | 83 |
| Chapter 5: Software | 84 |
| 5.1 Microsoft Windows OS Installation | 85 |
| Installing the OS | 85 |
| Driver Installation | 86 |
| 5.2 BMC | 88 |
| BMC ADMIN User Password | 88 |
| Chapter 6: Optional Components | 89 |
| 6.1 TPM Security Module | 90 |
| Chapter 7: Troubleshooting and Support | 91 |
| 7.1 Online Resources | 92 |
| Direct Links for the SYS-E300-14AR System | 92 |
| Direct Links for General Support and Information | 92 |
| 7.2 Baseboard Management Controller (BMC) | 93 |
| 7.3 Troubleshooting Procedures | 94 |
| Before Power On | 94 |
| No Power | 94 |
| No Video | 94 |
| System Boot Failure | 94 |
| Memory Errors | 95 |
| Losing the System's Setup Configuration | 95 |
| If the System Becomes Unstable | 95 |
| 7.4 CMOS Clear | 97 |
| 7.5 Motherboard Battery | 98 |
| 7.6 Where to Get Replacement Components | 99 |
| 7.7 Technical Support Procedures | 100 |
| Returning Merchandise for Service | 100 |
| 7.8 Feedback | 102 |
| Chapter 8: UEFI BIOS | 103 |
| 8.1 Introduction | 104 |

| | |
|---|-----|
| Updating BIOS | 104 |
| Starting the Setup Utility | 104 |
| 8.2 Main Setup | 106 |
| 8.3 Advanced Setup Configurations | 108 |
| ACPI Settings Menu | 108 |
| Boot Feature Menu | 109 |
| CPU Configuration Menu | 111 |
| Chipset Configuration Menu | 114 |
| Memory Configuration Menu | 115 |
| Graphics Configuration Menu | 116 |
| DMI Configuration Menu | 117 |
| PEG Port Configuration | 117 |
| GT - Power Management Control | 117 |
| PCH-IO Configuration | 118 |
| PCI Express Configuration | 118 |
| Onboard LAN1 | 118 |
| Onboard LAN2 | 118 |
| MCIO-1 | 119 |
| MCIO-2 | 119 |
| M.2-H | 120 |
| HTTP Boot Configuration Menu | 120 |
| Super IO Configuration Menu | 121 |
| Serial Port 1 Configuration Menu | 122 |
| Serial Port 2 Configuration Menu | 122 |
| Network Stack Configuration Menu | 122 |
| MAC:(MAC address)-IPv4 Network Configuration Menu | 123 |
| MAC:(MAC address)-IPv6 Network Configuration Menu | 124 |
| MAC:(MAC address)-IPv4 Network Configuration Menu | 125 |
| MAC:(MAC address)-IPv6 Network Configuration Menu | 126 |
| MAC:(MAC address)-IPv4 Network Configuration Menu | 127 |
| MAC:(MAC address)-IPv6 Network Configuration Menu | 128 |
| MAC:(MAC address)-IPv4 Network Configuration Menu | 129 |
| MAC:(MAC address)-IPv6 Network Configuration Menu | 130 |
| PCH-FW Configuration | 131 |

| | |
|---|------------|
| AMT Configuration | 131 |
| ASF Configuration | 131 |
| Secure Erase Configuration | 132 |
| One Click Recovery (OCR) Configuration | 132 |
| PCIe/PCI/PnP Configuration Menu | 133 |
| SATA and RST Configuration | 134 |
| VMD Setup Menu | 135 |
| Serial Port Console Redirection Menu | 135 |
| Trusted Computing Menu | 139 |
| USB Configuration Menu | 141 |
| Intel Ethernet Controller I226-LM | 141 |
| Intel Ethernet Controller I226-LM | 141 |
| Intel Ethernet Controller X550 | 141 |
| Firmware Image Properties | 142 |
| NIC Configuration | 142 |
| Intel Ethernet Controller X550 | 142 |
| Firmware Image Properties | 143 |
| NIC Configuration | 143 |
| TLS Authenticate Configuration Menu | 143 |
| Driver Health Menu | 144 |
| 8.4 Event Logs | 145 |
| 8.5 BMC | 147 |
| System Event Log Menu | 147 |
| BMC Network Configuration Menu | 148 |
| 8.6 Security | 151 |
| Secure Boot Menu | 152 |
| 8.7 Boot | 155 |
| 8.8 Save & Exit | 157 |
| 8.9 MEBx | 159 |
| Appendix A: BIOS Codes | 168 |
| BIOS Error POST (Beep) Codes | 168 |
| Additional BIOS POST Codes | 168 |
| Appendix B: Standardized Warning Statements for DC Systems | 169 |
| Standard Warning Definition | 169 |

| | |
|---|------------|
| Electrical Warning Definition | 171 |
| Installation Instructions | 173 |
| Circuit Breaker | 174 |
| Power Disconnection Warning | 175 |
| Equipment Installation | 177 |
| Rack Stability Hazard | 179 |
| Rack-Mounted Equipment Warning | 181 |
| Restricted Access Location | 182 |
| Battery Handling | 184 |
| Redundant Power Supplies | 186 |
| Backplane Voltage | 187 |
| Comply with Local and National Electrical Codes | 189 |
| Fan Warning | 190 |
| Connection to Earth | 192 |
| DC Power Supply | 193 |
| Power Disconnection Warning | 195 |
| Hazardous Voltage or Energy Present on DC Power Terminals | 197 |
| Product Disposal | 199 |
| Appendix C: System Specifications | 201 |

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000

Fax: +1 (408) 503-8008

Email: Marketing@supermicro.com (General Information)
Sales-USA@supermicro.com (Sales Inquiries)
Government_Sales-USA@supermicro.com (Gov. Sales Inquiries)
Support@supermicro.com (Technical Support)
RMA@Supermicro.com (RMA Support)
Webmaster@supermicro.com (Webmaster)

Website: <https://www.supermicro.com>

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390

Fax: +31 (0) 73-6416525

Email: Sales_Europe@supermicro.com (Sales Inquiries)
Support_Europe@supermicro.com (Technical Support)
RMA_Europe@supermicro.com (RMA Support)

Website: <https://www.supermicro.nl>

Asia-Pacific

Address: Super Micro Computer, Inc.
3F, No. 150, Jian 1st Rd.
Zhonghe Dist., New Taipei City 235 Taiwan (R.O.C)

Tel: +886 (2) 8226-3990

Fax: +886 (2) 8226-3992

Email: Sales-Asia@supermicro.com.tw (Sales Inquiries)
Support@supermicro.com.tw (Technical Support)
RMA@supermicro.com.tw (RMA Support)

Website: <https://www.supermicro.com.tw>

Chapter 1:

Introduction

This chapter provides a brief outline of the functions and features of the SYS-E300-14AR system. It is based on the X14SAV-TLN4F motherboard and the CSE-E300 chassis.

| | |
|--|-----------|
| 1.1 System Overview | 14 |
| 1.2 System Features | 16 |
| Front View | 16 |
| Control Panel | 17 |
| Rear View | 18 |
| 1.3 System Architecture | 19 |
| Main Components | 19 |
| Motherboard Block Diagram | 20 |
| 1.4 Motherboard Quick Reference | 21 |
| Motherboard Layout | 21 |
| Motherboard Quick Reference | 24 |

1.1 System Overview

The following provides an outline of the functions and features of the SuperServer® SYS-E300-14AR. It is based on the X14SAV-TLN4F motherboard and the CSE-E300 chassis.

| System Overview | |
|------------------------|---|
| Motherboard | X14SAV-TLN4F |
| Chassis | CSE-E300 |
| Processor | Single Intel® Core™ Ultra 9/7/5 (Series 2) processor (in a Socket LGA-1851), supports up to 65 W TDP CPUs (air cooled) |
| Memory | Supports up to 96 GB of ECC or Non-ECC DDR5 SODIMM memory with speeds of up to 6400 MT/s with U9/U7 processor in two slots |
| Drive Support | One M.2 PCIe 5.0 x4 NVMe slot (M-key 2280) One internal fixed 2.5" SATA drive bay (SATA support required for additional storage controllers/cables) |
| Expansion Slots | One M.2 PCIe 4.0 x2 slot (B-key 3052) One PCIe 5.0 x16 (in x16) low-profile slot (additional parts required; see Optional Parts for details) |
| I/O Ports | One RJ45 1 GbE dedicated BMC LAN port Two RJ45 10 GbE LAN ports (Intel® X550) Two RJ45 2.5 GbE LAN ports (Intel® I226-LM) Four USB 3.2 Gen2 Type-A ports One optional VGA port One DisplayPort One HDMI port One TPM header One TPM Onboard/port 80 |
| System Cooling | One CPU heatsink with 80 x 15 mm fan Two 4-pin PWM 40 x 40 x 28 mm fans |
| Power | Optional 180 W or 240 W DC power adapter |
| Form Factor | Mini-1U Embedded System: 10.43" x 1.69" x 8.89" / 264.8 x 43 x 8.89 mm (W x H x D) |

Notes:

- A Quick Reference Guide can be found on the following page of the Supermicro website: <https://www.supermicro.com/en/products/system/embedded/fan-based%20embedded/sys-e300-14ar>
- The following safety models associated with the SYS-E300-14AR have been certified as compliant with UL or CSA: E300-18, E300-A18X13 (for 180 W), and E300-24, E300-A24X13 (for 240 W).

1.2 System Features

The following views of the system display the main features. Refer to the System Specifications appendix of this manual for additional specifications.

Front View

The following features are located on the front of the SYS-E300-14AR server.




Figure 1-1. SYS-E300-14AR Front View

| Front View Features | |
|---------------------|---|
| Feature | Description |
| Front Bezel | Cover/faceplate securing internal components |
| Control Panel | Front control panel with LEDs and buttons (see Control Panel for details) |

Control Panel

The following switches and LEDs are located on the SYS-E300-14AR server control panel.




Figure 1-2. SYS-E300-14AR Control Panel

| Control Panel Features | |
|------------------------|---|
| Feature | Description |
| Information LED | LED indicating system states (see Information LED table below for details) |
| NIC LEDs | LEDs indicating network activity on LAN port 1 and LAN port 2 |
| Drive LED | LED indicating activity on any installed storage drive |
| Power LED | LED indicating power on (steady) |
| Power Button | Button applying/removing main power Standby power maintained when LED is off |
| Reset Button | Button activating the blue Information and rear UID LEDs for server location in a rack environment when pressed once, or performing a hard system reset when held for 3 seconds (all unsaved data will be lost) |

| Information LED | |
|------------------------|--|
| Color, Status | Description |
| Red, on | Overheating condition (check for cable congestion) |
| Red, blinking at 1 Hz | Fan failure (check for an inoperative fan) |
| Blue, solid | UID activated locally to locate the server in a rack environment |
| Blue, blinking at 1 Hz | UID activated via BMC to locate the server in a rack environment |

Rear View

The following features are located on the rear of the SYS-E300-14AR server.




Figure 1-3. SYS-E300-14AR Rear View

| Rear View Features | |
|--------------------|--|
| Feature | Description |
| Power Adapter | One lockable 12 V DC-In power adapter |
| LAN Ports | One IPMI LAN port Two 2.5 GbE LAN ports Two 10 GbE LAN ports |
| USB Ports | Four USB 3.2 Type-A ports |
| Display Port | Digital video interface port |
| HDMI Port | One HDMI 2.1 port |

| Expansion Slot Location | |
|-------------------------|-------------------|
| Slot | Description |
| 1 | PCIe 5.0 x16 (LP) |

1.3 System Architecture

This section covers the locations of the system's main components and provides a motherboard block diagram.

Main Components

The following main components are located inside the SYS-E300-14AR server.




Figure 1-4. SYS-E300-14AR Main Component Locations

| Top View Features | |
|-------------------|---|
| Feature | Description |
| M.2 Slots | One PCIe 5.0 M.2 NVMe slot (M-Key), (2280) One PCIe 4.0 M.2 NVMe slot (B-Key), (3052, USB 3.0) |
| Drive Bay | One internal SATA 2.5" drive bay (2.5" SATA drive available when AOC is not supported) |
| DIMM Slots | Two DDR5 DIMM slots |
| Processor | Single Intel® Ultra 9/7/5 (Series 2) processor |
| System Fans | Two internal fans |

Motherboard Block Diagram




Figure 1-5. X14SAV-TLN4F Motherboard Block Diagram

1.4 Motherboard Quick Reference

For details on the X14SAV-TLN4F motherboard layout and other quick reference information, refer to the content below.

Motherboard Layout




Figure 1-6. X14SAV-TLN4F Motherboard Photo




Figure 1-7. X14SAV-F Motherboard Photo




Figure 1-8. X14SAV-F Motherboard Layout

Notes:

- For detailed information on jumpers, connectors, and LED indicators, see ["Maintenance and Component Installation"](#) on page 33.
- "■" indicates the location of pin 1.
- "MH" indicates the location of a mounting hole.
- Components not documented are for internal testing purposes only.
- Use only the correct type of onboard CMOS battery as specified by the manufacturer. To avoid possible explosion, do not install the onboard battery upside down.

Motherboard Quick Reference

For details on the X14SAV-TLN4F motherboard layout, features, and other quick reference information, refer to the content below.

| Jumper | Description | Default Settings |
|------------|--|--|
| JBT1 | CMOS Clear | Open (Normal) |
| JNS2 | M.2 B-Key Mode Selection | Pins 1–2 (USB 3.0) Pins 2–3 (PCIe 4.0) |
| JPG1 | VGA Enable/Disable | Pins 1–2 (Enabled) |
| JPL1 | LAN1 Enable/Disable | Pins 1–2 (Enabled) |
| JPL2 | LAN2 Enable/Disable | Pins 1–2 (Enabled) |
| JPME2_CPU1 | ME Manufacturing Mode | Pins 1–2 (Normal) |
| JPME2_PCH1 | ME Manufacturing Mode | Pins 1–2 (Normal) |
| JPO1 | CPU Throttle when PWR_FAIL | Pins 1–2 (Enabled) Pins 2–3 (Disabled) (Default) |
| JPT1 | Onboard TPM 2.0 Enable/Disable | Pins 1–2 (Enabled) |
| JRF1, JRF2 | PCIe Bifurcation | JRF1 JRF2 PEG Pins 2–3 Pins 2–3 x16 (PCIe) (Default) Pins 1–2 Pins 2–3 2x8 (PCIe) Pins 2–3 Pins 1–2 1x8, 2x4 (PCIe) |
| JSIM_OPT1 | USB or PCI Interface Optional SIM Detect M.2 B-Key Storage LED | Pins 1–3 Short (USB) Pins 2–4 Short (Low Active) Pins 5–6 Enabled |
| JWD1 | Watchdog Timer | Pins 1–2 (Reset) |

| Connector | Description |
|-----------|---|
| BT1 | Onboard Battery |
| FAN1–FAN3 | Fan Headers |
| HDMI1/DP1 | High Definition Multimedia Interface/DisplayPort |
| JCOM1 | COM Header (supports RS232) |
| JD1 | Speaker/Buzzer (Pins: 1–4: Speaker, Pins 3–4: Buzzer) |
| JF1 | Front Control Panel Header |
| JIPMB1 | 4-pin BMC External I ² C Header |
| JL1 | Chassis Intrusion Header |
| JLAN1 | 2.5G LAN1/2 Ports |
| JLAN2 | 10G LAN3/4 Ports |
| JMD1 | M.2 M-Key Slot (PCIe 5.0 x4) |
| JMD2 | M.2 B-Key Slot (PCIe 4.0/USB 3.0) |
| JMD1_SRW1 | M.2 Mounting Hole for JMD1 |
| JMD2_SRW1 | M.2 Mounting Hole for JMD2 |
| JNVME1 | MCIO Slot supports two PCIe 4.0x Connectors |
| JNVME2 | MCIO Slot supports four SATA (or PCIe x4 by OEM BIOS) |
| JPCIE1 | PCIe 5.0 x16 Slot |
| JPH1 | 4-pin HDD Power Connector |
| JPI2C1 | Power System Management Bus (SMB) I ² C Header |
| JPV1 | 8-pin +12 V DC Power Connector for CPU (Required) or alternative single power input for when the 24-pin ATX is not in use |
| JPW1 | 4-pin +12 V Power Source |
| JSMB1 | Power Mangement Bus Header |
| JTPM1 | Trusted Platform Module/Port 80 Connector |
| JUSB1 | USB 2.0 Header (USB0/1) |
| JUSB2 | USB 3.2 (10 Gb) Header (USB6/7) |

| Connector | Description |
|------------------|---------------------------------------|
| JUSBRJ1 | BMC LAN/USB4/5 Ports (USB 3.2, 10 Gb) |
| JUSBRJ2 | USB 3.2 (10 Gb) Ports (USB2/3) |
| JVGA1 | VGA Header |
| MH2–MH6, MH8 | Mounting Holes |
| UID_SW | Unit Identifier Button |

| LED | Description | Status |
|------------|---------------------------|-----------------------------|
| LED1 | Power LED | Solid Green: Power On |
| LED2 | OH/Fan Fail LED | Blinking Red: OH/Fan fail |
| LED3 | BMC LED | Blinking Orange: BMC Normal |
| UID_LED1 | Unit Identifier (UID) LED | Solid Blue: Unit Identified |

Chapter 2:

Chassis Installation

This chapter provides advice and instructions for mounting your server in a server rack. If your server is not already fully integrated with processors, system memory, etc., refer to ["Maintenance and Component Installation" on page 33](#) for details on installing those specific components.

Important: Electrostatic Discharge (ESD) can damage electronic components. To prevent such damage to printed circuit boards (PCBs), it is important to use a grounded wrist strap, handle all PCBs by their edges, and keep PCBs in anti-static bags when not in use.

| | |
|--|-----------|
| 2.1 Unpacking the System | 28 |
| 2.2 Preparing for Setup | 29 |
| Choosing a Setup Location | 29 |
| Rack Precautions | 29 |
| System Precautions | 29 |
| Rack Mounting Considerations | 30 |
| 2.3 Installing Rack Mounting Brackets | 32 |

2.1 Unpacking the System

Inspect the box the SYS-E300-14AR server was shipped in and note if it was damaged in any way. If any equipment appears damaged, file a damage claim with the carrier who delivered it.

Decide on a suitable location for the rack unit that will hold the system. It should be situated in a clean, dust-free area that is well ventilated. Avoid areas where heat, electrical noise and electromagnetic fields are generated. It will also require a grounded AC power outlet nearby. Be sure to read the precautions and considerations noted in [Standardized Warning Statements for AC Systems](#).

2.2 Preparing for Setup

The box in which the SYS-E300-14AR server was shipped should include the rackmount hardware needed to install it into the rack. Read this section in its entirety before you begin the installation.

Choosing a Setup Location

- The server should be situated in a clean, dust-free area that is well ventilated. Avoid areas where heat, electrical noise and electromagnetic fields are generated.
- Leave enough clearance in front of the rack so that you can open the front door completely (~25 inches) and approximately 30 inches of clearance in the back of the rack to allow sufficient space for airflow and access when servicing.
- This product should be installed only in a Restricted Access Location (dedicated equipment rooms, service closets, etc.).
- This product is not suitable for use with visual display workplace devices according to §2 of the German Ordinance for Work with Visual Display Units.

Rack Precautions

- Ensure that the leveling jacks on the bottom of the rack are extended to the floor so that the full weight of the rack rests on them.
- In single rack installations, stabilizers should be attached to the rack. In multiple rack installations, the racks should be coupled together.
- Always make sure the rack is stable before extending a system or other component from the rack.
- You should extend only one system or component at a time. Extending two or more simultaneously may cause the rack to become unstable.

System Precautions

- Review the electrical and general safety precautions in [Standardized Warning Statements for AC Systems](#).
- Determine the placement of each component in the rack before you install the rails.
- Install the heaviest system components at the bottom of the rack first and then work your way up.

- Use a regulating uninterruptible power supply (UPS) to protect the system from power surges and voltage spikes and to keep your system operating in case of a power failure.
- Allow any drives and power supply modules to cool before touching them.
- When not servicing, always keep the front door of the rack and all covers/panels on the systems closed to maintain proper cooling.

Rack Mounting Considerations



Warning! Stability hazard. The rack may tip over causing serious personal injury. Before extending the rack to the installation position, read the installation instructions. Do not put any load on the slide-rail mounted equipment in the installation position. Do not leave the slide-rail mounted equipment in the installation position.



Avertissement!

Danger d'instabilité. Le rack peut basculer et provoquer des blessures corporelles graves.

Avant d'étendre le rack en position d'installation, lire les instructions d'installation. Ne pas charger l'équipement monté sur rail de glissière en position d'installation. Ne pas laisser l'équipement monté sur rail de glissière en position d'installation.

Important: To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:

- If this unit is the only unit in the rack, it should be mounted at the bottom of the rack.
- When mounting this unit in a partially filled rack, load the rack from the bottom to the top, placing the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.
- Slide rail mounted equipment is not to be used as a shelf or a workspace.
- Do not pick up the system with the front handles. They are designed to pull the system from a rack only.

Ambient Operating Temperature

If installed in a closed or multi-unit rack assembly, the ambient operating temperature of the rack environment may be greater than the room's ambient temperature. Therefore, consideration should be given to installing the equipment in an environment compatible with the manufacturer's maximum rated ambient temperature (TMRA).

Airflow

Equipment should be mounted into a rack so that the amount of airflow required for safe operation is not compromised.

Mechanical Loading

Equipment should be mounted into a rack so that a hazardous condition does not arise due to uneven mechanical loading.

Circuit Overloading

Consideration should be given to the connection of the equipment to the power supply circuitry and the effect that any possible overloading of circuits might have on overcurrent protection and power supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Ground

A reliable ground must be maintained at all times. To ensure this, the rack itself should be grounded. Particular attention should be given to power supply connections other than the direct connections to the branch circuit (i.e. the use of power strips, etc.).

2.3 Installing Rack Mounting Brackets

The chassis can be mounted in a rack using two rack brackets and a two-part power adapter shelf bracket (optional, MCP-290-30002-0B).

1. Attach the rack brackets using three screws through the holes in each bracket to secure the bracket to the chassis.
2. Install the handles, using two screws through the bracket and into each handle.
3. If you are using the optional power adapter bracket, install the power adapter on its bracket. Place it as shown, then add the retention bracket using two screws.
4. Mount the power adapter bracket assembly on the right side of the chassis using three screws.




Figure 2-1. Installing Rack Mounting Brackets

Chapter 3:

Maintenance and Component Installation

This chapter provides instructions on installing and replacing main system components for the SYS-E300-14AR server. To prevent compatibility issues, only use components that match the specifications and/or part numbers given.

Installation or replacement of most components require that power first be removed from the system. Follow the procedures given in each section.

| | |
|---|-----------|
| 3.1 Removing Power | 35 |
| 3.2 Accessing the System | 36 |
| Removing the Chassis Cover | 36 |
| 3.3 Static-Sensitive Devices | 37 |
| Precautions | 37 |
| 3.4 Processor and Heatsink Installation | 38 |
| Installing an LGA 1851 Processor | 38 |
| Installing a Processor Heatsink | 42 |
| Removing the Processor Heatsink | 46 |
| 3.5 Memory Support and Installation | 47 |
| Memory Support | 47 |
| General Guidelines for Optimizing Memory Performance | 47 |
| SODIMM Installation | 47 |
| SODIMM Removal | 49 |
| 3.6 Motherboard Battery Removal and Installation | 50 |
| Battery Removal | 50 |
| Proper Battery Disposal | 50 |
| Battery Installation | 50 |
| 3.7 Storage Drives | 51 |
| Installing Drives | 51 |
| M.2 Storage Drives | 53 |
| 3.8 System Cooling | 54 |
| Fans | 54 |
| 3.9 Expansion Cards | 56 |

| | |
|--|-----------|
| Riser Card | 56 |
| 3.10 Cable Routing Diagrams | 57 |
| Cable Routing | 57 |

3.1 Removing Power

Before performing some setup or maintenance tasks, use the following procedure to ensure that power has been removed from the SYS-E300-14AR server. This step is necessary when removing or installing non hot-swappable components or when replacing a non-redundant power supply.

1. Use the operating system to power down the system.
2. After the system has completely shut-down, disconnect the AC power cord(s) from the power strip or outlet.
3. Disconnect the power cord(s) from the power supply module(s).

3.2 Accessing the System

The CSE-E300 chassis features a removable top cover, which allows easy access to the inside of the chassis.

Removing the Chassis Cover

Important: Except for short periods of time, do not operate the server without the cover in place. The chassis cover must be in place to allow for proper airflow and to prevent overheating.

1. Begin by powering down the system as described in Section 3.1.
2. Carefully remove the system from the rack, placing the system on a workbench.
3. Remove the two screws that hold the cover in place.
4. Slide the cover sideways as illustrated below to release the front and rear cover hooks from the chassis.
5. Lift the cover up and off the chassis.




Figure 3-1. Removing the Chassis Cover

Note: Check that all ventilation openings on the top cover and the top of the chassis are clear and unobstructed.

3.3 Static-Sensitive Devices

Electrostatic Discharge (ESD) can damage electronic components. To avoid damaging your motherboard, it is important to handle it very carefully. The following measures are generally sufficient to protect your equipment from ESD.

Precautions

- Use a grounded wrist strap designed to prevent static discharge.
- Touch a grounded metal object before removing the board from the antistatic bag.
- Handle the motherboard only by its edges. Do not touch its components, peripheral chips, memory modules, or gold contacts.
- When handling chips or modules, avoid touching their pins.
- Put the motherboard and peripherals back into their antistatic bags when not in use.
- For grounding purposes, make sure that your computer chassis provides excellent conductivity between the power supply, the case, the mounting fasteners, and the motherboard.
- Use only the correct type of onboard CMOS battery. To avoid possible explosion, do not install the onboard battery upside down.

3.4 Processor and Heatsink Installation

This section provides procedures to install the processor(s) and heatsink(s).

Notes:

- Take industry standard precautions to avoid ESD damage. For details, see "[Static-Sensitive Devices](#)" on the previous page.
- Before starting, make sure that the plastic socket cap is in place and none of the socket pins are bent. If any damage is noted, contact your retailer.
- Do not connect the system power cord before the processor and heatsink installation is complete.
- When handling the processor, avoid touching or placing direct pressure on the LGA lands (gold contacts). Improper installation or socket misalignment can cause serious damage to the processor or processor socket.
- When buying a processor separately, use only a Supermicro certified heatsink.
- Refer to the Supermicro website for the most recent processor support.
- When installing the heatsink, ensure a torque driver set to the correct force is used for each screw.
- Thermal grease is pre-applied on a new heatsink. No additional thermal grease is needed.

Installing an LGA 1851 Processor

Important: You can only install the processor in one direction. Make sure it is properly inserted into the socket before closing the load plate. If it doesn't close properly, do not force it as it may damage your processor. Instead, open the load plate again and double-check that the processor is properly aligned.

1. Remove the plastic protective cover from the load plate.




Figure 3-2. Removing the Protective Cover

2. Gently push the load lever down and away from the lever lock, then lift it up completely.




Figure 3-3. Releasing and Lifting the Lever

3. Lift the load plate to open it completely.




Figure 3-4. Opening the Load Plate

4. Carefully hold the processor by its edges. Align the small triangle marker and notches on the processor with the corresponding triangle marker and notches on the processor load bracket. Once aligned, carefully lower the processor straight down into the socket. (Do not drop the processor on the socket, or move it horizontally or vertically.)




Figure 3-5. Aligning the Notches and Installing the Processor

5. Do not rub the processor against the surface or against any pins of the socket to avoid damaging the processor or the socket.

6. With the processor inside the socket, inspect all the corners to make sure it is properly installed.
7. Close the load plate with the processor inside the socket. Gently push the load lever down until it locks under the lever lock.




Figure 3-6. Closing the Load Plate and Pushing the Lever Down

Installing a Processor Heatsink

1. Loosen four screws to release the backplate. Note that one screw is not shown in the illustration below.




Figure 3-7. Releasing the Backplate from the Heatsink

2. If there is a thin layer of protective film on the backplate, remove it.





Figure 3-8. Removing the Protective Film

3. Attach the backplate into the mounting holes around the processor socket on the bottom side of the motherboard.






Figure 3-9. Attaching the Backplate to the Bottom Side of the Motherboard

4. Apply the proper amount of thermal grease on the processor.





Figure 3-10. Applying Thermal Grease

5. Place the heatsink on top of the processor so that the four mounting holes on the heatsink are aligned with those on the retention mechanism.

6. Tighten the screws.

**Figure 3-11. Tightening the Heatsink Screws****Notes:**

- The installation described in this section is for reference only. The actual installation steps may vary depending on the CPU heatsink model. Refer to the heatsink instructions for more details.
- Images displayed are for illustration purposes only. Your components might look different from those shown in this manual.

Removing the Processor Heatsink

Important: We do not recommend that the processor or heatsink be removed. However, if you do need to remove the heatsink, follow the instructions below to remove the heatsink and prevent damage done to the processor or other components.

1. Unplug the power cord from the power supply and the power connector from the cooler and fan header.
2. Loosen the screws as shown in figure in the next step.
3. Gently wiggle the heatsink to loosen it. Do not use excessive force when wiggling the heatsink.




Figure 3-12. Loosening the Heatsink Screws

4. Once the heatsink is loosened, remove it from the motherboard.

3.5 Memory Support and Installation

Important: To prevent any damage, exercise extreme care when installing or removing memory modules.

Note: Check the Supermicro website for recommended memory modules.

Memory Support

The X14SAV-TLN4F supports up to 96 GB of DDR5 ECC and Non-ECC SODIMM memory with speeds of up to 5600 MT/s in two memory slots.

General Guidelines for Optimizing Memory Performance

- It is recommended to use DDR5 memory of the same type, size, and speed.
- Mixed DIMM speeds can be installed. However, all DIMMs will run at the speed of the slowest DIMM.
- The motherboard will support an odd number amount of memory modules. However, to achieve the best memory performance, a balanced memory population is recommended.

SODIMM Installation

Important: To avoid causing any damage to the memory module or the DIMM socket, do not use excessive force when pressing the release tabs on the ends of the DIMM socket. Handle memory modules with care. To avoid ESD-related damage to your memory modules or components, carefully follow all the instructions given in "[Static-Sensitive Devices](#)" on [page 37](#).

1. Install the desired number of SODIMMs into the memory slots, starting with DIMMA1 and then DIMMB1.
2. Align the key on the bottom of the SODIMM module against the receptive point on the memory slot. Take note of the notches on the side of the SODIMM module and of the locking clips on the socket to avoid causing damage.




Figure 3-13. Aligning the SODIMM

3. Press the SODIMM module straight down into the socket with both hands until it is securely seated. The side clips will automatically lock the module into place.




Figure 3-14. Securing the SODIMM

SODIMM Removal

Push the side clips at the end of the slot to release the SODIMM module. Pull the SODIMM module up to remove it from the slot.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

3.6 Motherboard Battery Removal and Installation

Battery Removal

To remove the onboard battery, follow the steps below:

1. Power off your system and unplug your power cable.
2. Place the system on a workbench.
3. Remove the top cover from the system.
4. Locate the onboard battery as shown below.
5. Using a tool such as a pen or a small screwdriver, push the battery lock outwards to unlock it. Once unlocked, the battery will pop out from the holder.
6. Remove the battery.

Proper Battery Disposal

Important: Handle used batteries carefully. Do not damage the battery in any way; a damaged battery may release hazardous materials into the environment. Do not discard a used battery in the garbage or a public landfill. Comply with the regulations set up by your local hazardous waste management agency to dispose of your used battery properly.

Battery Installation

To install an onboard battery, follow steps 1 and 2 above and continue below:

Important: When replacing a battery, be sure to only replace it with the same type.

1. Identify the battery's polarity. The positive (+) side should be facing up.
2. Insert the battery into the battery holder and push it down until you hear a click to ensure that the battery is securely locked.




Figure 3-15. Installing a Battery

3.7 Storage Drives

When the PCIe riser card is removed, the system can support one fixed 2.5" storage drive, which will be installed using a bracket.

Note: Enterprise-level storage modules are recommended for use in Supermicro systems.

Installing Drives

The motherboard should be installed before installing the drive.

1. Make sure there is no power to the system as described in section 3.1.
2. Remove the chassis cover.
3. Remove the screws securing the hard drive tray to the support bracket and set them aside for later use.
4. Lift the tray out.




Figure 3-16. Attaching the Storage Drive to the Support Bracket

5. Place the drive into the tray.
6. Secure it to the tray with the screws provided with the drive.
7. Return the drive tray assembly into the chassis, aligning the tabs of the tray with the slots in the chassis.
8. Secure the tray to the chassis support bracket with the screws previously set aside.
9. Attach the SATA cable from the drive to the SATA port on the motherboard. This cable carries both the SATA signal and the SATA power.
10. Reinstall the chassis cover.
11. Power up the system.

M.2 Storage Drives

This motherboard supports one internally mounted storage card on M.2 slots supporting PCIe 3.0 x4, for NVMe storage of 2242/2280 length.

Note: The image below may not reflect the same layout as your system.

Installing M.2 Drives

M.2 is formerly known as Next Generation Form Factor (NGFF). The system deploys an M key (2280) dedicated for storage drive devices with the ultimate performance capability in a PCI Express 5.0 x4 (NVMe storage supporting 2280 length) and an M.2 B key that supports 3052 length.

1. Access the motherboard and locate the M.2 connector.
2. Gently insert the M.2 card into the connector.
3. Use a screw to secure the M.2 card to the M2_SRW1 or M2_SRW2 standoff.




Figure 3-17. Installing M.2 Drives and Devices

3.8 System Cooling

Refer to the following sections for information about the cooling capabilities of the SYS-E300-14AR server.

Fans

Two replaceable 4-cm fans provide the cooling for the system. Make sure the chassis top cover makes a good seal so the cooling air circulates properly through the chassis.

Replacing a Fan

The chassis includes two pre-installed fans. One additional open slot is available so that one more fan may be added if additional cooling is required. These fans are NOT redundant, hot-plug, and so must be replaced when they fail. Replace any failed fan at your earliest convenience with the same type and model.

Note: The system should be placed on a stable workbench when installing or replacing the fan.

1. Power down the system as described in section 2.1 and remove the AC power cord and the chassis cover.
2. Remove the wiring of the failed fan from the motherboard.
3. Remove the screws securing the fan to the chassis wall and save them.
4. Lift the fan out of the chassis.
5. Position the replacement fan to align with the chassis holes, ensuring the airflow direction is correct.
6. Secure the fan to the chassis wall using the screws previously set aside.
7. Reconnect the fan wiring to motherboard.
8. Reinstall the chassis top cover, reconnect the AC power cord, and power up the system.




Figure 3-18. Changing a Fan

3.9 Expansion Cards

Refer to the following sections for information on the expansion cards supported by the SYS-E300-14AR server.

Riser Card

The system can support one PCIe x16 expansion card by means of an optional riser card. The riser card is inserted in the expansion slot on the motherboard. Installation of the riser card and riser card bracket is pictured below.

Note: The image below may not reflect the same layout as your system.




Figure 3-19. Installing the Riser Card

3.10 Cable Routing Diagrams

The below diagrams indicate the cable routing for the storage, PCIe, I/O, and power cables. When disconnecting cables to add or replace components, refer to the diagrams so you can reroute them in the same manner. If cables are not connected or routed properly it may lead to device detection or performance issues.

Cable Routing




Figure 3-20. Cable Routing

Chapter 4:

Motherboard Connections, Jumpers, and LEDs

This section describes the connections on the motherboard and provides pinout definitions. Note that depending on how the system is configured, not all connections are required. The LEDs on the motherboard are also described here. A motherboard layout indicating component locations may be found in the ["Introduction" on page 13](#). More detail can be found in the X14SAV-TLN4F motherboard manual.

Review the [Standardized Warning Statements for AC Systems](#) before installing or removing components.

| | |
|---|-----------|
| 4.1 Power Supply and Power Connections | 60 |
| Power Supply | 60 |
| 4-Pin HDD Power Connector | 60 |
| 4-pin DC Power Source | 60 |
| 8-pin DC Power Connector | 61 |
| 4.2 Headers and Connections | 62 |
| Chassis Intrusion | 62 |
| CMOS Battery | 62 |
| COM Header | 62 |
| External BMC I ² C Header | 63 |
| Fan Headers | 63 |
| M.2 Slots | 64 |
| MCIO PCIe 4.0 x8 Connector | 67 |
| MCIO PCIe 4.0 x4 Connector | 67 |
| Power SMB (I ² C) Header | 67 |
| Power SMB Header | 68 |
| Speaker Header | 68 |
| TPM/Port 80 Header | 69 |
| VGA Header | 69 |
| USB Headers | 69 |
| 4.3 Jumper Settings | 71 |
| CMOS Clear | 71 |

| | |
|-------------------------------------|-----------|
| LAN1 Enable/Disable | 72 |
| LAN2 Enable/Disable | 72 |
| ME Manufacturing Mode | 73 |
| PCIe Bifurcation | 73 |
| Onboard TPM Enable/Disable | 73 |
| SIM Detect Option | 74 |
| VGA Enable/Disable | 74 |
| Watchdog Timer | 75 |
| 4.4 LED Indicators | 76 |
| BMC Heartbeat LED | 76 |
| Power LED | 76 |
| Unit ID (UID) LED | 76 |
| 4.5 Input/Output Ports | 78 |
| HDMI and DP Ports | 78 |
| LAN Ports | 79 |
| Unit Identifier Button | 79 |
| USB Ports | 80 |
| Front Control Panel | 80 |
| Power Button | 80 |
| Reset Button | 81 |
| Overheat/Fan Fail LED | 81 |
| NIC1/NIC2 (LAN1/LAN2) | 82 |
| HDD LED | 82 |
| Power LED | 82 |
| NMI Button | 83 |

4.1 Power Supply and Power Connections

For information about the power supply and power connections of the SYS-E300-14AR server, refer to the following content.

Power Supply

As with all computer products, a stable power source is necessary for proper and reliable operation. It is even more important for processors that have high CPU clock rates where noisy power transmission is present.

The X14SAV-TLN4F/F motherboard supports both +12 V DC and ATX power input. Either option requires an 8-pin +12 V connection to the JPV1 header, with an ATX power signal input requiring an additional connection using PN: CBL-PWEX-1063/1066 between header JPV1 and the 24-pin power connector of an ATX power supply. JPV1 allows motherboard control of the +5 V Stby, power on, power good, and ground signals from the ATX power supply.

It is strongly recommended that you use a high quality power supply that meets ATX power supply Specification 2.02 or above.

4-Pin HDD Power Connector

JPH1 is 4-pin power connector that provides power to onboard HDD devices.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "[Motherboard Quick Reference](#)" on page 21.

| 4-pin HDD Power | |
|-----------------------------|------------|
| Pin Definitions: Four Total | |
| Pin# | Definition |
| 1 | +12 V |
| 2 | GND |
| 3 | GND |
| 4 | +5 V |

4-pin DC Power Source

JPW1 is a necessary connection to the 24-pin ATX power header from the PSU via PN: CBL-PWEX-1066.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "[Motherboard Quick Reference](#)" on page 21.

| 4-pin DC Power Source | |
|------------------------------------|-------------------|
| Pin Definitions: Four Total | |
| Pin# | Definition |
| 1 | P5VSB |
| 2 | GND |
| 3 | ATX_PWRGD |
| 4 | PSU_PSON_N |

8-pin DC Power Connector

JPV1 is an 8-pin 12 V DC power input for the processor that must be connected to the power supply.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| 8-pin DC Power | |
|-------------------------------------|--------------------|
| Pin Definitions: Eight Total | |
| Pin# | Definition |
| 1-4 | GND |
| 5-8 | +12 V (12 V Power) |

4.2 Headers and Connections

For information about the headers on the X14SAV-TLN4F motherboard, refer to the following content.

Chassis Intrusion

A Chassis Intrusion header is located at JL1 on the X14SAV-TLN4F motherboard. Attach the appropriate cable from the chassis to inform you when the chassis is opened.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Chassis Intrusion | |
|----------------------------|-----------------|
| Pin Definitions: Two Total | |
| Pin# | Definition |
| 1 | Intrusion Input |
| 2 | GND |

CMOS Battery

BT1 is a 2-pin connector for an external CMOS battery. This connector is also used to clear the CMOS. To clear the CMOS, remove the battery, short pins 1–2 for more than 10 seconds and then install the battery.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

COM Header

There is one COM header on the X14SAV-TLN4F motherboard. Use a cable with the COM header to access the COM port. COM ports provide serial communication support.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| COM Header | | | |
|---------------------------|------------|------|------------|
| Pin Definitions: 10 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 1 | SP_DCD1 | 2 | SP_DSR1 |

| COM Header | | | |
|----------------------------------|-------------------|-------------|-------------------|
| Pin Definitions: 10 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 3 | SP_RXD1 | 4 | SP_RTS1 |
| 5 | SP_TXD1 | 6 | SP_CTS1 |
| 7 | SP_DTR1 | 8 | SP_RI1 |
| 9 | GND | 10 | NC |

External BMC I²C Header

A System Management Bus header for the BMC is located at JIPMB1 on the X14SAV-TLN4F motherboard. Connect the appropriate cable here to use the IPMB I²C connection on your system.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "[Motherboard Quick Reference](#)" on page 21.

| External I²C Header | |
|---------------------------------------|-------------------|
| Pin Definitions: Four Total | |
| Pin# | Definition |
| 1 | Clock |
| 2 | GND |
| 3 | Data |
| 4 | NC |

Fan Headers

There are three 4-pin fan headers (FAN1–FAN3) on the X14SAV-TLN4F motherboard. All the 4-pin fan headers are backwards compatible with the traditional 3-pin fans. However, fan speed control is available by Thermal Management via the IPMI 2.0 interface.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "[Motherboard Quick Reference](#)" on page 21.

| 4-pin Fan Header | |
|-----------------------------|-------------|
| Pin Definitions: Four Total | |
| Pin# | Definition |
| 1 | GND (Black) |
| 2 | +12 V (Red) |
| 3 | Tachometer |
| 4 | PWM Control |

M.2 Slots

Two M.2 slots are located on the X14SAV-TLN4F motherboard. M.2 was formerly known as Next Generation Form Factor (NGFF) and serves to replace mini PCIe. M.2 allows for a variety of card sizes, increased functionality, and spatial efficiency. The M.2 M-Key slot on the motherboard supports PCIe 5.0 x4 devices. The M.2 B-Key slot supports PCIe 4.0 and USB 3.0 devices.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| M.2 B-Key | | | |
|---------------------------|-------------------------------|------|--|
| Pin Definitions: 75 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 1 | No Connection | 2 | +3.3 VSB |
| 3 | GND | 4 | +3.3 VSB |
| 5 | GND | 6 | FULL_CARD_POWER_OFF# (PU to P1V8SB only) |
| 7 | USB_D+ | 8 | W_DISABLE1#(PU to +3.3 VSB only) |
| 9 | USB_D- | 10 | LED_N |
| 11 | GND | 12 | KEY B |
| 13 | KEY B | 14 | KEY B |
| 15 | KEY B | 16 | KEY B |
| 17 | KEY B | 18 | KEY B |
| 19 | KEY B | 20 | PCIE_DIS |
| 21 | No Connection | 22 | VBUS_SENSE |
| 23 | WAKE_ON_WWAN#(PU to +1.8 VSB) | 24 | No Connection |
| 25 | No Connection | 26 | W_DISABLE2#(PU to +1.8 VSB only) |

| M.2 B-Key | | | |
|----------------------------------|---------------------|-------------|------------------------------|
| Pin Definitions: 75 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 27 | GND | 28 | No Connection |
| 29 | USB3.0-RX- / PERn1 | 30 | UIM-RESET |
| 31 | USB3.0-Rx + / PERp1 | 32 | UIM-CLK |
| 33 | GND | 34 | UIM-DATA |
| 35 | USB3.0-Tx- /PETn1 | 36 | UIM-PWR |
| 37 | USB3.0-Tx+ / PETp1 | 38 | No Connection |
| 39 | GND | 40 | No Connection |
| 41 | PERn0 | 42 | No Connection |
| 43 | PERp0 | 44 | Alert# (PU to +1.8 VSB only) |
| 45 | GND | 46 | No Connection |
| 47 | PETn0 | 48 | No Connection |
| 49 | PETp0 | 50 | PERST# |
| 51 | GND | 52 | CLKRED# |
| 53 | REFCLKn | 54 | PEWAKE# |
| 55 | REFCLKp | 56 | No Connection |
| 57 | GND | 58 | No Connection |
| 59 | No Connection | 60 | No Connection |
| 61 | No Connection | 62 | No Connection |
| 63 | No Connection | 64 | No Connection |
| 65 | No Connection | 66 | SIM_DETECT |
| 67 | RESET# | 68 | No Connection |
| 69 | No Connection | 70 | SUSCLK |
| 71 | GND | 72 | +3.3 VSB |
| 73 | GND | 74 | +3.3 VSB |
| 75 | No Connection | | |

| M.2 M-Key | | | |
|----------------------------------|-------------------|-------------|-------------------|
| Pin Definitions: 75 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 1 | GND | 2 | +3.3 V |
| 3 | GND | 3 | +3.3 V |
| 5 | PERn3 | 6 | No Connection |
| 7 | PERp3 | 8 | No Connection |
| 9 | GND | 10 | LED_N |
| 11 | PETn3 | 12 | +3.3 V |
| 13 | PETp3 | 14 | +3.3 V |
| 15 | GND | 16 | +3.3 V |
| 17 | PERn2 | 18 | +3.3 V |
| 19 | PERp2 | 20 | No Connection |
| 21 | GND | 22 | No Connection |
| 23 | PETn2 | 24 | No Connection |
| 25 | PETp2 | 26 | No Connection |
| 27 | GND | 28 | No Connection |
| 29 | PERn1 | 30 | No Connection |
| 31 | PERp1 | 32 | No Connection |
| 33 | GND | 34 | No Connection |
| 35 | PETn1 | 36 | No Connection |
| 37 | PETp1 | 38 | No Connection |
| 39 | GND | 40 | SCL |
| 41 | PERn0 | 42 | SDA |
| 43 | PERp0 | 44 | SMB_ALERT |
| 45 | GND | 46 | No Connection |
| 47 | PETn0 | 48 | No Connection |
| 49 | PETp0 | 50 | PERST# |
| 51 | GND | 52 | CLKREQ# |
| 53 | REFCLKn | 54 | PCIe_wake |
| 55 | REFCLKp | 56 | No Connection |

| M.2 M-Key | | | |
|----------------------------------|-------------------|-------------|-------------------|
| Pin Definitions: 75 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 57 | GND | 58 | No Connection |
| 59 | KEY M | 60 | KEY M |
| 61 | KEY M | 62 | KEY M |
| 63 | KEY M | 64 | KEY M |
| 65 | KEY M | 66 | KEY M |
| 67 | No Connection | 68 | SUSCLK |
| 69 | PEDET | 70 | +3.3 V |
| 71 | GND | 72 | +3.3 V |
| 73 | GND | 74 | +3.3 V |
| 75 | GND | | |

MCIO PCIe 4.0 x8 Connector

One internal MCIO PCIe 4.0 x8 connector is located at JNVME1 on the motherboard for high-performance storage connectivity through the NVMe interface or for additional SATA storage.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

MCIO PCIe 4.0 x4 Connector

One internal MCIO PCIe 4.0 x4 connector is located at JNVME2 on the motherboard for high-performance storage connectivity through the NVMe interface or for additional SATA storage.

Depending on the setting through the JNS1 jumper, the MCIO PCIe 4.0 x4 connector can be utilized as PCIe x4/SATA ports or a single U.2 NVMe port. NVMe provides lower data latency for increased efficiency and storage performance.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

Power SMB (I²C) Header

The Power System Management Bus (I²C) connector on the X14SAV-TLN4F motherboard monitors the power supply, fan, and system temperatures.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Power SMBus Header | |
|------------------------------------|-------------------|
| Pin Definitions: Five Total | |
| Pin# | Definition |
| 1 | Clock |
| 2 | Data |
| 3 | PMBUS_Alert |
| 4 | GND |
| 5 | +3.3 V |

Power SMB Header

The Power System Management Bus header for additional slave devices is located at JSMB1.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Power SMBus Header | |
|-------------------------------------|-------------------|
| Pin Definitions: Three Total | |
| Pin# | Definition |
| 1 | Data |
| 2 | GND |
| 3 | Clock |

Speaker Header

On the JD1 header, close pins 3 and 4 with a cap to use the onboard buzzer. If you wish to use an external speaker, close pins 1-4 with a cable.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Buzzer/External Speaker | |
|------------------------------------|-------------------|
| Pin Definitions: Four Total | |
| Pin# | Definition |
| Pins 1-4 | Speaker |

TPM/Port 80 Header

The JTPM1 header on the X14SAV-TLN4F motherboard is used to connect a Trusted Platform Module (TPM)/Port 80, which is available from Supermicro (optional). A TPM/Port 80 connector is a security device that supports encryption and authentication in hard drives. It allows the motherboard to deny access if the TPM associated with the storage drive is not installed in the system. Go to the following link for more information on the TPM: https://www.supermicro.com/manuals/other/AOM-TPM-9670V_9670H_X12_H12.pdf.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "Motherboard Quick Reference" on page 21.

| Trusted Platform Module Header | | | |
|--------------------------------|--------------|------|---------------|
| Pin Definitions: 10 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 1 | +3.3 V | 2 | SPI_CS# |
| 3 | RESET# | 4 | SPI_MISO |
| 5 | SPI_CLK | 6 | GND |
| 7 | SPI_MOSI | 8 | No Connection |
| 9 | +3.3 V Stdby | 10 | SPI_IRQ# |

VGA Header

A video (VGA) header is located on the motherboard and is used with an optional VGA cable (OTHR-1062A-10). The VGA header provides analog interface support between the computer and the video displays.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "Motherboard Quick Reference" on page 21.

USB Headers

The motherboard has one USB 3.2 header (JUSB2) and one USB 2.0 header (USB0/1). The onboard headers can be used to provide front side USB access with a cable (not included).

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "Motherboard Quick Reference" on page 21.

| (USB 2.0) Header | | | |
|----------------------------------|-------------------|-------------|-------------------|
| Pin Definitions: 10 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 1 | +5 V | 2 | +5 V |
| 3 | USB_N | 4 | USB_N |
| 5 | USB_P | 6 | USB_P |
| 7 | GND | 8 | GND |
| 9 | Key | 10 | No Connection |

| (USB 3.2 Gen 1) Header | | | |
|----------------------------------|--------------------|-------------|--------------------|
| Pin Definitions: 20 Total | | | |
| Pin# | Definitions | Pin# | Definitions |
| 1 | VBUS | 11 | IntA_P2_D+ |
| 2 | IntA_P1_SSRX- | 12 | IntA_P2_D- |
| 3 | IntA_P1_SSRX+ | 13 | GND |
| 4 | GND | 14 | IntA_P2_SSTX+ |
| 5 | IntA_P1_SSTX- | 15 | IntA_P2_SSTX- |
| 6 | IntA_P1_SSTX+ | 16 | GND |
| 7 | GND | 17 | IntA_P2_SSRX+ |
| 8 | IntA_P1_D- | 18 | IntA_P2_SSRX- |
| 9 | IntA_P1_D+ | 19 | VBUS |
| 10 | GND | 20 | No Connection |

4.3 Jumper Settings

To modify the operation of the motherboard, jumpers can be used to choose between optional settings. Jumpers create shorts between two pins to change the function of the connector. Pin 1 is identified with a square solder pad on the printed circuit board. See the diagram below for an example of jumping pins 1 and 2. Refer to the motherboard layout page for jumper locations.

Note: On two-pin jumpers, "Closed" means the jumper is on and "Open" means the jumper is off the pins.




Figure 4-1. Jumping Connector Pins

CMOS Clear

JBT1 on the X14SAV-TLN4F motherboard is used to clear CMOS, which will also clear any passwords. Instead of pins, this jumper consists of contact pads to prevent accidentally clearing the contents of CMOS.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference"](#) on page 21.



1. Power down the system.
2. Unplug the power cord(s).
3. Remove the cover of the chassis to access the motherboard.
4. Remove the onboard battery from the motherboard.

5. Short the CMOS pads, JBT1, with a metal object such as a small screwdriver for at least four seconds.

Note: Clearing CMOS will also clear all passwords.

6. Remove the screwdriver or shorting device.
7. Reinsert the battery.
8. Replace the cover.
9. Reconnect the power cord(s).
10. Power on the system.

LAN1 Enable/Disable

Use JPL1 to enable or disable LAN on the X14SAV-TLN4F. The default setting is Enabled.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| LAN1 Enable/Disable | |
|---------------------|-------------------|
| Jumper Settings | |
| Jumper Setting | Definition |
| Pins 1–2 | Enabled (Default) |
| Pins 2–3 | Disabled |

LAN2 Enable/Disable

Use JPL2 to enable or disable LAN on the X14SAV-TLN4F. The default setting is Enabled.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| LAN2 Enable/Disable | |
|---------------------|-------------------|
| Jumper Settings | |
| Jumper Setting | Definition |
| Pins 1–2 | Enabled (Default) |
| Pins 2–3 | Disabled |

ME Manufacturing Mode

Close pins 2–3 of jumper JPME2_CPU1 and JPME_PCH1 to bypass SPI flash security and force the system to operate in the manufacturing mode, which will allow the user to flash the system firmware from a host server for system setting modifications. Refer to the table below for jumper settings. The default setting is Normal.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "[Motherboard Quick Reference](#)" on page 21.

| ME Manufacturing Mode | |
|-----------------------|--------------------|
| Jumper Settings | |
| Jumper Setting | Definition |
| Pins 1–2 | Normal (Default) |
| Pins 2–3 | Manufacturing Mode |

PCIe Bifurcation

Use JRF1 and JRF2 to adjust the PCIe lane options on the PCIe slot. The options are x16 or x8x8.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "[Motherboard Quick Reference](#)" on page 21.

| PCIe Bifurcation | | |
|------------------|----------|---------------------|
| Jumper Settings | | |
| JRF1 | JRF2 | PEG |
| Pins 2–3 | Pins 2–3 | x16 (PCIe)(Default) |
| Pins 2–3 | Pins 1–2 | 2x8 (PCIe) |
| Pins 1–2 | Pins 1–2 | 1x8, 2x4 (PCIe) |

Onboard TPM Enable/Disable

Use JPT1 to enable or disable the onboard TPM.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under "[Motherboard Quick Reference](#)" on page 21.

| TPM Enable/Disable | |
|--------------------|-------------------|
| Jumper Settings | |
| Jumper Setting | Definition |
| Pins 1–2 | Enabled (Default) |
| Pins 2–3 | Disabled |

SIM Detect Option

Pins 2 and 4 on the JSIM1_OPT jumper are for SIM card detection. Since each SIM card vendor sets a different condition for detection, check with the vendor for the correct detection type and set the JSIM1_OPT jumper before installing the SIM card. Pins 1 and 3 on the JSIM1_OPT jumper are for 5G/LTE USB/PCIe module detection. Check with the vendor for the correct detection type and set the JSIM1_OPT jumper before installing the module. Pins 5 and 6 on the JSIM1_OPT jumper are for enabling or disabling M.2 B-Key storage module LED signal to the front panel HDD LED. Disconnect pins 5 and 6 to disable the LED signal.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| SIM Detect Option | |
|-------------------|---|
| Jumper Settings | |
| Jumper Settings | Definition |
| Pins 1–3 | USB (Default) |
| Pins 1–3 Open | PCIe Low Active |
| Pins 2–4 | SIM Detect Low Active (Default) |
| Pins 2–4 Open | SIM Detect High Active |
| Pins 5–6 | M.2 B-Key Storage LED Enabled (Default) |
| Pins 5–6 Open | M.2 B-Key Storage LED Disabled |

VGA Enable/Disable

Jumper JPG1 allows you to enable the onboard VGA connector on the X14SAV-TLN4F motherboard. The default setting is pins 1–2 to enable the connection.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| VGA Enable/Disable | |
|---------------------------|-------------------|
| Jumper Settings | |
| Jumper Setting | Definition |
| Pins 1–2 | Enabled (Default) |
| Pins 2–3 | Disabled |

Watchdog Timer

Watchdog (JWD1) is a system monitor that can reboot the system when a software application hangs. Close pins 1–2 to reset the system if an application hangs. Close pins 2–3 to generate a non-maskable interrupt (NMI) signal for the application that hangs. The watchdog must also be enabled in the BIOS.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Watchdog Timer | |
|------------------------|-------------------|
| Jumper Settings | |
| Jumper Setting | Definition |
| Pins 1–2 | Reset (Default) |
| Pins 2–3 | NMI |
| Open | Disabled |

4.4 LED Indicators

For information about the LED indicators on the SYS-E300-14AR server, refer to the following content.

BMC Heartbeat LED

A BMC Heartbeat LED is located on the X14SAV-TLN4F motherboard. When this LED is blinking, the BMC is functioning normally.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| BMC Heartbeat LED Indicator | |
|-----------------------------|------------|
| LED Color | Definition |
| Orange: Blinking | BMC Normal |

Power LED

The Power LED is located on the X14SAV-TLN4F motherboard. When this LED is on, power is present on the motherboard. In suspend mode, this LED will blink on and off. Be sure to turn off the system and unplug the power cord before removing or installing components.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Power LED Indicator | |
|---------------------|------------|
| LED Color | Definition |
| Blinking | S3 Status |
| Green | Power On |

Unit ID (UID) LED

The front UID LED indicator is located UID_LED1 on the X14SAV-TLN4F motherboard. This UID indicator provides easy identification of a system that may need services.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| UID LED | |
|----------------------|--------------------|
| LED Indicator | |
| LED Color | Definitions |
| Blue: On | System Identified |

4.5 Input/Output Ports

For information about input/output ports on the SYS-E300-14AR server, refer to the following content.




Figure 4-2. X14SAV-TLN4F I/O Ports

| X14SAV-TLN4F I/O Ports | | | | | |
|------------------------|-------------------|---|-------------------|----|------------------------------------|
| # | Description | # | Description | # | Description |
| 1 | BMC LAN Port | 5 | HDMI 2.1 Port | 9 | LAN1 (2.5G) |
| 2 | USB4 (3.2, 10 Gb) | 6 | USB2 (3.2, 10 Gb) | 10 | LAN2 (2.5G) |
| 3 | USB5 (3.2, 10 Gb) | 7 | USB3 (3.2, 10 Gb) | 11 | LAN3 (10G) (on - TLN4F only) |
| 4 | DisplayPort | 8 | UID Button | 12 | LAN4 (10G) (10G) (on - TLN4F only) |

HDMI and DP Ports

One High Definition Multimedia Interface (HDMI) port is included on the I/O port. This port is used to display both high definition video and digital sound through an HDMI-capable display. HDMI 2.1 allows faster frame rates and is backward compatible with previous HDMI versions. This port provides Intel HD graphics digital output with a resolution up to 4096 x 2160 at 60 Hz refresh rate with HDR. There is also one DP port included on the I/O port. These ports deliver digital display and fast refresh rate. They can connect to virtually any display device using a DisplayPort adapter for devices such as VGA, DVI, or HDMI.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

LAN Ports

Two 2.5G (JLAN1) LAN ports and two 10G (JLAN2) LAN ports are located on the I/O ports. There is also one BMC LAN port on the I/O ports. These ports accept RJ45 cables.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

Unit Identifier Button

A Unit Identifier (UID) button and two LED indicators are located on the motherboard. The UID button is located near the I/O ports of the X14SAV-TLN4F motherboard.

Note: After pushing and holding the UID button for 12 seconds, all BMC settings including username and password will revert back to the factory default. Only the network settings and FRU are retained.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Function | User Input | Behavior | LED Activity |
|-------------------|---|--|--|
| UID LED Indicator | Push once Push again | Turns on the UID LED Turns off the UID LED | UID LED turns solid blue UID LED turns off |
| BMC Reset | Push and hold for 6 seconds Push and hold for 12 seconds | BMC will do a cold boot BMC will reset to factory default | BMC Heartbeat LED turns solid green BMC Heartbeat LED turns solid green |

| UID Button Pin Definitions: Four Total | |
|--|------------|
| Pin# | Definition |
| 1 | Button In |
| 2 | GND |
| G1 | GND |
| G2 | GND |

| UID LED Pin Definitions: Four Total | |
|---|-----------|
| Color | Status |
| 1 | Button In |
| 2 | GND |
| G1 | GND |
| G2 | GND |

USB Ports

There are four USB 3.2 ports (JUSBJ1, JUSBJ2) on the motherboard.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| USB 3.2 Gen 2 Ports | | | |
|---------------------------|------------|------|------------|
| Pin Definitions: 20 Total | | | |
| Pin# | Definition | Pin# | Definition |
| 1 | GND | 11 | GND |
| 2 | TX1+ | 12 | TX2- |
| 3 | TX1- | 13 | TX2+ |
| 4 | GND | 14 | GND |
| 5 | RX1+ | 15 | RX2- |
| 6 | RX1- | 16 | RX2+ |
| 7 | GND | 17 | GND |
| 8 | D1+ | 18 | D2+ |
| 9 | D1- | 19 | D2- |
| 10 | VBUS1 | 20 | VBUS2 |

Front Control Panel

JF1 on the X14SAV-TLN4F motherboard contains header pins for various buttons and indicators that are normally located on a control panel at the front of the chassis. These connectors are designed specifically for use with Supermicro chassis.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

Power Button

The Power Button connection is located on pins 1 and 2 of JF1 on the X14SAV-TLN4F motherboard. Momentarily contacting both pins will power on/off the system. This button can also be configured to function as a suspend button (with a setting in the BIOS). To turn off the power when the system is in suspend mode, press the button for four seconds or longer.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Power Button | |
|------------------------------|-------------------|
| Pin Definitions (JF1) | |
| Pin# | Definition |
| 1 | Signal |
| 2 | GND |

Reset Button

The Reset Button connection is located on pins 3 and 4 of JF1 on the X14SAV-TLN4F motherboard. Attach it to a hardware reset switch on the computer case to reset the system.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Reset Button | |
|------------------------------|-------------------|
| Pin Definitions (JF1) | |
| Pin# | Definition |
| 3 | Reset |
| 4 | GND |

Overheat/Fan Fail LED

Connect an LED cable to pins 7 and 8 of the Front Control Panel to use the UID LED and Overheat/Fan Fail LED connections. Attach a cable to pin 7 to use the UID button. The LED on pin 8 provides warnings of overheat or fan failure.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| OH/Fan Fail Indicator Status | | UID and OH-FAN Fail LED | |
|-------------------------------------|-------------------|--------------------------------|-------------------|
| Pin Definitions (JF1) | | Pin Definitions (JF1) | |
| State | Definition | Pin# | Definition |
| Off | Normal | 7 | UID LED |
| On | Overheat | 8 | OH-Fan Fail LED |
| Flashing | Fan Fail | | |

NIC1/NIC2 (LAN1/LAN2)

The Network Interface Controller (NIC) LED connection for LAN port 1 is located on pins 11 and 12 of JF1 on the X14SAV-TLN4F motherboard, and LAN port 2 is on pins 9 and 10. Attach the NIC LED cables here to display network activity.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| LAN1/LAN2 LED | |
|-----------------------|----------------------|
| Pin Definitions (JF1) | |
| Pin# | Definition |
| 9 | +3.3 V Stby |
| 10 | NIC2 Link/Active LED |
| 11 | +3.3 V Stby |
| 12 | NIC1 Link/Active LED |

HDD LED

The HDD LED connection is located on pins 13 and 14 of JF1 on the X14SAV-TLN4F motherboard. Attach a cable to pin 14 to show storage drive activity status.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| HDD LED | |
|-----------------------|------------|
| Pin Definitions (JF1) | |
| Pin# | Definition |
| 13 | +3.3 V |
| 14 | HDD LED |

Power LED

The Power LED connection is located on pins 15 and 16 of JF1 on the X14SAV-TLN4F motherboard.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| Power LED | |
|------------------------------|-------------------|
| Pin Definitions (JF1) | |
| Pin# | Definition |
| 15 | +3.3 V Stby |
| 16 | PWR LED |

NMI Button

The non-maskable interrupt (NMI) button header is located on pins 19 and 20 of JF1 on the X14SAV-TLN4F motherboard.

For a detailed diagram of the X14SAV-TLN4F motherboard, see the layout under ["Motherboard Quick Reference" on page 21](#).

| NMI Button | |
|------------------------------|-------------------|
| Pin Definitions (JF1) | |
| Pin# | Definition |
| 19 | Control |
| 20 | GND |

Chapter 5:

Software

After the SYS-E300-14AR server has been installed, you can install the Operating System (OS), configure RAID settings, and install the drivers.

| | |
|--|-----------|
| 5.1 Microsoft Windows OS Installation | 85 |
| Installing the OS | 85 |
| Driver Installation | 86 |
| 5.2 BMC | 88 |
| BMC ADMIN User Password | 88 |

5.1 Microsoft Windows OS Installation

If you will be using RAID, you must configure RAID settings before installing the Windows OS and the RAID driver. Refer to the RAID Configuration User Guides posted on our website at <https://www.supermicro.com/support/manuals>.

Installing the OS

1. Create a method to access the Microsoft Windows installation ISO file. That can be a USB flash or media drive, or the BMC KVM console.
2. Retrieve the proper drivers. Go to the Supermicro web page for your motherboard and click on "Download the Latest Drivers and Utilities," select the proper driver, and copy it to a USB flash drive.
3. Boot from a bootable device with Windows OS installation. You can see a bootable device list by pressing <F11> during the system bootup.




Figure 5-1. Selecting the Boot Device

4. During Windows Setup, continue to the dialog box where you select the drives on which to install Windows. If the disk you want to use is not listed, click on the "Load driver" link at the bottom left corner.




Figure 5-2. Loading the Driver Link

To load the driver, browse the USB flash drive for the proper driver files.

5. Once all devices are specified, continue with the installation.
6. After the Windows OS installation has completed, the system will automatically reboot multiple times for system updates.

Driver Installation

The Supermicro website contains drivers and utilities for your system at the following page:

<https://www.supermicro.com/wdl>.

Some of these drivers and utilities must be installed, such as the chipset driver. After accessing the website, go into the CDR_Images (in the parent directory of the above link) and locate the ISO file for your motherboard. Download this file to a USB flash or media drive. You may also use a utility to extract the ISO file if preferred.

Another option is to go to the Supermicro website at <https://www.supermicro.com>. Find the product page for your motherboard and download the latest drivers and utilities. Insert the flash drive or disk, and the screenshot shown below should appear.

Note: Click the icons showing a hand writing on paper to view the readme files for each item. Click the computer icons to the right of these items to install each item (from top to bottom) one at a time. After installing each item, you must reboot the system before moving on to the next item on the list. The bottom icon with a CD on it allows you to view the entire contents.




Figure 5-3. Driver Installation Screenshot

5.2 BMC

The X14SAV-TLN4F motherboard provides remote access, monitoring, and management through the baseboard management controller (BMC) and other management controllers distributed among different system modules. There are several BIOS settings that are related to BMC. For general documentation and information on BMC, visit our website at the following page:

<https://www.supermicro.com/en/solutions/management-software/bmc-resources>

BMC ADMIN User Password

For security, each system is assigned a unique default BMC password for the ADMIN user. The password can be found on a sticker on the motherboard and a sticker on the chassis, for Supermicro chassis. The sticker also displays the BMC MAC address. If necessary, the password can be reset using the Supermicro IPMICFG tool.



Figure 5-4. BMC Password Label

Chapter 6:

Optional Components

This chapter describes alternate configurations and optional system components for the SYS-E300-14AR server.

| | |
|--------------------------------------|-----------|
| 6.1 TPM Security Module | 90 |
|--------------------------------------|-----------|

6.1 TPM Security Module

This is an SPI-capable TPM 2.0 with Infineon 9672 controller.

The JTPM1 header is used to connect a Trusted Platform Module (TPM). A TPM is a security device that supports encryption and authentication in storage drives. It enables the X14SAV-TLN4F motherboard to deny access if the TPM associated with the storage drive is not installed in the SYS-E300-14AR server.

For details and installation procedures, refer to the following page:

<https://www.supermicro.com/en/products/accessories/addon/AOM-TPM-9672V.php>

- AOM-TPM-9672V (TCG 2.0)

Chapter 7:

Troubleshooting and Support

The following content contains information on common issues and how to resolve them.

| | |
|--|------------|
| 7.1 Online Resources | 92 |
| 7.2 Baseboard Management Controller (BMC) | 93 |
| 7.3 Troubleshooting Procedures | 94 |
| Before Power On | 94 |
| No Power | 94 |
| No Video | 94 |
| System Boot Failure | 94 |
| Memory Errors | 95 |
| Losing the System's Setup Configuration | 95 |
| If the System Becomes Unstable | 95 |
| 7.4 CMOS Clear | 97 |
| 7.5 Motherboard Battery | 98 |
| 7.6 Where to Get Replacement Components | 99 |
| 7.7 Technical Support Procedures | 100 |
| Returning Merchandise for Service | 100 |
| 7.8 Feedback | 102 |

7.1 Online Resources

A great deal of information is available on the Supermicro website. From the top menu of the Supermicro home page at <https://www.supermicro.com>:

- Specifications for servers and other hardware are available by clicking **Products**.
- The **Support** option offers downloads (manuals, BIOS/BMC, drivers, etc.), FAQs, RMA, warranty, and other service extensions.

Direct Links for the SYS-E300-14AR System

- SYS-E300-14AR system specifications page:
<https://www.supermicro.com/en/products/system/embedded/fan-based%20embedded/sys-e300-14ar>
- X14SAV-TLN4F motherboard page for links to the quick reference guide, user manual, validated storage drives, and more:
<https://www.supermicro.com/en/products/motherboard/x14sav-tln4f>

Direct Links for General Support and Information

- Frequently Asked Questions: <https://www.supermicro.com/FAQ/index.php>
- TPM User Guide: https://www.supermicro.com/manuals/other/AOM-TPM-9670V_9670H_X12_H12.pdf
- Product Resources page for validated memory details:
<https://www.supermicro.com/support/resources/mem.cfm>
- Product Matrices page for links to tables summarizing specs for systems, motherboards, power supplies, riser cards, add-on cards, and more:
<https://www.supermicro.com/en/support/product-matrices>
- Security Center for recent security notices:
https://www.supermicro.com/en/support/security_center
- Supermicro Phone and Addresses: <https://www.supermicro.com/en/about/contact>

7.2 Baseboard Management Controller (BMC)

The SYS-E300-14AR server supports the Baseboard Management Controller (BMC). BMC is used to provide remote access, monitoring, and management. There are several BIOS settings that are related to BMC.

For general documentation and information on BMC, visit our website at the following page:

<https://www.supermicro.com/en/solutions/management-software/bmc-resources>




Figure 7-1. BMC Dashboard

7.3 Troubleshooting Procedures

Use the following procedures to troubleshoot your system. If you have followed all of the procedures below and still need assistance, refer to the ["Technical Support Procedures" on page 100](#) section in this chapter. Always disconnect the AC power cord before adding, changing or installing any non hot-swappable hardware components. If the below steps do not fix the setup configuration problem, contact your vendor for repairs.

Before Power On

1. Make sure that there are no short circuits between the motherboard and chassis.
2. Disconnect all ribbon/wire cables from the motherboard, including those for the keyboard and mouse.
3. Remove all add-on cards.
4. Install the processor (making sure it is fully seated) and connect the front panel connectors to the motherboard.

No Power

1. Make sure that there are no short circuits between the motherboard and the chassis.
2. The battery on your motherboard may be old. Check to verify that it still supplies approximately 3 VDC. If it does not, replace it with a new one.

No Video

1. If the power is on, but you do not have video, remove all add-on cards and cables.
2. Remove all memory modules and turn on the system (if the alarm is on, check the specs of memory modules, reset the memory, or try a different one).

System Boot Failure

If the system does not display Power-On-Self-Test (POST) or does not respond after the power is turned on, do the following:

1. Remove all components from the motherboard, especially the DIMMs. Power on the system and check if the power-on LED and the BMC Heartbeat LED are on, and system fans are spinning.

2. Turn on the system with only one DIMM installed. If the system boots, check for bad DIMMs or slots by following the Memory Errors Troubleshooting procedure in this chapter.

Memory Errors

When suspecting faulty memory is causing the system issue, check the following:

1. Make sure that the memory modules are compatible with the system and are properly installed. See "[Maintenance and Component Installation](#)" on [page 33](#) for installation instructions. (For memory compatibility, refer to the "Tested Memory List" link on the motherboard's product page to see a list of supported memory.)
2. Check if different speeds of DIMMs have been installed. It is strongly recommended that you use the same RAM type and speed for all DIMMs in the system.
3. Make sure that you are using the correct type of DIMMs recommended by the manufacturer.
4. Check for bad DIMMs or slots by swapping a single module among all memory slots and check the results.

Losing the System's Setup Configuration

1. Make sure that you are using a high-quality power supply. A poor-quality power supply may cause the system to lose the CMOS setup information. Refer to "[Introduction](#)" on [page 13](#) for details on recommended power supplies.
2. The battery on your motherboard may be old. Check to verify that it still supplies approximately 3 VDC. If it does not, replace it with a new one.

If the System Becomes Unstable

If the system becomes unstable during or after OS installation, check the following:

1. Processor/BIOS support: Make sure that your processor is supported and that you have the latest BIOS installed in your system.
2. Memory support: Make sure that the memory modules are supported. Refer to the product page on our website at <https://www.supermicro.com>. Test the modules using memtest86 or a similar utility.

Note: Click on the "Tested Memory List" link on the motherboard's product page to see a list of supported memory.

3. Storage Drive support: Make sure that all storage drives work properly. Replace the failed storage drives with good ones.
4. System cooling: Check the system cooling to make sure that all heatsink fans and processor/system fans, etc., work properly. Check the hardware monitoring settings in the BMC to make sure that the processor and system temperatures are within the normal range. Also, check the front panel Overheat LED and make sure that it is not on.
5. Adequate power supply: Make sure that the power supply provides adequate power to the system. Make sure that all power connectors are connected. Refer to our website for more information on the minimum power requirements.
6. Proper software support: Make sure that the correct drivers are used.

If the system becomes unstable before or during OS installation, check the following:

1. Source of installation: Make sure that the devices used for installation are working properly, including boot devices such as a CD/Media drive.
2. Cable connection: Check to make sure that all cables are connected and working properly.
3. Use the minimum configuration for troubleshooting: Remove all unnecessary components (starting with add-on cards first), and use the minimum configuration (but with the processor and a memory module installed) to identify the trouble areas. Refer to the steps listed above in this section for proper troubleshooting procedures.
4. Identify bad components by isolating them: If necessary, remove a component in question from the chassis, and test it in isolation to make sure that it works properly. Replace a bad component with a good one.
5. Check and change one component at a time instead of changing several items at the same time. This will help isolate and identify the problem.
6. To find out if a component is good, swap this component with a new one to see if the system will work properly. If so, then the old component is bad. You can also install the component in question in another system. If the new system works, the component is good and the old system has problems.

7.4 CMOS Clear

JBT1 on the X14SAV-TLN4F motherboard is used to clear CMOS, which will also clear any passwords. For information on clearing CMOS, refer to ["CMOS Clear" on page 71](#) earlier in this manual.

7.5 Motherboard Battery

For information on removing, disposing of, and replacing the motherboard battery of your system, refer to ["Motherboard Battery Removal and Installation" on page 50](#).

7.6 Where to Get Replacement Components

If you need replacement parts for your SYS-E300-14AR server, to ensure the highest level of professional service and technical support, purchase exclusively from our Supermicro Authorized Distributors/System Integrators/Resellers. A list can be found on the Supermicro website:

<https://www.supermicro.com>

Under the "Buy" menu, click the "Where to Buy" link.

7.7 Technical Support Procedures

Before contacting Technical Support, take the following steps. Also, note that as a motherboard manufacturer, Supermicro also sells motherboards through its channels, so it is best to first check with your distributor or reseller for troubleshooting services. They should know of any possible problems with the specific system configuration that was sold to you.

1. Refer to "Troubleshooting Procedures" on page 94 or see the FAQs on our website (<https://www.supermicro.com/FAQ/index.php>) before contacting Technical Support.
2. BIOS upgrades can be downloaded from our website (https://www.supermicro.com/support/resources/bios_ipmi.php).
3. If you still cannot resolve the problem, include the following information when contacting Supermicro for technical support:
 - Motherboard model and PCB revision number
 - BIOS release date/version (This can be seen on the initial display when your system first boots up.)
 - System configuration
4. An example of a Technical Support form is on our website at <https://webpr3.supermicro.com/SupportPortal>.
5. Distributors: For immediate assistance, have your account number ready when placing a call to our Technical Support department. For Supermicro contact information, refer to "Contacting Supermicro" on page 12.

Returning Merchandise for Service

A receipt or copy of your invoice marked with the date of purchase is required before any warranty service will be rendered. You can obtain service by calling your vendor for a Returned Merchandise Authorization (RMA) number. When returning the server to the manufacturer, the RMA number should be prominently displayed on the outside of the shipping carton, and the shipping package is mailed prepaid or hand-carried. Shipping and handling charges will be applied for all orders that must be mailed when service is complete.

For faster service, RMA authorizations can be requested online at the following page:

<https://www.supermicro.com/RmaForm>

Whenever possible, repack the server in the original Supermicro carton, using the original packaging material. If these are no longer available, be sure to pack the server securely, using packaging material to surround the server so that it does not shift within the carton and become damaged during shipping.

This warranty only covers normal consumer use and does not cover damages incurred in shipping or from failure due to the alteration, misuse, abuse or improper maintenance of products.

During the warranty period, contact your distributor first for any product problems.

7.8 Feedback

Supermicro values your feedback as we strive to improve our customer experience in all facets of our business. Email us at Techwriterteam@supermicro.com to provide feedback on our manuals.

Chapter 8:

UEFI BIOS

The following content contains information on BIOS configuration with the SYS-E300-14AR server.

| | |
|--|------------|
| 8.1 Introduction | 104 |
| 8.2 Main Setup | 106 |
| 8.3 Advanced Setup Configurations | 108 |
| 8.4 Event Logs | 145 |
| 8.5 BMC | 147 |
| 8.6 Security | 151 |
| 8.7 Boot | 155 |
| 8.8 Save & Exit | 157 |
| 8.9 MEBx | 159 |

8.1 Introduction

This chapter describes the AMIBIOS™ Setup utility for the motherboard. The BIOS is stored on a chip and can be easily upgraded using the UEFI script (flash.nsh), the BMC WebUI, or the SuperServer Automation Assistant (SAA) utility.

Note: Due to periodic changes to the BIOS, some settings may have been added or deleted and might not yet be recorded in this manual. Refer to the Manual Download area of our website for any changes to BIOS that may not be reflected in this manual.

Updating BIOS

It is recommended that you do not upgrade your BIOS if you are not experiencing any problems with your system. Updated BIOS files are located on our website at the following page:

https://www.supermicro.com/support/resources/bios_ipmi.php

Check our BIOS warning message and the information on how to update your BIOS on our website. Select your motherboard model and download the BIOS file to your computer. Also, check the current BIOS revision to make sure that it is newer than your BIOS before downloading.

Important: Do not shut down or reset the system while updating the BIOS to prevent possible system boot failure! Read the motherboard README file carefully before you perform the BIOS update.

To update the BIOS under the UEFI Shell, unzip the BIOS file onto a bootable USB device and then boot into the built-in UEFI Shell. For motherboards with BMC support, type "flash.nsh <BIOS filename> <BMC Username> <BMC Password>" to start the BIOS update. The flash.nsh script will invoke the SAA (EFI) tool automatically to perform the BIOS update, beginning with uploading the BIOS image to BMC. After uploading the BIOS image, the system will reboot to continue the process. The BMC will take over and continue the BIOS update in the background. The process will take 3–5 minutes. Refer to the README file for more information.

Starting the Setup Utility

To enter the BIOS Setup utility, press the <Delete> key while the system is booting-up. In most cases, the <Delete> key is used to invoke the BIOS Setup screen. There are a few cases when other hot keys are used, such as <F1>, <F2>, etc. Each main BIOS menu option is described in this manual.

The Main BIOS screen has two main frames. The left frame displays all the options that can be configured. "Grayed-out" options cannot be configured. The right frame displays the key legend. Above the key legend is an area reserved for a text message. When a BIOS submenu or item is selected in the left frame, it is highlighted in white. Often a text message will accompany it. (Note that BIOS has default text messages built in. We retain the option to include, omit, or change any of these text messages.) Settings printed in **Bold** are the default values.

A "▶" indicates a submenu. Highlighting such an item and pressing the <Enter> key open the list of settings within that submenu.

The BIOS Setup utility uses a key-based navigation system called hot keys. Most of these hot keys (<F1>, <F2>, <F3>, <F4>, <F5>, <F6>, <Enter>, <ESC>, the arrow keys, etc.) can be used at any time during the setup navigation process.

8.2 Main Setup

The Main setup screen appears when the AMI BIOS Setup utility is first entered. To return to the Main setup screen, select the Main tab at the top of the screen. The Main BIOS setup screen is shown below.




Figure 8-1. Main Setup Screen

System Date/System Time

Use the two features to change the system date and time. Highlight **System Date** or **System Time** using the arrow keys. Enter new values using the keyboard. Press the <Tab> key or the arrow keys to move between fields. The date must be entered in MM/DD/YYYY format. The time is entered in HH:MM:SS format.

Note: The time is in the 24-hour format. For example, 5:30 P.M. appears as 17:30:00.

Supermicro X14SAV-TLN4F

BIOS Version

This feature displays the version of the BIOS ROM used in the system.

Build Date

This feature displays the date when the version of the BIOS ROM used in the system was built.

CPLD Version

This feature displays the version of the Complex-Programmable Logical Device (CPLD) used in the system.

Memory Information

Total Memory

This feature displays the total size of memory available in the system.

8.3 Advanced Setup Configurations

Use the arrow keys to select the Advanced submenu and press <Enter> to access the submenu items.

Important: Use caution when changing the Advanced settings. An incorrect value, an improper DRAM frequency, or a wrong BIOS timing setting may cause the system to malfunction. When this occurs, revert the settings to the default manufacturing settings.




Figure 8-2. Advanced Setup Screen

ACPI Settings Menu

▶ ACPI Settings

ACPI Sleep State

Use this feature to select the ACPI Sleep State that the system will enter into when the suspend button is activated. The options are Suspend Disabled and **S3 (Suspend to RAM)**.

WHEA Support

Select Enabled to support the Windows Hardware Error Architecture (WHEA) platform. WHEA provides a common infrastructure for the system to handle hardware errors within the Windows OS environment, reducing system crashes and enhancing system recovery and health monitoring. The options are Disabled and **Enabled**.

High Precision Event Timer

Select Enabled to activate the High Precision Event Timer (HPET) that produces periodic interrupts at a much higher frequency than a Real-time Clock (RTC) does in synchronizing multimedia streams, providing smooth playback and reducing the dependency on other timestamp calculation devices, such as an x86 RDTSC Instruction embedded in the CPU. The High Performance Event Timer is used to replace the 8254 Programmable Interval Timer. The options are Disabled and **Enabled**.

Native PCIe Enable

Enable this feature to grant control of PCI Express Native hot plug, PCI Express Power Management Events, and PCI Express Capability Structure Control. The options are Disabled and **Enabled**.

Native ASPM

Select Enabled for the operating system to control the ASPM, or Disabled for the BIOS to control the ASPM. The options are Auto, Enabled, and **Disabled**.

Boot Feature Menu

► Boot Feature

Quiet Boot

Use this feature to select the screen between displaying the Power On Self Test (POST) messages or the OEM logo upon bootup. Select Disabled to display the POST messages. Select Enabled to display the OEM logo instead of the normal POST messages. The options are Disabled and **Enabled**.

Note: BIOS POST messages are always displayed regardless of the setting of this feature.

Fast Boot

This feature enables the system to boot with a minimal set of required devices to launch. This has no effect on BBS boot options. The options are **Disabled** and Enabled.

Bootup NumLock State

Use this feature to set the power on state for the <Num Lock> key. The options are **On** and Off.

Wait For "F1" If Error

Select Enabled to force the system to wait until the <F1> key is pressed if an error occurs. The options are Disabled and **Enabled**.

Re-try Boot

If this feature is set to Enabled, the system BIOS will automatically reboot the system from an Extensible Firmware Interface (EFI) boot device after an initial boot failure. The options are **Disabled** and Enabled.

Power Configuration**Watch Dog Function**

Select Enabled to allow the Watchdog timer to reboot the system when it is inactive for more than five minutes. The options are **Disabled** and Enabled.

Restore on AC Power Loss

Use this feature to set the power state after a power outage. Select Stay Off for the system power to remain off after a power loss. Select Power On for the system power to be turned on after a power loss. Select Last State to allow the system to resume its last power state before a power loss. The options are Stay Off, Power On, and **Last State**.

Power Button Function

This feature controls how the system shuts down when the power button is pressed. Select 4 Seconds Override to power off the system after pressing and holding the power button for four seconds or longer. Select Instant Off to instantly power off the system as soon as you press the power button. The options are **Instant Off** and 4 Seconds Override.

DeepSx Power Policies

Use this feature to configure the Advanced Configuration and Power Interface (ACPI) settings for the system. Enable S4 to use Hibernation mode (Suspend to Disk) so that all data stored in the main memory can be saved in a non-volatile memory area such as in a hard drive and then power down the system. Enable S5 to power off the whole system except the power supply unit (PSU) and keep the power button alive so that you can wake up the system by using a USB keyboard or mouse. The options are **Disabled**, Enabled In S4-S5, and Enabled in S5.

Delay Time Before PCI Enumeration

Use this feature to set the amount of time the system waits before enumerating PCI devices during the boot process. The valid range is 0–30 with a step of 1 second. The default setting is **0** for off, meaning the system will skip the delay time and immediately begin enumerating PCI devices.

CPU Configuration Menu

► CPU Configuration

Important: Setting the wrong values in this section may cause the system to malfunction.

The following processor information is displayed.

- Processor BSP Revision
- CPU Signature
- Microcode Patch
- Max CPU Speed
- Min CPU Speed
- CPU Speed
- Number of Performance-core(s)
- Number of Efficient-core(s)
- VMX
- SMX/TXT
- 64-bit
- EIST Technology
- CPU C3 state
- CPU C6 state
- CPU C7 state
- CPU C8 state
- CPU C9 state
- CPU C10 state
- Performance L1 Data Cache
- Performance L1 Instruction Cache
- Performance L2 Cache
- Performance L3 Cache
- Efficient L1 Data Cache

- Efficient L1 Instruction Cache
- Efficient L2 Cache
- Efficient L3 Cache

Intel Virtualization Technology

Select Enabled to enable the Intel Vanderpool Technology for Virtualization platform support, which allows multiple operating systems to run simultaneously on the same computer to maximize system resources for performance enhancement. The options are Disabled and **Enabled**. Changes take effect after you save settings and reboot the system.

Notes:

- This feature is NOT available when "TXT Support" is set to Enabled.
- This feature is NOT available when "Workload Profile" is set to Virtualization.

Active Performance-cores

This feature determines how many performance cores will be activated for each processor package. When all is selected, all cores in the processor will be activated. The options are **All**, 7, 6, 5, 4, 3, 2, and 1.

Active Efficient-cores

This feature determines how many efficient cores will be activated for each processor package. When all is selected, all cores in the processor will be activated. The options are **All**, 11, 10, 9, 8, 7, 6, 5, 4, 3, 2, and 1.

AES

Select Enabled to use the Intel Advanced Encryption Standard (AES) to ensure data security. The options are Disabled and **Enabled**.

Boot Performance Mode

This feature allows you to select the performance state that the BIOS will set before the operating system handoff. The options are **Max Non-Turbo Performance** and Turbo Performance.

Intel® SpeedStep™

Intel SpeedStep Technology allows the system to automatically adjust processor voltage and core frequency to reduce power consumption and heat dissipation. The options are Disabled and **Enabled**.

Intel® Speed Shift Technology

Use this feature to enable or disable Intel Speed Shift Technology support. When this feature is enabled, the Collaborative Processor Performance Control (CPPC) version 2 interface will be available to control CPU P-States. The options are Disabled and **Enabled**.

Turbo Mode

Select Enabled to allow the CPU to operate at the manufacturer-defined turbo speed by increasing CPU clock frequency. This feature is available when it is supported by the processors used in the system. The options are Disabled and **Enabled**.

Notes:

- This feature is available when "SpeedStep (P-States)" is set to Enabled.
- This feature is available when "Workload Profile" is set to Disabled.

Power Limit 1 Override

Select Enabled to support average power limit (PL1) override. The options are **Disabled** and Enabled.

Power Limit 2 Override

Select Enabled to support rapid power limit (PL2) override. The options are Disabled and **Enabled**.

Power Limit 2

Use this feature to configure the value for Power Limit 2. The value is in milliwatts and the step size is 125 mW. Use the number keys on your keyboard to enter the value. Enter 0 to use the manufacture default setting. If the value is 0, the BIOS will set PL2 as 1.25* TDP.

C-States

Use this feature to enable the C-State of the CPU. The options are Disabled and **Enabled**.

Enhanced C-States

Use this feature to enable the enhanced C-State of the CPU. The options are Disabled and **Enabled**.

C-State Auto Demotion

Use this feature to prevent unnecessary excursions into the C-states to improve latency. The options are Disabled and **C1**.

C-State Un-Demotion

This feature allows you to enable or disable the un-demotion of C-State. The options are Disabled and **C1**.

Package C-State Demotion

Use this feature to enable or disable the Package C-State demotion. The options are Disabled and **Enabled**.

Package C-State Un-Demotion

Use this feature to enable or disable the Package C-State un-demotion. The options are Disabled and **Enabled**.

C-State Pre-Wake

This feature allows you to enable or disable the C-State Pre-Wake. The options are Disabled and **Enabled**.

Package C-State Limit

Use this feature to set the Package C-State limit. The options are C0/C1, C2, C3, C6, C7, C7s, C8, C9, C10, Cpu Default, and **Auto**.

Monitor MWAIT

Select Enabled to support MONITOR and MWAIT, which are two instructions in Streaming SIMD Extension 3 (SSE3) to improve synchronization between multiple threads for CPU performance enhancement. The options are Disabled and **Enabled**.

Chipset Configuration Menu

► Chipset Configuration

Important: Setting the wrong values in this section may cause the system to malfunction.

System Agent (SA) Configuration

VT-d Supported

VT-d

Select Enabled to activate Intel Virtualization Technology support for Direct I/O VT-d by reporting the I/O device assignments to VMM through the DMAR ACPI Tables. This feature offers fully-protected I/O resource-sharing across the Intel platforms, providing the user with greater reliability, security and availability in networking and data-sharing. The options are **Enabled** and Disabled.

X2APIC Enable

Use this feature to enable or disable the Advanced Programmable Interrupt Controller (X2APIC) operating mode. The options are Disabled and **Enabled**.

DMA Control Guarantee

Use this feature to enable or disable DMA Control Guarantee bit. The options are **Enabled** and Disabled.

Memory Configuration Menu

▶ **Memory Configuration**

This submenu is used to configure the Integrated Memory Controller (IMC) settings.

- Memory RC Version
- Memory Frequency
- Memory Timings (tCL-tRCD-tRP-tRAS)
- DIMMA1
- DIMMA2
- DIMMB1
- DIMMB2

Maximum Memory Frequency

Use this feature to set the maximum memory frequency for onboard memory modules. The options are **Auto**, 1600, 2400, 3200, 3600, 4000, 4200, 4400, 4600, 4800, 5000, 5200, 5400, 5600, 5800, 6000, 6200, and 6400.

Max TOLUD

This feature sets the maximum TOLUD value, which specifies the "Top of Low Usable DRAM" memory space to be used by internal graphics devices, GTT Stolen Memory, and TSEG, respectively, if these devices are enabled. The options are **Dynamic**, 1 GB, 1.25 GB, 1.5 GB, 1.75 GB, 2 GB, 2.25 GB, 2.5 GB, 2.75 GB, 3 GB, 3.25 GB, and 3.5 GB.

Memory Scrambler

Use this feature to enable or disable memory scrambler support. The options are Disabled and **Enabled**.

Force ColdReset

Use this feature to enable or disable a cold boot during a MRC execution. The options are Enabled and **Disabled**.

Force Single Rank

Select enabled to use only Rank 0 in each DIMM. The options are **Disabled** and Enabled.

Memory Remap

Use this feature to enable or disable memory remap above 4 GB. The options are **Enabled** and Disabled.

MRC Fast Boot

Use this feature to enable or disable fast path through the memory reference code. The options are Disabled and **Enabled**.

Total Memory Encryption

Use this feature to enable or disable Total Memory Encryption (TME). When enabled, Intel TME enhances memory data security. The options are **Disabled** and Enabled.

Graphics Configuration Menu

► Graphics Configuration

This submenu allows you to configure the graphics configuration settings.

Graphics Configuration

IGFX GOP Version

Skip Scanning of External Gfx Card

If this feature is enabled, the system will not scan for an external graphics card on PEG and PCIe slots. The options are **Disabled** and Enabled.

Primary Display

Use this feature to select the primary video display. The options are Auto and **IGFX**.

Internal Graphics

Select Auto to keep an internal graphics device installed on an expansion slot supported by the CPU to be automatically enabled. The options are Auto, Disabled, and **Enabled**.

DVMT Pre-Allocated

Dynamic Video Memory Technology (DVMT) allows dynamic allocation of system memory to be used for video devices to ensure best use of available system memory based on the DVMT 5.0 platform. The options are 0M, 32M, 64M, 96M, **128M**, 4M, 8M, 12M, 16M, 20M, 24M, 28M, 32M/F7, 36M, 40M, 44M, 48M, 52M, 56M, and 60M.

Configure GT for use

Use this feature to enable or disable GT configuration. The options are Disabled and **Enabled**.

PAVP Enable

Use this feature to enable or disable PAVP support. The options are Disabled and **Enabled**.

DMI Configuration Menu

▶ **DMI Configuration**

This submenu allows you to configure the DMI configuration settings.

DMI ASPM

Use this feature to set the Active State Power Management (ASPM) state on the System Agent (SA) side of the DMI Link. The options are Disabled, ASPM L1, and **Auto**.

PEG Port Configuration

▶ **PEG Port Configuration**

CPU SLOT7 PCIe 5.0 x16

Enable Root Port

Use this feature to enable or disable the PCIe Graphics (PEG) device in the specified port . The options are Disabled and **Enabled**.

Max Link Speed

Use this feature to select PCIe support for the device installed the M.2 specified port. The options are **Auto**, Gen1, Gen2, Gen3, Gen4, and Gen5.

M.2-C PCIe 5.0 x4

Enable Root Port

Use this feature to enable or disable the PCIe Graphics (PEG) device in the specified port . The options are Disabled and **Enabled**.

Max Link Speed

Use this feature to select PCIe support for the device installed the M.2 specified port. The options are **Auto**, Gen1, Gen2, Gen3, Gen4, and Gen5.

GT - Power Management Control

GT - Power Management Control

RC6 (Render Standby)

Use this feature to enable render standby support. The options are Disabled and **Enabled**.

Maximum GT Frequency

Use this feature to define the Maximum GT frequency. Choose between 1650 MHz (RPN) and 6000 MHz (RP0). Any value beyond this range will be clipped to its min/max supported by the

CPU. The options are **Default Max Frequency**, 100Mhz, 150Mhz, 200Mhz, 250Mhz, 300Mhz, 350Mhz, 400Mhz, 450Mhz, 500Mhz, 550Mhz, 600Mhz, 650Mhz, 700Mhz, 750Mhz, 800Mhz, 850Mhz, 900Mhz, 950Mhz, 100Mhz, 1050Mhz, 1100Mhz, 1150Mhz, and 1200Mhz.

Disable Turbo GT Frequency

Use this feature to disable Turbo GT frequency. If set to Enabled, Turbo GT frequency becomes disabled. If set to Disabled, GT frequency limiters will be removed. The options are Enabled and **Disabled**.

PCH-IO Configuration

PCH SKU

Stepping

PCI Express Configuration

PCI Express Configuration

Onboard LAN1

ASPM

Use this feature to activate the Active State Power Management (ASPM) level for a PCIe device. Select Auto for the system BIOS to automatically set the ASPM level based on the system configuration. Select Disabled to disable ASPM support. The options are Disabled, **L1**, and Auto.

L1 Substates

Use this feature to set the PCI Express L1 Substate. The options are Disabled, L1.1 and **L1.1 & L1.2**.

PCIe Speed

Use this feature to set the PCI Express port speed. The options are **Auto**, Gen1, Gen2, Gen3, and Gen4.

Peer Memory Write Enable

Use this feature to enable or disable Peer Memory Write. The options are **Disabled** and Enabled.

Onboard LAN2

ASPM

Use this feature to activate the Active State Power Management (ASPM) level for a PCIe device. Select Auto for the system BIOS to automatically set the ASPM level based on the system configuration. Select Disabled to disable ASPM support. The options are Disabled, **L1**,

and Auto.

L1 Substates

Use this feature to set the PCI Express L1 Substate. The options are Disabled, L1.1 and **L1.1 & L1.2**.

PCIe Speed

Use this feature to set the PCI Express port speed. The options are **Auto**, Gen1, Gen2, Gen3, and Gen4.

Peer Memory Write Enable

Use this feature to enable or disable Peer Memory Write. The options are **Disabled** and Enabled.

MCIO-1

ASPM

Use this feature to activate the Active State Power Management (ASPM) level for a PCIe device. Select Auto for the system BIOS to automatically set the ASPM level based on the system configuration. Select Disabled to disable ASPM support. The options are Disabled, **L1**, and Auto.

L1 Substates

Use this feature to set the PCI Express L1 Substate. The options are Disabled, L1.1 and **L1.1 & L1.2**.

PCIe Speed

Use this feature to set the PCI Express port speed. The options are **Auto**, Gen1, Gen2, Gen3, and Gen4.

Peer Memory Write Enable

Use this feature to enable or disable Peer Memory Write. The options are **Disabled** and Enabled.

MCIO-2

ASPM

Use this feature to activate the Active State Power Management (ASPM) level for a PCIe device. Select Auto for the system BIOS to automatically set the ASPM level based on the system configuration. Select Disabled to disable ASPM support. The options are Disabled, **L1**, and Auto.

L1 Substates

Use this feature to set the PCI Express L1 Substate. The options are Disabled, L1.1 and **L1.1 & L1.2**.

PCIe Speed

Use this feature to set the PCI Express port speed. The options are **Auto**, Gen1, Gen2, Gen3, and Gen4.

Peer Memory Write Enable

Use this feature to enable or disable Peer Memory Write. The options are **Disabled** and Enabled.

M.2-H

ASPM

Use this feature to activate the Active State Power Management (ASPM) level for a PCIe device. Select Auto for the system BIOS to automatically set the ASPM level based on the system configuration. Select Disabled to disable ASPM support. The options are Disabled, **L1**, and Auto.

L1 Substates

Use this feature to set the PCI Express L1 Substate. The options are Disabled, L1.1 and **L1.1 & L1.2**.

PCIe Speed

Use this feature to set the PCI Express port speed. The options are **Auto**, Gen1, Gen2, Gen3, and Gen4.

Peer Memory Write Enable

Use this feature to enable or disable Peer Memory Write. The options are **Disabled** and Enabled.

HTTP Boot Configuration Menu

► HTTP Boot Configuration

HTTP Boot Policy

Use this feature to set the HTTP boot policy. The options are Apply to all LANs, **Apply to each LAN**, and Boot Priority #1 instantly.

HTTPS Boot Checks Hostname

Important: Disabling "HTTPS Boot Checks Hostname" is a violation of RFC 6125 and may expose you to Man-in-the-Middle Attacks. Supermicro is not responsible for any and all security risks incurred by you disabling this feature.

Enable this feature for HTTPS boot to check the hostname of the TLS certificates to see if it matches the host name provided by the remote server. The options are **Enabled** and Disabled (WARNING: Security Risk!!).

Priority of HTTP Boot

Instance of Priority 1: (Available when your motherboard supports this feature)

This feature sets the rank target port. The default setting is **1**.

Select IPv4 or IPv6

This feature specifies which connection the target LAN port should boot from. The options are **IPv4** and IPv6.

Boot Description

Use this feature to enter a boot description, which cannot be longer than 75 characters. Be sure to enter a boot description; otherwise, the boot option for the URI cannot be created.

Boot URI

Enter a Boot Uniform Research Identifier (URI) with 128 characters or shorter. This Boot URI determines how IPv4 Boot Option and IPv6 Boot Option will be created.

Instance of Priority 2: (Available when your motherboard supports this feature)

This feature sets the rank target port. The default setting is **0**.

Instance of Priority 3: (Available when "HTTP Boot Policy" is set to Apply to each LAN or Boot Priority #1 instantly)

This feature sets the rank target port. The default setting is **0**.

Super IO Configuration Menu

► Super IO Configuration

The following information is displayed.

- Super IO Chip

Note: This submenu is available when your system supports this feature.

Serial Port 1 Configuration Menu

► Serial Port 1 Configuration

Serial Port 1

Select Enabled to enable serial port 1. The options are Disabled and **Enabled**.

Device Settings (Available when "Serial Port 1" above is set to Enabled)

This feature displays the base I/O port address and the Interrupt Request address of serial port 1.

Change Settings (Available when "Serial Port 1" above is set to Enabled)

Use this feature to specify the base I/O port address and the Interrupt Request address of serial port 1. Select Auto for the BIOS to automatically assign the base I/O and IRQ address to serial port 1. The options are **Auto**, (IO=3F8h; IRQ=4;), (IO=2F8h; IRQ=4;), (IO=3E8h; IRQ=4;), and (IO=2E8h; IRQ=4;).

Serial Port 2 Configuration Menu

► Serial Port 2 Configuration

Serial Port 2

Select Enabled to enable serial port 2. The options are Disabled and **Enabled**.

Device Settings (Available when "Serial Port 2" above is set to Enabled)

This feature displays the base I/O port address and the Interrupt Request address of serial port 2.

Change Settings (Available when "Serial Port 2" above is set to Enabled)

Use this feature to specify the base I/O port address and the Interrupt Request address of serial port 2 (or SOL). Select Auto for the BIOS to automatically assign the base I/O and IRQ address to serial port 2 (or SOL). The options are **Auto**, (IO=2F8h; IRQ=3;), (IO=3F8h; IRQ=3;), (IO=3E8h; IRQ=3;), and (IO=2E8h; IRQ=3;).

Network Stack Configuration Menu

► Network Stack Configuration

Network Stack

Select Enabled to enable Preboot Execution Environment (PXE) or Unified Extensible Firmware Interface (UEFI) for network stack support. The options are Disabled and **Enabled**.

IPv4 PXE Support (Available when "Network Stack" is set to Enabled)

Select Enabled to enable IPv4 PXE boot support. If this feature is disabled, it will not create the IPv4 PXE boot option. The options are Disabled and **Enabled**.

IPv4 HTTP Support (Available when "Network Stack" is set to Enabled)

Select Enabled to enable IPv4 HTTP boot support. If this feature is disabled, it will not create the IPv4 HTTP boot option. The options are **Disabled** and Enabled.

IPv6 PXE Support (Available when "Network Stack" is set to Enabled)

Select Enabled to enable IPv6 PXE boot support. If this feature is disabled, it will not create the IPv6 PXE boot option. The options are Disabled and **Enabled**.

IPv6 HTTP Support (Available when "Network Stack" is set to Enabled)

Select Enabled to enable IPv6 HTTP boot support. If this feature is disabled, it will not create the IPv6 HTTP boot option. The options are **Disabled** and Enabled.

PXE Boot Wait Time (Available when "Network Stack" is set to Enabled)

Use this feature to set the wait time (in seconds) upon which the system BIOS will wait for you to press the <ESC> key to abort PXE boot instead of proceeding with PXE boot by connecting to a network server immediately. Press the <+> or <-> key on your keyboard to change the value. The default setting is **0**.

Media Detect Count (Available when "Network Stack" is set to Enabled)

Use this feature to set the wait time (in seconds) for the BIOS ROM to detect the presence of a LAN media either via the Internet connection or via a LAN port. Press the <+> or <-> key on your keyboard to change the value. The default setting is **1**.

MAC:(MAC address)-IPv4 Network Configuration Menu**▶ MAC:(MAC address)-IPv4 Network Configuration****Configured**

Enable this feature to configure network addresses for DHCP, local IP address, local netmask, local gateway, and local DNS server. The options are **Disabled** and Enabled.

Enable DHCP (Available when "Configured" is set to Enabled)

Select Enabled to support Dynamic Host Configuration Protocol (DHCP), which allows the BIOS to search for a DHCP server attached to the network and request the next available IP address for this computer. The options are **Disabled** and Enabled.

Local IP Address (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to enter an IP address for the local machine.

Local NetMask (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the netmask for the local machine.

Local Gateway (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the gateway address for the local machine.

Local DNS Servers (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the Domain Name System (DNS) server address for the local machine.

Save Changes and Exit

Press <Enter> to save changes and exit.

MAC:(MAC address)-IPv6 Network Configuration Menu**▶ MAC:(MAC address)-IPv6 Network Configuration****▶ Enter Configuration Menu**

The following information is displayed.

- Interface Name
- Interface Type
- MAC address
- Host address
- Route Table
- Gateway addresses
- DNS addresses

Interface ID

Use this feature to change/enter the 64-bit alternative interface ID for the device. The string format is colon separated. The default setting is the MAC address above.

DAD Transmit Count

Use this feature to set the number of consecutive neighbor solicitation messages that have been sent while performing duplicate address detection on a tentative address. The default setting is **1**.

Policy

Use this feature to select how the policy is to be configured. The options are **automatic** and **manual**.

► Advanced Configuration

Note: This submenu is available when "Policy" is set to manual.

New IPv6 address: Use this feature to enter the IPv6 address for the local machine.

New Gateway addresses: Use this feature to set the gateway address for the local machine.

New DNS addresses: Use this feature to set the DNS server address for the local machine.

Commit Changes and Exit: Press <Enter> to save changes and exit.

Discard Changes and Exit: Press <Enter> to discard changes and exit.

Save Changes and Exit

Press <Enter> to save changes and exit.

MAC:(MAC address)-IPv4 Network Configuration Menu

► MAC:(MAC address)-IPv4 Network Configuration

Configured

Enable this feature to configure network addresses for DHCP, local IP address, local netmask, local gateway, and local DNS server. The options are **Disabled** and **Enabled**.

Enable DHCP (Available when "Configured" is set to Enabled)

Select **Enabled** to support Dynamic Host Configuration Protocol (DHCP), which allows the BIOS to search for a DHCP server attached to the network and request the next available IP address for this computer. The options are **Disabled** and **Enabled**.

Local IP Address (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to enter an IP address for the local machine.

Local NetMask (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the netmask for the local machine.

Local Gateway (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the gateway address for the local machine.

Local DNS Servers (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the Domain Name System (DNS) server address for the local machine.

Save Changes and Exit

Press <Enter> to save changes and exit.

MAC:(MAC address)-IPv6 Network Configuration Menu**▶ MAC:(MAC address)-IPv6 Network Configuration****▶ Enter Configuration Menu**

The following information is displayed.

- Interface Name
- Interface Type
- MAC address
- Host address
- Route Table
- Gateway addresses
- DNS addresses

Interface ID

Use this feature to change/enter the 64-bit alternative interface ID for the device. The string format is colon separated. The default setting is the MAC address above.

DAD Transmit Count

Use this feature to set the number of consecutive neighbor solicitation messages that have been sent while performing duplicate address detection on a tentative address. The default setting is **1**.

Policy

Use this feature to select how the policy is to be configured. The options are **automatic** and **manual**.

▶ Advanced Configuration

Note: This submenu is available when "Policy" is set to manual.

New IPv6 address: Use this feature to enter the IPv6 address for the local machine.

New Gateway addresses: Use this feature to set the gateway address for the local machine.

New DNS addresses: Use this feature to set the DNS server address for the local machine.

Commit Changes and Exit: Press <Enter> to save changes and exit.

Discard Changes and Exit: Press <Enter> to discard changes and exit.

Save Changes and Exit

Press <Enter> to save changes and exit.

MAC:(MAC address)-IPv4 Network Configuration Menu

► MAC:(MAC address)-IPv4 Network Configuration

Configured

Enable this feature to configure network addresses for DHCP, local IP address, local netmask, local gateway, and local DNS server. The options are **Disabled** and **Enabled**.

Enable DHCP (Available when "Configured" is set to Enabled)

Select **Enabled** to support Dynamic Host Configuration Protocol (DHCP), which allows the BIOS to search for a DHCP server attached to the network and request the next available IP address for this computer. The options are **Disabled** and **Enabled**.

Local IP Address (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to enter an IP address for the local machine.

Local NetMask (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the netmask for the local machine.

Local Gateway (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the gateway address for the local machine.

Local DNS Servers (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the Domain Name System (DNS) server address for the local machine.

Save Changes and Exit

Press <Enter> to save changes and exit.

MAC:(MAC address)-IPv6 Network Configuration Menu

▶ **MAC:(MAC address)-IPv6 Network Configuration**

▶ **Enter Configuration Menu**

The following information is displayed.

- Interface Name
- Interface Type
- MAC address
- Host address
- Route Table
- Gateway addresses
- DNS addresses

Interface ID

Use this feature to change/enter the 64-bit alternative interface ID for the device. The string format is colon separated. The default setting is the MAC address above.

DAD Transmit Count

Use this feature to set the number of consecutive neighbor solicitation messages that have been sent while performing duplicate address detection on a tentative address. The default setting is **1**.

Policy

Use this feature to select how the policy is to be configured. The options are **automatic** and manual.

▶ **Advanced Configuration**

Note: This submenu is available when "Policy" is set to manual.

New IPv6 address: Use this feature to enter the IPv6 address for the local machine.

New Gateway addresses: Use this feature to set the gateway address for the local machine.

New DNS addresses: Use this feature to set the DNS server address for the local machine.

Commit Changes and Exit: Press <Enter> to save changes and exit.

Discard Changes and Exit: Press <Enter> to discard changes and exit.

Save Changes and Exit

Press <Enter> to save changes and exit.

MAC:(MAC address)-IPv4 Network Configuration Menu

► MAC:(MAC address)-IPv4 Network Configuration

Configured

Enable this feature to configure network addresses for DHCP, local IP address, local netmask, local gateway, and local DNS server. The options are **Disabled** and **Enabled**.

Enable DHCP (Available when "Configured" is set to Enabled)

Select **Enabled** to support Dynamic Host Configuration Protocol (DHCP), which allows the BIOS to search for a DHCP server attached to the network and request the next available IP address for this computer. The options are **Disabled** and **Enabled**.

Local IP Address (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to enter an IP address for the local machine.

Local NetMask (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the netmask for the local machine.

Local Gateway (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the gateway address for the local machine.

Local DNS Servers (Available when "Configured" is set to Enabled and "Enable DHCP" is set to Disabled)

Use this feature to set the Domain Name System (DNS) server address for the local machine.

Save Changes and Exit

Press <Enter> to save changes and exit.

MAC:(MAC address)-IPv6 Network Configuration Menu

▶ MAC:(MAC address)-IPv6 Network Configuration

▶ Enter Configuration Menu

The following information is displayed.

- Interface Name
- Interface Type
- MAC address
- Host address
- Route Table
- Gateway addresses
- DNS addresses

Interface ID

Use this feature to change/enter the 64-bit alternative interface ID for the device. The string format is colon separated. The default setting is the MAC address above.

DAD Transmit Count

Use this feature to set the number of consecutive neighbor solicitation messages that have been sent while performing duplicate address detection on a tentative address. The default setting is **1**.

Policy

Use this feature to select how the policy is to be configured. The options are **automatic** and **manual**.

▶ Advanced Configuration

Note: This submenu is available when "Policy" is set to manual.

New IPv6 address: Use this feature to enter the IPv6 address for the local machine.

New Gateway addresses: Use this feature to set the gateway address for the local machine.

New DNS addresses: Use this feature to set the DNS server address for the local machine.

Commit Changes and Exit: Press <Enter> to save changes and exit.

Discard Changes and Exit: Press <Enter> to discard changes and exit.

Save Changes and Exit

Press <Enter> to save changes and exit.

PCH-FW Configuration

ME Firmware Version: 19.0.0.1797

ME Firmware Mode: Normal Mode

ME Firmware SKU: Corporate SKU

ME FW Image Re-Flash

Use this feature to update the Management Engine firmware. The options are **Disabled** and Enabled.

TPM Device Selection

Use this feature to select dTPM or PTT for the TPM device. dTPM is discrete Trusted Platform Module and PTT is Platform Trusted Technology. The options are **dTPM** and PTT.

AMT Configuration

USB Provisioning of AMT

Use this feature to enable or disable USB provisioning. The options are **Disabled** and Enabled.

MAC Pass Through

Use this feature to enable or disable the MAC Pass Through function. The options are **Disabled** and Enabled.

Activate Remote Assistance Process

Use this feature to activate Remote Assistance. Enabling this feature will also trigger the Client Initiated Remote Access (CIRA) boot. The options are **Disabled** and Enabled.

Unconfigure ME

Use this feature to unconfigure ME with resetting the MEBx password to default on next boot. The options are **Disabled** and Enabled.

ASF Configuration

PET Progress

Use this feature to enable or disable PET Events Progress to receive PET Events alerts. The options are Disabled and **Enabled**.

WatchDog

Select Enabled to allow the Watchdog timer to reboot the system when it is inactive for more than five minutes. The options are **Disabled** and Enabled.

OS Timer / BIOS Timer

These options appear if WatchDog (above) is enabled. This is a timed delay in seconds, before a system power down or reset after a BIOS or operating system failure is detected. Enter the value in seconds. The default setting is **0**.

ASF Sensors Table

Enable this feature for the ASF Sensor Table to be added into the ASF ACPI table. The options are **Disabled** and Enabled.

Secure Erase Configuration

Secure Erase mode

Select Real to securely erase a solid state drive. The options are **Simulated** and Real.

Force Secure Erase

Select Enabled to force a secure erase of the solid state drive on the next boot. The options are **Disabled** and Enabled.

One Click Recovery (OCR) Configuration

OCR Https Boot

Use this feature to enable or disable One Click Recovery Https Boot. One Click Recovery is a recovery process that lets you restore your computer to its last known good state with a single command. The options are Disabled and **Enabled**.

OCR PBA Boot

Use this feature to enable or disable One Click Recovery PBA Boot. The options are Disabled and **Enabled**.

OCR Windows Recovery Boot

Use this feature to enable or disable One Click Recovery Windows Boot. The options are Disabled and **Enabled**.

OCR Disable Secure Boot

Use this feature to allow CSME to request Secure Boot to be disabled for One Click Recovery. The options are Disabled and **Enabled**.

PCIe/PCI/PnP Configuration Menu

PCI PERR/SERR Support

Use this feature to enable or disable the runtime event for PCI errors. The options are **Disabled** and **Enabled**.

Re-Size BAR Support

Use this feature to enable Resizable Base Address Register (BAR) support. Resizable BAR is a PCIe interface technology that allows the CPU to access the entire frame buffer. With this technology, your system will be able to handle multiple CPU to GPU transfers simultaneously rather than queuing, which can improve the frame rate performance. The options are **Disabled** and **Enabled**.

SR-IOV Support (Unavailable when "Workload Profile" is set to Virtualization)

Select **Enabled** for Single-Root IO Virtualization support. The options are **Disabled** and **Enabled**.

BME DMA Mitigation

Enable this feature to help block DMA attacks. The options are **Disabled** and **Enabled**.

Onboard Video Option ROM

Select **EFI** to boot the computer using the Extensible Firmware Interface (EFI) device installed on the onboard video port. The options are **Disabled** and **EFI**.

NVMe Firmware Source

Use this feature to select the NVMe firmware to support system boot. The options are **Vendor Defined Firmware** and **AMI Native Support**. The option of Vendor Defined Firmware is pre-installed on the drive and may resolve errata or enable innovative functions for the drive. The default option, AMI Native Support, is offered by the BIOS with a generic method.

Consistent Device Name Support

This feature controls the device naming for network devices and slots. The options are **Disabled** and **Enabled**.

PCIe/PCI/PnP Configuration

M.2-C PCIe 5.0 x4 OPROM

Use this feature to select which firmware type to be loaded for the add-on card in this slot. The options are **Disabled** and **EFI**.

CPU SLOT7 PCIe 5.0 x16 OPROM

Use this feature to select which firmware type to be loaded for the add-on card in this slot. The options are **Disabled** and **EFI**.

MCIO-1 OPROM

Use this feature to select which firmware type to be loaded for the add-on card in this slot. The options are Disabled and **EFI**.

MCIO-2 OPROM

Use this feature to select which firmware type to be loaded for the add-on card in this slot. The options are Disabled and **EFI**.

M.2-H OPROM

Use this feature to select which firmware type to be loaded for the add-on card in this slot. The options are Disabled and **EFI**.

Onboard LAN1 Support

Use this feature to enable or disable LAN1. The options are Disabled and **Enabled**.

Onboard LAN2 Support

Use this feature to enable or disable LAN2. The options are Disabled and **Enabled**.

Onboard LAN1 Option ROM

Select EFI to boot the computer using the EFI device installed on LAN port 1. The options are Disabled and **EFI**.

Note: This feature is available when your motherboard supports onboard LAN ports.

SATA and RST Configuration

SATA And RST Configuration**SATA Controller(s)**

Use this feature to enable or disable the onboard SATA controller supported by the Intel PCH chip. The options are **Enabled** and Disabled.

Support Aggressive Link Power Management

When this feature is set to Enabled, the SATA AHCI controller manages the power usage of the SATA link. The controller will put the link in a low power mode during extended periods of I/O inactivity and will return the link to an active state when I/O activity resumes. The options are Disabled and **Enabled**.

I-SATA5 / I-SATA6 / I-SATA7

This feature displays the information detected on the installed SATA drive on the particular SATA port.

Software Preserve Support

Hot Plug

Set this feature to Enable for hot plug support, which allows you to replace a SATA drive without shutting down the system. The options are Disabled and **Enabled**.

Spin Up Device

Set this feature to enable or disable the PCH to initialize the device. The options are **Disabled** and Enabled.

SATA Device Type

Use this feature to specify if the SATA port is connected to a Solid State Drive or a Hard Disk Drive. The options are **Hard Disk Drive** and Solid State Drive.

VMD Setup Menu

► VMD Setup Menu

VMD Configuration

Enable VMD Controller

Use this feature to enable or disable the VMD controller. The options are **Disabled** and Enabled.

Enable VMD Global Mapping (Available when Enable VMD Controller is set to "Enabled")

Use this feature to enable or disable VMD global mapping. The options are **Disabled** and Enabled.

Map PCH SATA Controller under VMD (Available when Enable VMD Controller is set to "Enabled")

Use this feature to map or unmap the selected root port to VMD. The options are **Disabled** and Enabled.

Serial Port Console Redirection Menu

► Serial Port Console Redirection

COM1

Console Redirection

Select Enabled to enable COM port 1 for Console Redirection, which allows a client machine to be connected to a host machine at a remote site for networking. The options are **Disabled** and Enabled.

Note: This feature will be set to Enabled if there is no BMC support.

SOL

Note: This feature is available when your system supports serial port of SOL.

Console Redirection

Select Enabled to use the SOL port for Console Redirection. The options are Disabled and Enabled.

AMT SOL

COM3 Console Redirection

Select Enabled to enable console redirection support for the specified serial port. The options are **Disabled** and Enabled.

► Console Redirection Settings

Note: This submenu is available when "Console Redirection" for COM1, SOL/COM2, or AMT SOL is set to Enabled.

Terminal Type

Use this feature to select the target terminal emulation type for Console Redirection. Select VT100 to use the ASCII character set. Select VT100+ to add color and function key support. Select ANSI to use the extended ASCII character set. Select VT-UTF8 to use UTF8 encoding to map Unicode characters into one or more bytes. The options are VT100, **VT100+**, VT-UTF8, and ANSI.

Bits Per Second

Use this feature to set the transmission speed for a serial port used in Console Redirection. Make sure that the same speed is used in the host computer and the client computer. A lower transmission speed may be required for long and busy lines. The options are 9600, 19200, 38400, 57600, and **115200** (bits per second).

Data Bits

Use this feature to set the data transmission size for Console Redirection. The options are 7 and **8** (bits).

Parity

A parity bit can be sent along with regular data bits to detect data transmission errors. Select Even if the parity bit is set to 0 and the number of 1s in data bits is even. Select Odd if the parity bit is set to 0 and the number of 1s in data bits is odd. Select None if you do not want to

send a parity bit with your data bits in transmission. Select Mark to add a mark as a parity bit to be sent along with the data bits. Select Space to add a space as a parity bit to be sent with your data bits. The options are **None**, Even, Odd, Mark, and Space.

Stop Bits

A stop bit indicates the end of a serial data packet. Select 1 (stop bit) for standard serial data communication. Select 2 (stop bits) if slower devices are used. The options are **1** and **2**.

Flow Control

Use this feature to set the flow control for Console Redirection to prevent data loss caused by buffer overflow. Send a "Stop" signal to stop sending data when the receiving buffer is full. Send a "Start" signal to start sending data when the receiving buffer is empty. The options are **None** and Hardware RTS/CTS.

VT-UTF8 Combo Key Support

Select Enabled to enable VT-UTF8 Combination Key support for ANSI/VT100 terminals. The options are Disabled and **Enabled**.

Recorder Mode

Select Enabled to capture the data displayed on a terminal and send it as text messages to a remote server. The options are **Disabled** and Enabled.

Resolution 100x31

Select Enabled for extended-terminal resolution support. The options are Disabled and **Enabled**.

Putty KeyPad

Use this feature to select the function key and keypad settings on Putty, which is a terminal emulator designed for the Windows OS. The options are **VT100**, LINUX, XTERMR6, SCO, ESCN, and VT400.

Redirection After BIOS POST

Use this feature to enable or disable legacy console redirection after BIOS POST. When set to Bootloader, legacy console redirection is disabled before booting the OS. When set to Always Enable, legacy console redirection remains enabled when booting the OS. The options are **Always Enable** and Bootloader.

Serial Port for Out-of-Band Management/Windows Emergency Management Services (EMS)

Use the features below to configure Console Redirection settings to support Out-of-Band Serial Port management.

Console Redirection EMS

Select Enabled to use the SOL port for Console Redirection. The options are **Disabled** and Enabled.

► Console Redirection Settings

Note: This submenu is available when "Console Redirection EMS" is set to Enabled.

Out-of-Band Mgmt Port

Use this feature to select a serial port in a client server to be used by the Microsoft Windows Emergency Management Services (EMS) to communicate with a remote host server. The options are **COM1** and SOL/COM2. Note that the option of SOL/COM2 indicates a shared serial port. SOL is available with BMC support.

Terminal Type EMS

Use this feature to select the target terminal emulation type for Console Redirection. Select VT100 to use the ASCII character set. Select VT100+ to add color and function key support. Select ANSI to use the extended ASCII character set. Select VT-UTF8 to use UTF8 encoding to map Unicode characters into one or more bytes. The options are VT100, VT100+, **VT-UTF8**, and ANSI.

Bits Per Second EMS

This feature sets the transmission speed for a serial port used in Console Redirection. Make sure that the same speed is used in the host computer and the client computer. A lower transmission speed may be required for long and busy lines. The options are 9600, 19200, 57600, and **115200** (bits per second).

Flow Control EMS

Use this feature to set the flow control for Console Redirection to prevent data loss caused by buffer overflow. Send a "Stop" signal to stop sending data when the receiving buffer is full. Send a "Start" signal to start sending data when the receiving buffer is empty. The options are **None**, Hardware RTS/CTS, and Software Xon/Xoff.

The following information is displayed.

- **Data Bits EMS**
- **Parity EMS**
- **Stop Bits EMS**

Trusted Computing Menu

► Trusted Computing

When the TPM 2.0 (either onboard or external) is detected by your system, the following information is displayed.

- TPM 2.0 Device Found
- Firmware Version:
- Vendor:

Note: This submenu is available when the TPM 2.0 (either onboard or external) is detected by the BIOS.

Security Device Support

Select Enabled to enable BIOS support for onboard security devices, which are not displayed in the OS. If this feature is set to Enabled, TCG EFI protocol and INT1A interface will not be available. The options are Disabled and **Enabled**.

When "Security Device Support" is set to Enabled and the TPM 2.0 (either onboard or external) is detected by the BIOS, the following information is displayed.

- Active PCR banks
- Available PCR banks

Note: The following features are available when the TPM 2.0 (either onboard or external) is detected by the BIOS.

SHA256 PCR Bank (Available when "Security Device Support" is set to Enabled)

Select Enabled to enable SHA256 PCR Bank support to enhance system integrity and data security. The options are Disabled and **Enabled**.

SHA384 PCR Bank (Available when "Security Device Support" is set to Enabled)

Select Enabled to enable SHA384 PCR Bank support to enhance system integrity and data security. The options are **Disabled** and Enabled.

Pending Operation (Available when "Security Device Support" is set to Enabled)

Use this feature to schedule a TPM-related operation to be performed by the security TPM (either onboard or external) at the next system boot to enhance system data integrity. The options are **None** and TPM Clear.

Note: If this feature is used, your system will reboot to carry out a pending TPM operation.

Platform Hierarchy (Available when "Security Device Support" is set to Enabled)

Select Enabled for TPM Platform Hierarchy support, which allows the manufacturer to utilize the cryptographic algorithm to define a constant key or a fixed set of keys to be used for initial system boot. These early boot codes are shipped with the platform and are included in the list of "public keys." During system boot, the platform firmware uses the trusted public keys to verify a digital signature in an attempt to manage and control the security of the platform firmware used in a host system via the TPM (either onboard or external). The options are Disabled and **Enabled**.

Storage Hierarchy (Available when "Security Device Support" is set to Enabled)

Select Enabled for TPM Storage Hierarchy support that is intended to be used for non-privacy-sensitive operations by a platform owner such as an IT professional or the end user. Storage Hierarchy has an owner policy and an authorization value, both of which can be set and are held constant (-rarely changed) through reboots. This hierarchy can be cleared or changed independently of the other hierarchies. The options are Disabled and **Enabled**.

TPM 2.0 InterfaceType

This feature displays the TPM interface type. The default option is **TIS**.

Endorsement Hierarchy (Available when "Security Device Support" is set to Enabled)

Select Enabled for Endorsement Hierarchy support, which contains separate controls to address the user's privacy concerns because the primary keys in the hierarchy are certified by the TPM key or by a manufacturer with restrictions on how an authentic TPM (either onboard or external) that is attached to an authentic platform can be accessed and used. A primary key can be encrypted and certified with a certificate created by using TPM2_ActivateCredential, which allows the user to independently enable "flag, policy, and authorization values" without involving other hierarchies. A user with privacy concerns can disable the endorsement hierarchy while still using the storage hierarchy for TPM applications, permitting the platform software to use the TPM. The options are Disabled and **Enabled**.

PH Randomization

Select Enabled for Platform Hierarchy (PH) Randomization support, which is used only during the platform developmental stage. This feature cannot be enabled in the production platforms. The options are **Disabled** and Enabled.

Intel Trusted Execution Technology

Intel Trusted Execution Technology (TXT) helps protect against software-based attacks and ensures protection, confidentiality, and integrity of data stored or created on the system. Use this feature to enable or disable TXT Support. The options are **Disabled** and Enabled.

USB Configuration Menu

► USB Configuration

USB Module Version

USB Controllers

USB Devices

XHCI Hand-off

This is a work-around solution for operating systems that do not support Extensible Host Controller Interface (XHCI) hand-off. The XHCI ownership change should be claimed by the XHCI driver. The settings are **Enabled** and Disabled.

USB Mass Storage Driver Support

Select Enabled for USB mass storage device support. The options are Disabled and **Enabled**.

USB S5 Wakeup Support

Use this feature to enable or disable USB S5 Wakeup support. The options are Disabled and **Enabled**.

Intel Ethernet Controller I226-LM

UEFI Driver

Device Name

Link Status

MAC Address

Intel Ethernet Controller I226-LM

UEFI Driver

Device Name

Link Status

MAC Address

Intel Ethernet Controller X550

Blink LEDs

Use this feature to identify the physical network port by blinking the associated LED. The default setting is **0** (up to 15 seconds).

UEFI Driver

Adapter PBA

Device Name

Chip Type

PCI Device ID

PCI Address

Link Status

MAC Address

Virtual MAC Address

Firmware Image Properties

The following firmware image information is displayed.

- Option ROM version
- Unique NVM/EEPROM ID
- NVM Version

NIC Configuration

Link Speed

The feature displays the connection speed of a LAN port. The options are **Auto Negotiated**, 10 Mbps Half, 10 Mbps Full, 100 Mbps Half, and 100 Mbps Full.

Wake On LAN

If this feature is set to Enabled, the LAN port you specified will be enabled when the system is powered on. The options are Disabled and **Enabled**.

Intel Ethernet Controller X550

Blink LEDs

Use this feature to identify the physical network port by blinking the associated LED. The default setting is **0** (up to 15 seconds).

UEFI Driver

Adapter PBA

Device Name

Chip Type

PCI Device ID

PCI Address

Link Status

MAC Address

Virtual MAC Address

Firmware Image Properties

The following firmware image information is displayed.

- Option ROM version
- Unique NVM/EEPROM ID
- NVM Version

NIC Configuration

Link Speed

The feature displays the connection speed of a LAN port. The options are **Auto Negotiated**, 10 Mbps Half, 10 Mbps Full, 100 Mbps Half, and 100 Mbps Full.

Wake On LAN

If this feature is set to Enabled, the LAN port you specified will be enabled when the system is powered on. The options are Disabled and **Enabled**.

TLS Authenticate Configuration Menu

► TLS Authenticate Configuration

Use this submenu to configure Transport Layer Security (TLS) settings.

► Server CA Configuration

Use this feature to configure the server Certificate Authority (CA).

► Enroll Certification

Use this feature to enroll the certificates in the system.

► Enroll Certification Using File

Use this feature to enroll the security certificates in the system by using a file.

▶ **Commit Changes and Exit**

Use this feature to save all changes and exit TLS settings.

▶ **Discard Changes and Exit**

Use this feature to discard all changes and exit TLS settings.

▶ **Delete Certification**

Use this feature to delete the certificates that have been enrolled in the system.

▶ **Client Certification Configuration**

This feature is to manage the certificates used to authenticate remote clients connecting to your system. Add, view, or delete client certificates as needed.

Driver Health Menu

▶ **Driver Health**

This feature displays the health information of the drivers installed in your system, including LAN controllers, as detected by the BIOS. Select one and press <Enter> to see the details.

Note: This section is provided for reference only. The driver health status will differ depending on the drivers installed in your system. It's also based on your system configuration and the environment that your system is operating in.

8.4 Event Logs

Use this menu to configure Event Logs settings.

Note: After making any changes in this section, be sure to reboot the system for the changes to take effect.



Figure 8-3. Event Logs Screen

► Change SMBIOS Event Log Settings

Note: Reboot the system for the changes in this section to take effect.

Enabling/Disabling Options

SMBIOS Event Log

Select Enabled to enable System Management BIOS (SMBIOS) Event Logging during system boot. The options are Disabled and **Enabled**.

Erasing Settings

Erase Event Log (Available when "SMBIOS Event Log" is set to Enabled)

Select No to keep the event log without erasing it upon next system bootup. Select (Yes, Next reset) to erase the event log upon next system reboot. The options are **No**, (Yes, Next reset), and (Yes, Every reset).

When Log is Full (Available when "SMBIOS Event Log" is set to Enabled)

Select Erase Immediately to immediately erase all errors in the SMBIOS event log when the event log is full. Select Do Nothing for the system to do nothing when the SMBIOS event log is full. The options are **Do Nothing** and Erase Immediately.

SMBIOS Event Log Standard Settings

Log System Boot Event (Available when "SMBIOS Event Log" is set to Enabled)

Select Enabled to log system boot events. The options are Enabled and **Disabled**.

MECI (Available when "SMBIOS Event Log" is set to Enabled)

Enter the increment value for the multiple event counter. Enter a number between 1 and 255. The default setting is **1**. (MECI is the abbreviation for Multiple Event Count Increment.)

METW (Available when "SMBIOS Event Log" is set to Enabled)

Use this feature to determine how long (in minutes) should the multiple event counter wait before generating a new event log. Enter a number between 0 and 99. The default value is **60**. (METW is the abbreviation for Multiple Event Count Time Window.)

► View SMBIOS Event Log

Use this feature to view the events in the system event log. Select this feature and press <Enter> to view the status of an event in the log. The following information is displayed: DATE / TIME / ERROR CODE / SEVERITY.

8.5 BMC

Use this menu to configure Baseboard Management Console (BMC) settings.




Figure 8-4. BMC Screen

BMC Firmware Revision

This feature indicates the BMC firmware revision used in this system.

BMC STATUS

This feature indicates the status of the BMC firmware installed in this system.

System Event Log Menu

▶ System Event Log

Note: All values changed in this submenu do not take effect until next system reboot.

Enabling/Disabling Options

SEL Components

Select Enabled to enable all system event logging upon system boot. The options are Disabled and **Enabled**.

Erasing Settings

Erase SEL (Available when "SEL Components" is set to Enabled)

Select (Yes, On next reset) to erase all system event logs upon next system boot. Select (Yes, On every reset) to erase all system event logs upon each system reboot. Select No to keep all system event logs after each system reboot. The options are **No**, (Yes, On next reset), and (Yes, On every reset).

When SEL is Full (Available when "SEL Components" is set to Enabled)

This feature defines what the BIOS should do when the system event log is full. Select Erase Immediately to erase all events in the log when the system event log is full. The options are **Do Nothing** and Erase Immediately.

BMC Network Configuration Menu

► BMC Network Configuration

Update BMC LAN Configuration

Select Yes for the BIOS to implement all IP/MAC address changes upon next system boot. The options are **No** and Yes.

Configure IPv4 Support

BMC LAN Selection

This feature displays the type of the BMC LAN.

BMC Network Link Status:

This feature displays the status of the BMC network link for this system.

Configuration Address Source

Use this feature to select the source of the IPv4 connection. If Static is selected, note the IP address of the IPv4 connection and enter it to the system manually in the field. If DHCP is selected, the BIOS will search for a Dynamic Host Configuration Protocol (DHCP) server in the

network that is attached to and request the next available IP address for this computer. The options are Static and **DHCP**. It is available for configuration when "Update BMC LAN Configuration" is set to Yes.

Station IP Address

This feature displays the Station IP address in decimal and in dotted quad form (i.e., 172.29.176.131). It is available for configuration when "Update BMC LAN Configuration" is set to Yes and "Configuration Address Source" above is set to Static.

Subnet Mask

This feature displays the sub-network that the system belongs to. It is available for configuration when "Update BMC LAN Configuration" is set to Yes and "Configuration Address Source" above is set to Static.

Station MAC Address

This feature displays the Station MAC address for the system. MAC addresses are six two-digit hexadecimal numbers.

Gateway IP Address

This feature displays the IPv4 gateway IP address for the system. This should be in decimal and in dotted quad form (i.e., 172.29.0.1). It is available for configuration when "Update BMC LAN Configuration" is set to Yes and "Configuration Address Source" above is set to Static.

Configure IPv6 Support

IPv6 Address Status

This feature displays the status of the IPv6 address.

IPv6 Support

Use this feature to enable IPv6 support. The options are **Enabled** and Disabled. It is available for configuration when "Update BMC LAN Configuration" is set to Yes.

Configuration Address Source

Use this feature to select the source of the IPv6 connection. If Static Configuration is selected, note the IP address of IPv6 connection and enter it to the system manually in the field. If the other two options are selected, the BIOS will search for a DHCP server in the network that is attached to and request the next available IP address for this computer. The options are Static Configuration, **DHCPv6 Stateless**, and DHCPv6 Stateful. It is available for configuration when "Update BMC LAN Configuration" is set to Yes.

IPv6 Address ("Static," "DHCPv6 Stateless," or "DHCPv6 Stateful," depending on the option you selected for "Configuration Address Source" above)

This feature displays the station IPv6 address. It is available for configuration when "Update BMC LAN Configuration" is set to Yes and "Configuration Address Source" above is set to Static Configuration.

Prefix Length

This feature displays the prefix length. It is available for configuration when "Update BMC LAN Configuration" is set to Yes and "Configuration Address Source" above is set to Static Configuration.

Gateway IP

This feature displays the IPv6 gateway IP address. It is available for configuration when "Update BMC LAN Configuration" is set to Yes and "Configuration Address Source" above is set to Static Configuration.

Advanced Settings

Use this feature to set the DNS server IP. The default setting allows this system to obtain the DNS server IP automatically. The options are **Auto obtain DNS server IP** and **Manually obtain DNS server IP**. It is available for configuration when "Update BMC LAN Configuration" is set to Yes and "Configuration Address Source" above is set to DHCPv6 Stateless.

Preferred DNS server IP (Available when "Advanced Settings" above is set to Manually obtain DNS server IP)

This feature displays the preferred DNS server IP. It can be configured via Redfish.

Alternative DNS server IP (Available when "Advanced Settings" above is set to Manually obtain DNS server IP)

This feature displays the alternative DNS server IP. It can be configured via Redfish.

Configure VLAN Support

VLAN Support

Use this feature to enable the virtual LAN (VLAN) support. The options are **Enabled** and **Disabled**.

VLAN ID (Available when "VLAN Support" is set to Enabled)

Use this feature to create a new VLAN ID. The valid range is 1–4094. The default setting is **1**.

8.6 Security

Use this menu to configure the following security settings for the system.




Figure 8-5. Security Screen

Administrator Password

This feature indicates if an administrator password has been installed. Use this feature to set the administrator password, which is required to enter the BIOS Setup utility. The length of the password can be between three and 20 characters long.

User Password (Available when "Administrator Password" has been set)

This feature indicates if a user password has been installed. Use this feature to set the user password which is required to enter the BIOS Setup utility. The length of the password can be between three and 20 characters long.

Hard Drive Security Frozen

Select Enabled to freeze the Lock Security feature for HDD to protect key data in hard drives from being altered. The options are **Disabled** and Enabled.

Password Check

Select Setup for the system to check for a password upon entering the BIOS Setup utility. Select Always for the system to check for the passwords needed at bootup and upon entering the BIOS Setup utility. The options are **Setup** and Always.

Lockdown Mode (Available when the DCMS key is activated)

Select Enabled to support the Lockdown Mode, which prevents the existing data or keys stored in the system from being altered or changed in an effort to preserve system integrity and security. The options are **Disabled** and Enabled.

Secure Boot Menu

► Secure Boot

The following information is displayed:

- System Mode
- Secure Boot

Note: For detailed instructions on configuring Security Boot settings, refer to the Security Boot Configuration User's Guide at <https://www.supermicro.com/support/manuals>.

Secure Boot

Select Enabled to configure Secure Boot settings. The options are **Disabled** and Enabled.

Secure Boot Mode

Use this feature to select the desired secure boot mode for the system. The options are Standard and **Custom**.

► Enter Audit Mode

Select Ok to enter the Audit Mode workflow. It will result in erasing the Platform Key (PK) variables and resetting the system to the Setup/Audit Mode.

Note: This submenu is available when "Secure Boot Mode" is set to Custom.

► Enter Deployed Mode / Exit Deployed Mode

Select Ok to reset system to the User Mode or to the Deployed Mode.

Note: This submenu is available when "Secure Boot Mode" is set to Custom.

► Key Management

The following information is displayed:

- Vendor Keys

Note: This submenu is available when "Secure Boot Mode" is set to Custom.

Provision Factory Defaults

Select Enabled to install the default secure boot keys when the system is in the Setup Mode. Changes take effect after you save settings and reboot the system. The options are **Disabled** and Enabled.

► Restore Factory Keys

Select Yes to restore manufacturer default keys to ensure system security. The options are **Yes** and No. Selecting Yes will reset the system to the User Mode.

Note: This submenu is available when any secure keys have been installed.

► Reset To Setup Mode

This feature resets the system to the Setup Mode. The options are **Yes** and No.

Note: This submenu is available when any secure keys have been installed.

► Enroll Efi Image

This feature allows the Efi image to run in the secure boot mode and enroll the SHA256 Hash certificate of a PE image into the Authorized Signature Database (DB).

► Export Secure Boot Variables

This feature exports the NVRAM contents of secure boot variables to a storage device. The options are **Yes** and No.

Note: This submenu is available when any secure keys have been installed.

Secure Boot variable / Size / Keys / Key Source

► Platform Key (PK)

Use this feature to enter and configure a set of values to be used as platform firmware keys for the system. These values also indicate the sizes, key numbers, and the sources of the authorized signatures. Select Update to update the platform key.

► Key Exchange Keys (KEK)

Use this feature to enter and configure a set of values to be used as Key Exchange Keys for the system. These values also indicate the sizes, key numbers, and the sources of the authorized signatures. Select Update to update the Key Exchange Keys. Select Append to append the Key Exchange Keys.

► Authorized Signatures (db)

Use this feature to enter and configure a set of values to be used as Authorized Signatures for the system. These values also indicate the sizes, key numbers, and sources of the authorized signatures. Select Update to update the Authorized Signatures. Select Append to append the new Authorized Signatures.

► Forbidden Signatures (dbx)

Use this feature to enter and configure a set of values to be used as Forbidden Signatures for the system. These values also indicate sizes, key numbers, and key sources of the forbidden signatures. Select Update to update the Forbidden Signatures. Select Append to append the Forbidden Signature.

► Authorized TimeStamps (dbt)

Use this feature to set and save the timestamps for the Authorized Signatures, which will indicate the time when these signatures are entered into the system. These values also indicate sizes, keys, and key sources of the authorized timestamps. Select Update to update the Authorized TimeStamps. Select Append to append the Authorized TimeStamps.

► OsRecovery Signatures (dbr)

Use this feature to set and save the Authorized Signatures used for OS recovery. Select Update to update the OsRecovery Signatures. These values also indicate sizes, keys, and key sources of the OsRecovery Signatures. Select Append to append the OsRecovery Signatures.

8.7 Boot

Use this menu to configure Boot settings.




Figure 8-6. Boot Screen

FIXED BOOT ORDER Priorities

Use this feature to prioritize the order of bootable devices from which the system will boot. Press <Enter> on each item sequentially to select the device.

- Boot Option #1 – Boot Option #9

► Add New Boot Option

Use this feature to add a new boot option to the boot priority features for system boot.

Note: This submenu is available when any storage device is detected by the BIOS.

Add boot option

Use this feature to specify the name for the new boot option.

Path for boot option

Use this feature to enter the path for the new boot option in the format fsx:\path\filename.efi.

Boot option File Path

Use this feature to specify the file path for the new boot option.

Create

After setting the name and the file path for the boot option, press <Enter> to create the new boot option in the boot priority list.

▶ Delete Boot Option

Use this feature to select a boot device to delete from the boot priority list.

Delete Boot Option

Use this feature to remove an EFI boot option from the boot priority list.

▶ UEFI USB Key Drive BBS Priorities

Use this feature to set the system boot order of detected devices.

▶ UEFI NETWORK Drive BBS Priorities

Use this feature to set the system boot order of detected devices.

▶ UEFI Application Boot Priorities

Use this feature to set the system boot order of detected devices.

8.8 Save & Exit

Select Save & Exit from the BIOS Setup screen to configure the settings below.




Figure 8-7. Save & Exit Screen

Save Options

Discard Changes and Exit

Use this feature to exit from the BIOS Setup utility without making any permanent changes to the system configuration and reboot the system.

Save Changes and Reset

On completing the system configuration changes, use this feature to exit the BIOS Setup utility and reboot the system for the new system configuration parameters to take effect.

Save Changes

On completing the system configuration changes, use this feature to save all changes made. This will not reset (reboot) the system.

Discard Changes

Select this feature and press <Enter> to discard all changes made and return to the BIOS Setup utility.

Default Options**Load Optimized Defaults**

Select this feature and press <Enter> to load manufacturer optimized default settings, which are intended for maximum system performance but not for maximum stability.

Note: After pressing <Enter>, reboot the system for the changes to take effect, which ensures that this system has the optimized default settings.

Save as User Defaults

Select this feature and press <Enter> to save all changes as the default values specified to the BIOS Setup utility for future use.

Restore User Defaults

Select this feature and press <Enter> to restore user-defined default settings that have been saved previously.

Boot Override

Note: Use this section to override the Boot priorities sequence in the Boot menu, and immediately boot the system with a device specified here instead of the one specified in the boot list. This is a one-time boot override.

Launch EFI Shell from filesystem device

Use this feature to launch the EFI shell application (Shell.efi) from one of the available filesystem devices. A filesystem is a virtual, logical, or physical system for organizing, managing, and accessing the files and directories on devices such as SSDs, HDDs, or other storage devices.

8.9 MEBx

Use this menu to create a password for MEBx.



Figure 8-8. MEBx Screen

Intel(R) ME Password

Use this feature to create a password for the Intel Management Engine BIOS Extension.

Intel(R) AMT (Available after entering a password for Intel(R) ME Password)

Use this feature to enable or disable Active Management Technology (AMT). The options are Disabled, Partially Disabled, and **Enabled**.

Change ME Password (Available after entering a password for Intel(R) ME Password)

Press Enter and follow the prompt to change the password.

► Intel(R) AMT Configuration

► Redirection features

SOL

Use this feature to enable the SOL firmware interface. The options are Disabled and **Enabled**.

Storage Redirection

Use this feature to enable the firmware remote storage redirection. The options are Disabled and **Enabled**.

KVM Feature Selection

Use this feature to enable the firmware KVM feature. The options are Disabled and **Enabled**.

► User Consent

User Opt-in

Use this feature to configure when user consent is required. The options are None, **KVM**, and ALL.

Opt-in Configurable from Remote IT

Use this feature to enable or disable the remote change capability of the User Opt-in feature. The options are Disabled and **Enabled**.

Password Policy

Use this feature to set the password policy. The options are Default Password Only, During Setup And Configuration, and **Anytime**.

► Network Setup

► Intel(R) ME Network Name Settings

FQDN

Use this feature to specify the fully qualified domain name.

Shared/Dedicated FQDN

Use this feature to select dedicated or shared for the fully qualified domain name. The options are Dedicated and **Shared**.

► TCP/IP Settings

► Wired LAN IPv4 Configuration

DHCP Mode

Use this feature to enable or disable IPv4 DHCP mode. The options are **Disable** and **Enabled**.

Network Access State

Use this feature to change the state of the network state of ME. The options are **Network Active**, **Network Inactive**, **Partial Unprovision**, and **Full Unprovision**.

► Remote Setup And Configuration

Provisioning Server address

Use this feature to enter the provisioning server address. It's either a host name, IPv4, or IPv6.

Provisioning server port number

Use this feature to enter the provisioning server port number. The port numbers can range from 0 to 65535.

Remote Configuration **

Use this feature to enable or disable remote configuration. The options are **Disabled** and **Enabled**.

PKI DNS Suffix

Use this feature to enter the PKI DNS suffix.

Activate Remote Configuration

Use this feature to activate remote configuration.

► Manage Certificates

► Go Daddy Class 2 CA

This page displays information about the Go Daddy Root 2 CA certificates.

Active

Use this feature to set this certificate to active. The options are **NO** and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type

Hash data

► Go Daddy Root 2 CA-G2

This page displays information about the Go Daddy Class 2 CA-G2 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ Comodo AAA CA**

This page displays information about the Comodo AAA CA certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ Starfield Class 2 CA**

This page displays information about the Starfield Class 2 CA certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ Starfield Root CA-G2**

This page displays information about the Starfield Root 2 CA-G2 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► VeriSign Class 3 Primary CA-G5**

This page displays information about the VeriSign Class 3 Primary CA-G5 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► Baltimore CyberTrust Root**

This page displays information about the Baltimore CyberTrust Root certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► USERTrust RSA CA**

This page displays information about the USERTrust RSA CA certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► Verizon Global Root**

This page displays information about the Verizon Global Root certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ Entrust .net CA (2048)**

This page displays information about the Entrust .net CA (2048) certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ Entrust Root CA**

This page displays information about the Entrust Root CA certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ Entrust Root CA-G2**

This page displays information about the Entrust Root CA-G2 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► VeriSign Universal Root CA**

This page displays information about the VeriSign Universal Root CA certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► Affirm Trust Premium**

This page displays information about the Affirm Trust Premium certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► DigiCert Global Root CA**

This page displays information about the DigiCert Global Root CA certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► DigiCert Global Root G2**

This page displays information about the DigiCert Global Root G2 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ DigiCert Global Root G3**

This page displays information about the DigiCert Global Root G3 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ DigiCert Trusted Root G4**

This page displays information about the DigiCert Trusted Root G4 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****▶ GlobalSign Root CA - R3**

This page displays information about the GlobalSign Root CA - R3 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► GlobalSign ECC Root CA - R5**

This page displays information about the GlobalSign ECC Root CA - R5 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► GlobalSign Root CA - R6**

This page displays information about the GlobalSign Root CA - R6 certificates.

Active

Use this feature to set this certificate to active. The options are NO and **YES**.

Default

Shows this certificate as default. The option is **YES**.

Hash type**Hash data****► Power Control****ME ON in Host Sleep States**

Use this feature to select the host sleep states. The options are Desktop: ON in S0 and **Desktop: ON in S0, ME Wake in S3, S4-5**.

Idle Timeout

Use this feature to enter the timeout value. The value can range from 1 to 65535.

Appendix A:

BIOS Codes

For information about BIOS codes for the SYS-E300-14AR server, refer to the following content.

BIOS Error POST (Beep) Codes

During the Power-On Self-Test (POST) routines, which are performed each time the system is powered on, errors may occur.

Non-fatal errors are those which, in most cases, allow the system to continue the boot up process. The error messages normally appear on the screen.

Fatal errors are those which will not allow the system to continue the boot up process. If a fatal error occurs, you should consult with your system manufacturer for possible repairs.

These fatal errors are usually communicated through a series of audible beeps that can be heard on an external buzzer connected to JD1. The table shown below lists some common errors and their corresponding beep codes encountered by users.

| BIOS Beep (POST) Codes | | |
|------------------------|---------------------------------|--|
| Beep Code | Error Message | Description |
| 1 beep | Refresh | Circuits have been reset (Ready to power up) |
| 5 short, 1 long | Memory error | No memory detected in system |
| 5 short, 2 long | Display memory read/write error | Video adapter missing or with faulty memory |
| 1 long continuous | System OH | System overheat condition |

Additional BIOS POST Codes

The AMI BIOS supplies additional checkpoint codes, which are documented online at <https://www.supermicro.com/support/manuals> ("AMI BIOS POST Codes User's Guide").

For information on AMI updates, refer to <https://www.ami.com/products>.

Appendix B:

Standardized Warning Statements for DC Systems

The following statements are industry standard warnings, provided to warn the user of situations which have the potential for bodily injury. Should you have questions or experience difficulty, contact Supermicro's Technical Support department for assistance. Only certified technicians should attempt to install or configure components.

Read this section in its entirety before installing or configuring components in the Supermicro SYS-E300-14AR server.

These warnings may also be found on our website at the following page:

https://www.supermicro.com/about/policies/safety_information.cfm

Standard Warning Definition



Warning! This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be familiar with standard practices for preventing accidents.

تحذير! هذا الرمز التحذيري يعني خطر. إنك في موقف قد يتسبب في إصابة جسدية. قبل العمل على أي أجهزة يجب أن تكون على دراية بالممارسات القياسية للحيلولة دون وقوع حوادث.

警告! 此警告符号代表危险, 表示正处于可能遭受严重身体伤害的工作环境。在使用任何设备开始工作之前, 务必熟悉防止事故发生的标准工作规范。

警告! 此警告符號代表危險。您正處於可能身體可能會受損傷的工作環境中。操作任何設備之前, 請熟悉標準做法以預防事故發生。

Advarsel! Dette advarselssymbol betyder fare. Du er i en situation, der kan føre til personskader. Før du arbejder på noget udstyr, skal du være bekendt med standardpraksis for at forebygge ulykker.

Waarschuwing! Dit waarschuwingssymbool betekent gevaar. U bevindt zich in een situatie die lichamelijk letsel zou kunnen veroorzaken. Voordat u aan enige apparatuur gaat werken, moet u vertrouwd zijn met standaard praktijken voor het voorkomen van ongevallen.

Varoitus! Tämä varoitussymboli tarkoittaa vaaraa. Olet tilanteessa, joka voi aiheuttaa ruumiinvammoja. Ennen kuin ryhdyt työskentelemään laitteiden parissa, tutustu onnettomuuksien ehkäisemistä koskeviin vakiintuneisiin käytäntöihin.

Attention! Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant entraîner des blessures ou des dommages corporels. Avant de travailler sur un équipement, familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents.

Warnung! Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu Körperverletzungen führen kann. Bevor Sie an Geräten arbeiten, machen Sie sich mit den üblichen Verfahren zur Unfallverhütung vertraut.

אזהרה! סמל אזהרה זה מסמן סכנה. אתה נמצא במצב שעלול לגרום לפגיעה גופנית. לפני שתתחיל לעבוד על כל ציוד, הכר את הנהלים הסטנדרטיים למניעת תאונות.

चेतावनी! यह चेतावनी चिह्न खतरे का प्रतीक है। आप ऐसी स्थिति में हैं जिससे शारीरिक चोट लग सकती है। किसी भी उपकरण पर काम करने से पहले, दुर्घटनाओं को रोकने के लिए मानक प्रथाओं से परिचित हो लें।

警告! この警告記号は危険を意味します。人身事故につながる可能性のある状況にあります。機器で作業を行う前に、標準的な事故防止策に精通してください。

경고! 이 경고 기호는 위험이 있음을 알려 줍니다. 신체 상해를 초래할 수 있는 상황입니다. 장비에서 작업하기 전에 사고 예방을 위한 표준 수칙을 숙지하십시오.

Advarsel! Dette advarselsymbolet betyr fare. Du er i en situasjon som kan forårsake kroppsskade. Før du arbeider på noe utstyr, må du gjøre deg kjent med standardrutiner for å forhindre ulykker.

¡Advertencia! Este símbolo de advertencia significa peligro. Se encuentra en una situación que podría provocar lesiones corporales. Antes de trabajar con cualquier equipo, familiarícese con las prácticas estándar para prevenir accidentes.

Varning! Denna varningssymbol betyder fara. Du befinner dig i en situation som kan orsaka personskada. Innan du arbetar på någon utrustning måste du bekanta dig med standardrutiner för att förhindra olyckor.

Electrical Warning Definition



Warning! This warning symbol indicates high voltage may be encountered when performing a procedure. Before you work on any equipment, be aware of the hazards involved with electrical circuitry.

تحذير! يشير رمز التحذير هذا إلى احتمالية مواجهة جهد كهربائي عالٍ عند إجراء عملية ما. قبل البدء في العمل على أي أجهزة كن على دراية بالمخاطر المرتبطة بالدوائر الكهربائية.

警告！此警告符号表示作业过程中可能会遇到高电压。操作任何设备之前，请务必了解电路的危险。

警告！此警告符號表示執行程序時可能會遇到高電壓。操作任何設備之前，請瞭解與電路相關的危害。

Advarsel! Dette advarselssymbol indikerer, at der kan opstå høj spænding under udførelsen af en procedure. Før du arbejder på noget udstyr, skal du være opmærksom på de farer, der er forbundet med elektriske kredsløb.

Waarschuwing! Dit waarschuwingssymbool geeft aan dat men hoge spanning tegen kan komen bij het uitvoeren van een procedure. Voordat u aan enige apparatuur gaat werken, moet u zich bewust zijn van de gevaren van elektrische schakelssystemen.

Varoitus! Tämä varoitussymboli osoittaa, että toimenpiteen suorittamisen aikana voi esiintyä korkeaa jännitettä. Ennen kuin ryhdyt työskentelemään laitteiden parissa, ota huomioon sähköpiireihin liittyvät vaarat.

Attention! Ce symbole d'avertissement indique un risque d'exposition à une tension élevée lors de l'exécution d'une procédure. Avant de travailler sur un équipement, prenez connaissance des dangers liés aux circuits électriques.

Warnung! Dieses Warnsymbol weist darauf hin, dass bei der Durchführung eines Vorgangs Hochspannung auftreten kann. Bevor Sie an Geräten arbeiten, machen Sie sich mit den Gefahren elektrischer Schaltungen vertraut.

אזהרה! סמל אזהרה זה מציין כי ייתכן שתיתקל במתח גבוה בעת ביצוע הליך. לפני עבודה על ציוד כלשהו, עליך להיות מודע לסכנות הכרוכות במעגלים חשמליים.

चेतावनी! यह चेतावनी चिह्न इंगित करता है कि प्रक्रिया को निष्पादित करते समय उच्च वोल्टेज का सामना करना पड़ सकता है। किसी भी उपकरण पर काम करने से पहले, विद्युत सर्किट्री से जुड़े खतरों के प्रति सचेत रहें।

警告! この警告記号は、手順を実行する際に高電圧が発生する可能性があることを示しています。機器で作業を行う前に、電気回路に関連する危険に注意してください。

경고! 이 경고 기호는 절차 수행 중 고전압에 노출될 수 있음을 알려 줍니다. 장비에서 작업하기 전에 전기 회로와 관련된 위험 요소를 충분히 인지하십시오.

Advarsel! Dette varselsymbolet indikerer at det kan oppstå høy spenning når en prosedyre utføres. Før du arbeider på utstyr, må du være oppmerksom på farene forbundet med elektriske kretser.

¡Advertencia! Este símbolo de advertencia indica que puede haber alto voltaje al realizar un procedimiento. Antes de trabajar con cualquier equipo, tenga en cuenta los peligros que conllevan los circuitos eléctricos.

Varning! Denna varningssymbol indikerar att hög spänning kan förekomma när en procedur utförs. Innan du arbetar med någon utrustning ska du vara medveten om de faror som är förknippade med elektriska kretsar.

Installation Instructions



Warning! Read the installation instructions before connecting the system to the power source.

تحذير! اقرأ تعليمات التثبيت قبل توصيل النظام بمصدر الطاقة.

警告！ 将此系统连接电源前，请先阅读安装说明。

警告！ 將系統與電源連接前，請先閱讀安裝說明。

Advarsel! Læs monteringsvejledningen, før systemet sluttes til strømforsyningen.

Waarschuwing! Raadpleeg de installatie-instructies voordat u het systeem op de voedingsbron aansluit.

Varoitus! Lue asennusohjeet ennen järjestelmän liittämistä virtälähteeseen.

Attention! Avant de brancher le système sur la source d'alimentation, consulter les directives d'installation.

Warnung! Vor dem Anschließen des Systems an die Stromquelle die Installationsanweisungen lesen.

אזהרה! יש לקרוא את הוראות ההתקנה לפני חיבור המערכת למקור המתח.

चेतावनी! सिस्टम को बिजली के स्रोत से जोड़ने से पहले स्थापना निर्देश पढ़ें।

警告！ システムを電源に接続する前に、設置手順書をお読み下さい。

경고! 시스템을 전원에 연결하기 전에 설치 안내를 읽어주십시오.

Advarsel! Les installasjonsinstruksjonene før du kobler systemet til strømkilden.

¡Advertencia! Lea las instrucciones de instalación antes de conectar el sistema a la red de alimentación.

Varning! Läs installationsanvisningarna innan du ansluter systemet till strömkällan.

Circuit Breaker



Warning! This product relies on the building's installation for short-circuit (overcurrent) protection. Ensure that the protective device is rated not greater than: 250 VAC, 20 A.

تحذير! يعتمد هذا المنتج على التركيبات الكهربائية في المبنى للحماية من حدوث قصر دائرة (تيار زائد). تأكد من أن تصنيف جهاز الحماية لا يتجاوز: 250 فولت تيار متردد, 20 أمبير.

警告! 此产品由建筑物的供电系统提供短路(过载)保护,并确保额定电压/电流不大于 250 VAC/20 A。

警告! 此产品的短路(過載電流)保護由建築物的供電系統提供,確保短路保護設備的額定電流不大於 250 VAC、20 A。

Advarsel! Dette produkt forudsætter, at bygningens elinstallation sørger for kortslutningsbeskyttelse (overstrøm). Sørg for, at beskyttelsesordeningen ikke er klassificeret til mere end: 250 VAC, 20 A.

Waarschuwing! Dit product vertrouwt op de installatie van het gebouw voor kortsluitbeveiliging (overstroombeveiliging). Zorg ervoor dat de beveiligingsvoorziening is gespecificeerd voor niet meer dan: 250 VAC, 20 A.

Varoitus! Tämä tuote on riippuvainen rakennuksen asennuksesta oikosulku- (ylivirta-) suojausten osalta. Varmista, että suojalaitteen nimellisarvot eivät ylitä seuraavia arvoja: 250 VAC, 20 A.

Attention! Ce produit dépend de l'installation du bâtiment pour la protection contre les courts-circuits (surintensité). Assurez-vous que le dispositif de protection n'est pas supérieur à : 250 VAC, 20 A.

Warnung! Dieses Produkt ist auf den Kurzschluss- bzw. Überstromschutz der Gebäudeinstallation angewiesen. Stellen Sie sicher, dass die Schutzvorrichtung für maximal 250 VAC, 20 A ausgelegt ist.

אזהרה! מוצר זה מסתמך על תשתית החשמל של המבנה להגנה מפני קצר חשמלי (זרם יתר). ודא שדירוג התקן ההגנה אינו עולה על: 250 VAC, 20 A.

चेतावनी! यह उत्पाद शॉर्ट-सर्किट (ओवरकरंट) सुरक्षा के लिए भवन की स्थापना पर निर्भर करता है। सुनिश्चित करें कि सुरक्षात्मक उपकरण की रेटिंग निम्नलिखित से अधिक न हो: 250 VAC, 20 A.

警告! この製品は、短絡(過電流)保護装置がある建物での設置を前提としています。保護装置の定格が次の値以下であることを確認 ください: 250 VAC、20 A。

경고! 이 제품은 단락(과전류) 방지에 대해서 전적으로 건물의 관련 설비에 의존합니다. 보호 장치의 정격이 다음 값을 초과하지 않도록 하십시오: 250 VAC(볼트), 20 A(암페어).

Advarsel! Dette produktet er avhengig av bygningens installasjon for kortslutningsbeskyttelse (overstrømsbeskyttelse). Sørg for at beskyttelsesanordningen ikke er klassifisert som høyere enn: 250 V vekselstrøm, 20 A.

¡Advertencia! Este producto depende de la instalación del edificio para protección contra cortocircuitos (sobrecorriente). Asegúrese de que el dispositivo de protección tenga una clasificación no mayor a: 250 VAC, 20 A.

Varning! Denna produkt är beroende av byggnadens installation för kortslutningsskydd (överströmsskydd). Se till att skyddsanordningen inte är märkt för mer än: 250 VAC, 20 A.

Power Disconnection Warning



Warning! The system must be disconnected from all sources of power and the power cord removed from the power supply module(s) before accessing the chassis interior to install or remove system components (except for hot-swappable components).

تحذير! يجب فصل النظام عن جميع مصادر الطاقة، وإزالة سلك الطاقة من وحدة/وحدات إمداد الطاقة قبل الدخول إلى الجزء الداخلي من الهيكل لتثبيت أو فك مكونات النظام (باستثناء المكونات القابلة للاستبدال السريع).

警告！在打开机箱并安装或移除内部器件(热插拔器件除外)前，必须将系统完全断电，并移除电源线。

警告！在您打開機殼安裝或移除內部元件(熱插拔元件除外)前，必須將系統完全斷電，並移除電源線。

Advarsel! Systemet skal afbrydes fra alle strømkilder, og strømkablet skal fjernes fra strømforsyningsmodulerne, før der gives adgang til kabinettet for at montere eller fjerne systemkomponenter (undtagen hot-swap-komponenter).

Waarschuwing! Het systeem moet worden losgekoppeld van alle voedingen en het stroomsnoer moet uit de voedingsmodule(s) worden gehaald voorafgaand aan toegang tot de binnenkant van het chassis voor installeren of verwijderen van systeemcomponenten (behalve hot-swap componenten).

Varoitus! Järjestelmä on irrotettava kaikista virtalähteistä ja virtajohto on irrotettava virtalähdemoduulista (moduuleista) ennen kotelon sisälle pääsyä järjestelmän komponenttien asentamista tai poistamista varten (lukuun ottamatta hot-swap-komponentteja).

Attention! Le système doit être déconnecté de toutes les sources d'alimentation et le cordon d'alimentation doit être débranché du/des modules d'alimentation avant d'accéder à l'intérieur du châssis pour installer ou retirer des composants du système (à l'exception des composants remplaçables à chaud).

Warnung! Das System muss von allen Stromquellen getrennt und das Netzkabel von den Netzteilmodulen entfernt werden, bevor auf den Innenraum des Chassis zugegriffen wird, um Systemkomponenten zu installieren oder zu entfernen (ausgenommen Hot-Swap-Komponenten).

אזהרה! יש לנתק את המערכת מכל מקורות הכוח ולהסיר את כבל החשמל ממודולי/אספקת החשמל לפני הגישה לחלק הפנימי של המארז לצורך התקנה או הסרה של רכיבי המערכת (למעט רכיבים הניתנים להחלפה חמה).

चेतावनी! सिस्टम के घटकों को इंस्टॉल करने या निकालने (हॉट-स्वैप घटकों को छोड़कर) के लिए चेसिस के आंतरिक भाग तक पहुँचने से पहले, सिस्टम को बिजली के सभी स्रोतों से डिस्कनेक्ट किया जाना चाहिए और बिजली की आपूर्ति मॉड्यूल से पावर कॉर्ड को निकाल दिया जाना चाहिए।

警告! システムコンポーネント(ホットスワップコンポーネントを除く)の取り付けまたは取り外しを行うために、シャーシ内部にアクセスするには、システムの電源はすべてのソースから切断され、電源コードは電源モジュールから取り外す必要があります。

경고! (핫스왑 구성품을 제외하고) 시스템에 부품들을 장착하거나 제거하기 위해서는 새시 내부에 접근하기 전에 반드시 전원 공급장치로부터 연결되어있는 모든 전원과 전기코드를 분리해 주어야 합니다.

Advarsel! Systemet må kobles fra alle strømkilder, og strømledningen må fjernes fra strømforsyningsmodulen (e) før man går inn i kabinettet for å installere eller fjerne systemkomponenter (unntatt komponenter som kan byttes ut under drift).

¡Advertencia! El sistema debe estar desconectado de todas las fuentes de energía y el cable de alimentación debe retirarse de los módulos de fuente de alimentación antes de acceder al interior del chasis para instalar o quitar componentes del sistema (excepto los componentes reemplazables en caliente).

Varning! Systemet måste vara fränkopplat från alla strömkällor och strömsladden måste vara borttagen från strömförsörjningsmodulerna innan du öppnar chassit för att installera eller ta bort systemkomponenter (med undantag för hot-swap-komponenter).

Equipment Installation



Warning! Only authorized personnel and qualified service persons should be allowed to install, replace, or service this equipment.

تحذير! لا يُسمح إلا للعاملين المعتمدين وفنيي الخدمة المؤهلين بتركيب هذا الجهاز أو استبداله أو صيانته.

警告! 仅限经过授权培训且拥有相关资质的人员才能进行此设备的安装、更换和维修。

警告！ 只有經過受訓且具資格人員才可安裝、更換與維修此設備。

Advarsel! Dette udstyr må kun installeres, udskiftes eller serviceres af autoriseret personale og kvalificerede servicemedarbejdere.

Waarschuwing! Alleen geautoriseerd personeel en gekwalificeerd onderhoudspersoneel mag deze apparatuur installeren, vervangen of onderhouden.

Varoitus! Vain valtuutetut henkilöt ja pätevät huoltoteknikot saavat asentaa, vaihtaa tai huoltaa tätä laitetta.

Attention! Seul le personnel autorisé et le personnel de maintenance qualifié doivent être autorisés à installer, remplacer ou entretenir cet équipement.

Warnung! Nur autorisiertes Personal und qualifizierte Servicetechniker dürfen dieses Gerät installieren, austauschen oder warten.

אזהרה! רק אנשי צוות מורשים ואנשי שירות מוסמכים רשאים להתקין, להחליף או לטפל בציוד זה.

चेतावनी! केवल अधिकृत कर्मियों और योग्य सेवा व्यक्तियों को ही इस उपकरण को स्थापित करने, बदलने या सेवा देने की अनुमति दी जानी चाहिए।

警告！ トレーニングを受け認定された人だけがこの機器の設置、交換、またはサービスを許可されています。

경고! 승인된 직원과 자격을 갖춘 서비스 담당자만이 이 장비를 설치, 교체 또는 서비스할 수 있습니다.

Advarsel! Kun autorisert personell og kvalifiserte servicefolk skal ha tillatelse til å installere, bytte ut eller utføre service på dette utstyret.

¡Advertencia! Sólo el personal autorizado y el personal de servicio calificado pueden instalar, reemplazar o dar servicio a este equipo.

Warning! Endast auktoriserad personal och kvalificerade servicetekniker får installera, byta ut eller utföra service på denna utrustning.

Rack Stability Hazard



Warning! Stability hazard. The rack may tip over causing serious personal injury. Before extending the rack to the installation position, read the installation instructions. Do not put any load on the slide-rail mounted equipment in the installation position. Do not leave the slide-rail mounted equipment in the installation position.

تحذير! خطر عدم الاستقرار. قد ينقلب الحامل، مما قد يتسبب في إصابات شخصية خطيرة. قبل تمديد الحامل إلى موضع التركيب اقرأ إرشادات التركيب. لا تضع أي حمولة على الأجهزة المركبة على حوامل منزلقة في وضع التركيب. لا تترك الأجهزة المركبة على حوامل منزلقة في وضع التركيب.

警告！稳定性危险。机架可能会翻倒，造成严重的人身伤害。在将机架延伸到安装位置之前，请阅读安装说明。请勿在安装位置对滑轨安装的设备施加任何负载。请勿将滑轨安装的设备留在安装位置。

警告！穩定性危險。機架可能會翻倒，造成嚴重的人身傷害。將機架延伸至安裝位置前，請先閱讀安裝說明。請勿在安裝位置的滑軌安裝設備上放置任何負載。請勿將滑軌安裝設備留在安裝位置。

Advarsel! Stabilitetsfare. Udstyrsskabet kan vælte, hvilket kan føre til alvorlige personskader. Læs monteringsvejledningen, før udstyrsskabet trækkes ud til monteringsstedet. Anbring ikke nogen belastning på udstyr monteret på skinner, når det er på monteringsstedet. Efterlad ikke udstyr monteret på skinner på monteringsstedet.

Waarschuwing! Gevaar voor instabiliteit. Het rack kan kantelen en ernstig persoonlijk letsel veroorzaken. Lees de installatie-instructies voordat u het rack uitschuift naar de installatiepositie. Plaats geen last op de op de glijrail gemonteerde apparatuur in de installatiepositie. Laat de op de glijrail gemonteerde apparatuur niet in de installatiepositie staan.

Varoitus! Vakausvaara. Teline voi kaatua ja aiheuttaa vakavia henkilövahinkoja. Ennen telineen asettamista asennusasentoon, lue asennusohjeet. Älä aseta mitään kuormitusta liukukiskoon asennettuihin laitteisiin asennusasennossa. Älä jätä liukukiskoon asennettuja laitteita asennusasentoon.

Attention! Danger d'instabilité. Le rack peut basculer et provoquer des blessures corporelles graves. Avant d'étendre le rack en position d'installation, lire les instructions d'installation. Ne pas charger l'équipement monté sur rail de glissière en position d'installation. Ne pas laisser l'équipement monté sur rail de glissière en position d'installation.

Warnung! Gefahr der Instabilität. Das Rack kann umkippen und schwere Verletzungen verursachen. Lesen Sie vor dem Ausziehen des Racks in die Installationsposition die Installationsanweisungen. Belasten Sie in der Installationsposition keine auf Gleitschienen montierten Geräte. Lassen Sie auf Gleitschienen montierte Geräte nicht unbeaufsichtigt in der Installationsposition.

אזהרה! סכנת יציבות. הארון עלול להתהפך ולגרום לפציעה גופנית חמורה. לפני הארכת הארון למצב התקנה, יש לקרוא את הוראות ההתקנה. אין להניח עומס כלשהו על הציוד המותקן על מסילות ההחלקה כשהוא במצב התקנה. אין להשאיר את הציוד המותקן על מסילות ההחלקה במצב התקנה.

चेतावनी! स्थिरता का खतरा। रैक पलट सकता है जिससे गंभीर व्यक्तिगत चोट लग सकती है। रैक को इंस्टालेशन स्थिति तक बढ़ाने से पहले, स्थापना निर्देश पढ़ें। स्थापना स्थिति में स्लाइड-रेल पर लगे उपकरणों पर कोई भार न डालें। स्लाइड-रेल पर लगे उपकरणों को स्थापना स्थिति में न छोड़ें।

警告! 安定性に危険があります。ラックが転倒して、重大な人身事故を引き起こす可能性があります。ラックを設置位置まで伸ばす前に、設置手順をお読みください。設置位置にあるスライドレールに取り付けられた機器に負荷をかけないでください。スライドレールに取り付けられた機器を設置位置に放置しないでください。

경고! 안정성 위험. 랙이 넘어져 심각한 개인 부상을 입을 수 있습니다. 랙을 설치 위치까지 확장하기 전에 설치 지침을 읽으십시오. 설치 위치에서 슬라이드 레일 장착 장비에 하중을 가하지 마십시오. 슬라이드 레일 장착 장비를 설치 위치에 두지 마십시오.

Advarsel! Stabilitetsfare. Stativet kan velte og forårsake alvorlig personskade. Les installasjonsanvisningen før du forlenger stativet till installasjonsposisjonen. Ikke belast utstyret som er montert på glideskinnen i installasjonsposisjon. Ikke la utstyret som er montert på glideskinnen stå i installasjonsposisjon.

¡Advertencia! Peligro de inestabilidad. El rack podría volcarse y causar lesiones personales graves. Antes de extender el rack a la posición de instalación, lea las instrucciones de instalación. No coloque ninguna carga sobre el equipo montado sobre rieles deslizantes en la posición de instalación. No deje el equipo montado sobre rieles deslizantes en la posición de instalación.

Varning! Stabilitetsrisk. Racket kan välta och orsaka allvarliga personskador. Läs monteringsanvisningarna innan du skjuter ut racket till monteringspositionen. Belasta ej utrustning som är monterad på glidskena i installationsläget. Lämna ej utrustning som är monterad på glidskena i monteringsläget.

Rack-Mounted Equipment Warning



Warning! Rack-mounted equipment should not be used as a shelf or work space.

تحذير! لا ينبغي استخدام المعدات المثبتة على حوامل كرف أو مساحة عمل.

警告！机架式设备不应用作货架或工作空间。

警告！不得將機架式設備當作置物架或工作空間使用。

Advarsel! Udstyr, der er monteret i udstyrsskabe, må ikke bruges som hylder eller arbejdsflader.

Waarschuwing! In rack gemonteerde apparatuur moet niet worden gebruikt als plank of werkruimte.

Varoitus! Telineasennettavia laitteita ei saa käyttää hyllynä tai työtasoina.

Attention! Un équipement installé en rack ne doit pas être utilisé comme une étagère ou un espace de travail.

Warnung! In Racks montierte Geräte dürfen nicht als Ablagefläche oder Arbeitsfläche verwendet werden.

אזהרה! אין להשתמש בצידוד המותקן במסד (Rack) כמדף או כמשטח עבודה.

चेतावनी! रैक-माउंटेड उपकरण का उपयोग शेल्फ या कार्यक्षेत्र के रूप में नहीं किया जाना चाहिए।

警告! ラックマウント機器を棚や作業スペースとして使用しないでください。

경고! 랙 장착 장비를 선반 또는 작업대처럼 사용하지 마십시오.

Advarsel! Rackmontert utstyr skal ikke brukes som hylle eller arbeidsområde.

¡Advertencia! Los equipos montados en rack no deben utilizarse como estante o espacio de trabajo.

Varning! Rackmonterad utrustning ska inte användas som hylla eller arbetsyta.

Restricted Access Location



Warning! This unit is intended for installation in restricted access areas. A restricted access area can be accessed only by an instructed person or a skilled person.

تحذير! هذه الوحدة مخصصة للتركيب في المناطق الممنوع الدخول إليها. يقتصر الدخول إلى منطقة منع الدخول إلا للأشخاص المدربين أو المهرة.

警告! 此装置应安装在限制进出的场所, 而此类场所仅限经过相关训练或技术熟练的人员进出。

警告！此部件應安裝在限制進出區域。只有受過指導的人員或專業人員才可進出限制進出區域。

Advarsel! Denne enhed er beregnet til montering i områder med begrænset adgang. Et område med begrænset adgang må kun tilgås af en instrueret person eller en fagkyndig person.

Waarschuwing! Deze eenheid is bedoeld voor installatie in gebieden met beperkte toegang. Er kan alleen toegang worden verkregen tot een gebied met beperkte toegang door een geïnstrueerde persoon of een ervaren persoon.

Varoitus! Tämä laite on tarkoitettu asennettavaksi rajoitetun pääsyn alueille. Rajoitetun pääsyn alueelle pääsee vain koulutettu tai ammattitaitoinen henkilö.

Attention! Cet appareil est destiné à être installé dans des zones à accès restreint. Une zone à accès restreint n'est accessible qu'à une personne formée ou qualifiée.

Warnung! Diese Einheit ist zur Installation in Bereichen mit beschränktem Zutritt vorgesehen. Ein Bereich mit beschränktem Zutritt darf nur von unterwiesenen oder fachkundigen Personen betreten werden.

אזהרה! יחידה זו מיועדת להתקנה באזורים עם גישה מוגבלת. ניתן לגשת לאזור עם גישה מוגבלת רק על ידי אדם שהוכשר לכך או אדם מיומן.

चेतावनी! यह इकाई प्रतिबंधित पहुँच वाले क्षेत्रों में स्थापना के लिए ही है। प्रतिबंधित पहुँच वाले क्षेत्र में केवल एक निर्देशित व्यक्ति या कुशल व्यक्ति द्वारा ही पहुँचा जा सकता है।

警告！このユニットはアクセス制限区域に設置することを想定しています。アクセス制限区域は、トレーニングを受けた人または熟練者だけが出入り可能です。

경고! 본 장치는 접근이 제한된 구역에 설치하도록 되어있습니다. 교육을 받은 사람 또는 숙련된 사람만 접근 제한 구역에 들어갈 수 있습니다.

Advarsel! Denne enheten er beregnet for installasjon i områder med begrenset tilgang. Et område med begrenset tilgang kan kun nås av en person som har fått instruksjoner eller en fagperson.

¡Advertencia! Esta unidad está diseñada para su instalación en áreas de acceso restringido. A un área de acceso restringido solo puede acceder una persona instruida o una persona capacitada.

Varning! Denna enhet är avsedd för installation i områden med begränsad åtkomst. Ett område med begränsad åtkomst får endast beträdas av en instruerad eller kvalificerad person.

Battery Handling



Warning! There is risk of explosion if the battery is replaced by an incorrect type. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

تحذير! يوجد خطر حدوث انفجار إذا تم استبدال البطارية بنوع غير صحيح. استبدل البطارية بنفس النوع أو نوع مكافئ موصى به من قبل الشركة المصنعة فقط. يجب التخلص من البطاريات المستخدمة وفقاً لإرشادات الجهة المصنعة.

警告! 如果更换的电池类型不正确, 有爆炸危险。更换电池时, 请使用制造商推荐的相同或同等型号的电池。请按制造商的说明处理废旧电池。

警告! 如果更換的電池類型不正確, 有爆炸危險。請使用製造商建議之相同或功能相當的電池更換原有電池。請按照製造商的說明指示處理廢棄舊電池。

Advarsel! Der er risiko for eksplosion, hvis batteriet skiftes med et batteri af den forkerte type. Batteriet må kun skiftes med et batteri af samme eller tilsvarende type, der anbefales af producenten. Opbrugte batterier skal bortskaffes i henhold til vejledningerne fra producenten.

Waarschuwing! Er bestaat een explosiegevaar als de batterij wordt vervangen door een onjuist type. Vervang de batterij alleen door hetzelfde type of een soortgelijk type aanbevolen door de fabrikant. Verwijder gebruikte batterijen overeenkomstig de instructies van de fabrikant.

Varoituis! Väärän tyypisen akun käyttö voi aiheuttaa räjähdysvaaran. Vaihda akku vain valmistajan suosittelemaan samaan tai vastaavaan tyypiseen akkuun. Hävitä käytetyt paristot valmistajan ohjeiden mukaisesti.

Attention! Il y a un risque d'explosion si la batterie est remplacée par une d'un type incorrect. Remplacez la batterie uniquement par une d'un type identique ou équivalent recommandé par le fabricant. Éliminez les batteries usagées conformément aux instructions du fabricant.

Warnung! Es besteht Explosionsgefahr, wenn die Batterie durch einen falschen Typ ersetzt wird. Ersetzen Sie die Batterie ausschließlich durch denselben oder einen vom Hersteller empfohlenen gleichwertigen Typ. Entsorgen Sie gebrauchte Batterien gemäß den Anweisungen des Herstellers.

אזהרה! קיימת סכנת פיצוץ אם הסוללה תוחלף בסוללה מסוג שגוי. החלף את הסוללה רק בסוללה מאותו סוג או בסוללה מקבילה המומלצת על ידי היצרן. השלך סוללות משומשות בהתאם להוראות היצרן.

चेतावनी! यदि बैटरी को गलत प्रकार से बदला जाता है तो विस्फोट का जोखिम है। बैटरी को केवल निर्माता द्वारा अनुशंसित समान या समकक्ष प्रकार से ही बदलें। इस्तेमाल की गई बैटरियों का निपटान निर्माता के निर्देशों के अनुसार करें।

警告! 電池を間違ったタイプに交換すると爆発する危険があります。交換する電池はメーカーが推奨するタイプ、または同等のものを使用してください。使用済み電池は、メーカーの指示に従って廃棄してください。

경고! 배터리를 잘못된 종류로 교체하면 폭발의 위험이 있습니다. 기존 배터리와 동일하거나 제조사에서 권장하는 동등한 종류의 배터리로만 교체해야 합니다. 제조사의 안내에 따라 사용된 배터리를 처리하여 주십시오.

Advarsel! Det er fare for eksplosjon hvis batteriet byttes ut med et av feil type. Batterier skal kun byttes ut med et av lik eller tilsvarende type, som anbefalt av produsenten. Kast brukte batterier i henhold til produsentens instruksjoner.

¡Advertencia! Existe riesgo de explosión si se sustituye la batería por una de tipo incorrecto. Reemplace la batería únicamente con el mismo tipo o uno equivalente recomendado por el fabricante. Deseche las baterías usadas de acuerdo con las instrucciones del fabricante.

Varning! Det finns risk för explosion om batteriet byts ut mot en felaktig typ. Byt endast ut batteriet mot ett batteri av samma eller likvärdig typ som rekommenderas av tillverkaren. Kassera förbrukade batterier i enlighet med tillverkarens anvisningar.

Redundant Power Supplies



Warning! This unit might have more than one power supply connection. All connections must be removed to de-energize the unit.

تحذير! قد تحتوي هذه الوحدة على أكثر من وصلة لإمداد الطاقة. يجب فصل جميع التوصيلات لفصل الطاقة عن الوحدة.

警告！ 本设备可能有多个电源连接。必须切断所有连接，才能使设备断电。

警告！ 此裝置連接的電源可能不只一個。必須切斷所有電源才能停止對該裝置的供電。

Advarsel! Denne enhed kan have mere end én strømforsyningsforbindelse. Alle forbindelser skal fjernes for at deaktivere spændingen.

Waarschuwing! Deze eenheid kan meer dan één stroomtoevoeraansluiting bevatten. Alle aansluitingen dienen verwijderd te worden om het apparaat stroomloos te maken.

Varoitus! Laitteessa voi olla useampi kuin yksi virtalähteen liitäntä. Laitteen virta on katkaistava irrottamalla kaikki liitännät.

Attention! Cette unité peut avoir plus d'une connexion d'alimentation. Pour supprimer toute tension et tout courant électrique de l'unité, toutes les connexions d'alimentation doivent être débranchées.

Warnung! Diese Einheit kann über mehr als eine Stromversorgungsanschluss verfügen. Um sicherzustellen, dass die Einheit spannungsfrei ist, müssen alle Verbindungen entfernt werden.

אזהרה! יחידה זו עשויה לכלול יותר מחיבור אחד לספק כוח. יש לנתק את כל החיבורים כדי להפסיק את הזנת המתח ליחידה.

चेतावनी! इस इकाई में एक से अधिक पावर सप्लाय कनेक्शन हो सकते हैं। इकाई को ऊर्जा-मुक्त (डी-एनर्जाइज) करने के लिए सभी कनेक्शन हटा दिए जाने चाहिए।

警告！ このユニットは複数の電源装置が接続されている場合があります。ユニットの電源を切るためには、すべての接続を取り外さなければなりません。

경고! 이 장치에는 한 개 이상의 전원 공급 단자가 연결되어 있을 수 있습니다. 이 장치에 전원을 차단하기 위해서는 모든 연결 단자를 제거해야만 합니다.

Advarsel! Denne enheten kan ha mer enn én strømforsyningstilkobling. Alle tilkoblinger må fjernes for å gjøre enheten strømløs.

¡Advertencia! Puede que esta unidad tenga más de una conexión para fuentes de alimentación. Para cortar por completo el suministro de energía, deben desconectarse todas las conexiones.

Varning! Denna enhet kan ha mer än en strömförsörjningsanslutning. Alla anslutningar måste tas bort för att enheten ska bli strömlös.

Backplane Voltage



Warning! Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing. Read the instructions before servicing.

تحذير! يوجد جهد أو طاقة خطيرة على اللوحة الخلفية أثناء تشغيل النظام. توخ الحذر عند إجراء الصيانة. اقرأ التعليمات قبل إجراء الصيانة.

警告！ 当系统运行时，背板上存在危险电压或能量，进行维修时务必小心。维修前请阅读使用说明。

警告！ 系統運作時，背板上存在危險電壓或能量。維修時請小心。維修前請閱讀說明書。

Advarsel! Når systemet er i drift, er farlig spænding eller energi til stede på bagpladen. Vær forsigtig ved servicering. Læs instruktionerne før service.

Waarschuwing! Gevaarlijke spanning of energie is aanwezig op de achterzijde wanneer het systeem in bedrijf is. Wees voorzichtig bij service. Lees de instructies voorafgaand aan service.

Varoitus! Järjestelmän ollessa käynnissä takapaneelissa on vaarallista jännitettä tai energiaa. Ole varovainen huoltotöiden aikana. Lue ohjeet ennen huoltoa.

Attention! Une tension ou de l'énergie dangereuse est présente sur le panneau arrière lorsque le système est en fonctionnement. Soyez prudent lors de l'entretien. Lisez les instructions avant d'effectuer un entretien.

Warnung! Bei eingeschaltetem System liegt an der Backplane gefährliche Spannung oder Energie an. Seien Sie bei Wartungsarbeiten vorsichtig. Lesen Sie vor der Wartung die Anweisungen.

אזהרה! מתח או אנרגיה מסוכנים קיימים בלוח האחורי כאשר המערכת פועלת. יש לנקוט בזהירות בעת ביצוע תחזוקה. קרא את ההוראות לפני ביצוע תחזוקה.

चेतावनी! जब सिस्टम चालू होता है, तो बैकप्लेन पर खतरनाक वोल्टेज या ऊर्जा मौजूद होती है। सर्विसिंग करते समय सावधानी बरतें। सर्विसिंग से पहले निर्देश पढ़ें।

警告! システム稼働中は、危険な電圧または電流がバックプレーン上にかかっています。修理を行う際には注意してください。修理を行う前に取扱説明書をお読みください。

경고! 시스템이 동작 중일 때 후면판(Backplane)에는 위험한 전압이나 에너지가 발생합니다. 서비스 작업 시 주의하십시오. 서비스 작업 전에 지침을 읽으십시오.

Advarsel! Det er farlig spenning eller energi på bakplaten når systemet er i drift. Vær forsiktig ved service. Les instruksjonene før service.

¡Advertencia! Hay voltaje o energía peligrosos presentes en la placa posterior cuando el sistema está en funcionamiento. Tenga cuidado al realizar el mantenimiento. Lea las instrucciones antes de realizar el mantenimiento.

Varning! Farlig spänning eller energi finns på backplane när systemet är i drift. Var försiktig vid service. Läs instruktionerna före service.

Comply with Local and National Electrical Codes



Warning! Installation of the equipment must comply with local and national electrical codes.

تحذير! يجب أن يتوافق تركيب الأجهزة مع لوائح الكهرباء المحلية والوطنية.

警告! 设备安装必须符合本地与本国电气法规。

警告! 設備安裝必須符合本地與本國電氣法規。

Advarsel! Alle lokale og nationale el-regler skal overholdes under montering af udstyret.

Waarschuwing! Bij installatie van de apparatuur moet worden voldaan aan de lokale en nationale elektriciteitsvoorschriften.

Varoitus! Laitteiden asennus on suoritettava paikallisten ja kansallisten sähkömääräysten mukaisesti.

Attention! L'équipement doit être installé conformément aux normes électriques nationales et locales.

Warnung! Die Installation des Geräts muss den lokalen und nationalen elektrotechnischen Vorschriften entsprechen.

אזהרה! התקנת הציוד חייבת להתבצע בהתאם לתקני החשמל המקומיים והארציים.

चेतावनी! उपकरण की इंस्टालेशन स्थानीय और राष्ट्रीय विद्युत कोड के अनुरूप होनी चाहिए।

警告! 機器の取り付けはその地域および国の電気規定に準拠する必要があります。

경고! 현 지역 및 국가의 전기 규정에 따라 장비를 설치해야 합니다.

Advarsel! Installasjon av utstyret må være i samsvar med lokale og nasjonale elektriske forskrifter.

¡Advertencia! La instalacion del equipo debe cumplir con las normas de electricidad locales y nacionales.

Varning! Installation av utrustningen måste följa lokala och nationella elektriska föreskrifter.

Fan Warning



Warning! Hazardous moving parts. Keep away from moving fan blades. The fans might still be turning when you remove the fan assembly from the chassis. Keep fingers, screwdrivers, and other objects away from the openings in the fan assembly's housing.



تحذير! تجنب خطر الأجزاء المتحركة. ابتعد عن شفرات المروحة المتحركة. قد تستمر المراوح في الدوران بعد فك مجموعة المراوح من الهيكل. أبق أصابعك ومفكات البراغي والأغراض الأخرى بعيدة عن الفتحات الموجودة في مبيت مروحة التبريد.

警告！ 危险的活动零部件。请务必与转动的风扇叶片保持距离。从机箱移除风扇装置时，风扇可能仍在转动。小心不要将手指、螺丝起子和其他物品太靠近风扇外壳开口。

警告！ 危险的可移动性零件。请务必與轉動的風扇葉片保持距離。當您從機架移除風扇裝置，風扇可能仍在轉動。小心不要將手指、螺絲起子和其他物品太靠近風扇。

Advarsel! Farlige bevægelige dele. Hold dig væk fra ventilatorblade i bevægelse. Ventilatorerne kan stadig køre, når du tager ventilatorsamlingen af kabinettet. Hold fingre, skruetrækkere og andre genstande væk fra åbningerne i ventilatorkabinettet.

Waarschuwing! Gevaarlijke bewegende onderdelen. Houd voldoende afstand tot de bewegende ventilatorbladen. Het is mogelijk dat de ventilator nog draait tijdens het verwijderen van het ventilatorsamenstel uit het chassis. Houd uw vingers, schroevendraaiers en eventuele andere voorwerpen uit de buurt van de openingen in de ventilatorbehuizing.

Varoitus! Vaaralliset liikkuvat osat. Pysy kaukana liikkuvista tuulettimen siivistä. Tuulettimet saattavat edelleen pyöriä, kun irrotat tuulettimen kokoonpanon kotelosta. Pidä sormet, ruuvimeisselit ja muut esineet poissa tuulettimen kotelon aukkojen läheltä.

Attention! Pieces mobiles dangereuses. Se tenir à l'écart des lames du ventilateur Il est possible que les ventilateurs soient toujours en rotation lorsque vous retirerez le bloc ventilateur du châssis. Prenez garde à ce que doigts, tournevis et autres objets soient éloignés du logement du bloc ventilateur.

Warnung! Gefährliche bewegliche Teile. Halten Sie Abstand von rotierenden Lüfterblättern. Die Lüfter können sich noch drehen, wenn Sie die Lüfterbaugruppe aus dem Chassis entfernen. Halten Sie Finger, Schraubendreher und andere Gegenstände von den Öffnungen des Lüftergehäuses fern.

אזהרה! חלקים נעים מסוכנים. יש להתרחק מלהבי מאוורר נעים. המאווררים עשויים להמשיך להסתובב בעת הסרת מכלול המאוורר מהמארז. יש להרחיק אצבעות, מברגים וחפצים אחרים מהפתחים שבבית מכלול המאוורר.

चेतावनी! खतरनाक चलते हुए भाग। चलते हुए पंखे के ब्लेड से दूर रहें। जब आप चैसिस से पंखे की असेंबली निकालते हैं, तब भी पंखे घूम रहे हो सकते हैं। उंगलियों, स्कूट्राइवर और अन्य वस्तुओं को पंखे की असेंबली के हाउसिंग के छिद्रों से दूर रखें।

警告! 回転部品に注意。運転中は回転部(羽根)に触れないでください。シャーンからファンアセンブリを取り外す際、ファンがまだ回転している可能性があります。ファンアセンブリの開口部に、指、ドライバー、およびその他のものを近づけないで下さい。

경고! 움직이는 위험한 부품. 회전하는 송풍 날개에 접근하지 마세요. 새시로부터 팬 조립품을 제거할 때 팬은 여전히 회전하고 있을 수 있습니다. 팬 조립품 외관의 열려있는 부분들로부터 손가락 및 스크류드라이버, 다른 물체들이 가까이 하지 않도록 배치해 주십시오.

Advarsel! Farlige bevegelige deler. Hold deg unna vifteblader i fart. Viftene kan fortsatt gå rundt når du fjerner vifteenheten fra kabinettet. Hold fingre, skrutrekkere og andre gjenstander unna åpningene i viftehuset.

¡Advertencia! Riesgo de piezas móviles. Mantener alejado de las aspas del ventilador. Los ventiladores podran dar vuelta cuando usted quite el montaje del ventilador del chasis. Mantenga los dedos, los destornilladores y todos los objetos lejos de las aberturas del ventilador.

Varning! Farliga rörliga delar. Håll dig borta från rörliga fläktblad. Fläktarna kan fortfarande snurra när du tar bort fläktenheten från chassit. Håll fingrar, skruvmejslar och andra föremål borta från öppningarna i fläktenhetens hölje.

Connection to Earth



Warning! Equipment shall be connected to an Earth mains socket-outlet.

تحذير! يجب توصيل الأجهزة بمقبس كهربائي أرضي.

警告！设备应连接到接地电源插座。

警告！應將設備連接至接地電源插座。

Advarsel! Dette udstyr skal sluttes til en jordforbundet stikkontakt.

Waarschuwing! De apparatuur moet worden aangesloten op een geaard netstopcontact.

Varoitus! Laitteet on kytkettävä maadoitettuun pistorasiaan.

Attention! L'équipement doit être connecté à une prise de courant avec mise à la terre.

Warnung! Das Gerät muss an eine geerdete Netzsteckdose angeschlossen werden.

אזהרה! יש לחבר את הציוד לשקע חשמל עם הארקה.

चेतावनी! उपकरण को एक अर्थ मेन्स सॉकेट-आउटलेट से जोड़ा जाना चाहिए।

警告! 機器は、接地主電源コンセントに接続するものとします。

경고! 장비는 접지된 전원 콘센트에 연결해야 합니다.

Advarsel! Utstyret skal kobles til en jordet stikkontakt.

¡Advertencia! El equipo deberá conectarse a una toma de corriente con conexión a tierra.

Varning! Utrustningen ska vara ansluten till ett jordat eluttag.

DC Power Supply



Warning! When stranded wiring is required, use approved wiring terminations, such as closed-loop or spade-type with upturned lugs. These terminations should be the appropriate size for the wires and should securely clamp both the insulation and the conductor.

تحذير! عند الحاجة إلى توصيل أسلاك مجدولة استخدم نهايات معتمدة، مثل الحلقة المغلقة أو نوع شوكي مع أطراف مقلوبة لأعلى. ينبغي أن تكون هذه النهايات بحجم مناسب للأسلاك، ويجب أن تثبت العازل والموصل بإحكام.

警告! 需要使用绞线连接时, 请使用经认可的连接端子, 如闭环端子或具有接线柱的铲形端子。这些端子的大小应适合线缆, 并且可以将绝缘部分和导体夹紧固定。

警告! 需要多股佈線時, 請使用經核准的佈線終端, 例如閉環或鏟型接線片。這些終端的大小應適合線路, 並且應牢固夾緊絕緣體和導體。

Advarsel! Hvis der skal bruges en flertrådet leder, skal der anvendes godkendte kabelsko, såsom ringkabelsko eller gaffelkabelsko med opadbøjede tunger. Disse kabelsko skal have korrekt størrelse til lederne og skal fastholde både isoleringen og lederen sikkert.

Waarschuwing! Wanneer gevlochten bedrading vereist is, moet u goedgekeurde bedradingsafsluitingen gebruiken, zoals gesloten lus of plat met omgekeerde kabelschoenen. Deze afsluitingen moeten de juiste maat hebben voor de draden en moeten zowel de isolatie als de geleider stevig klemmen.

Varoitus! Kun tarvitaan säikeinen johdotus, käytä hyväksytyjä johdotuksen päätteitä, kuten suljettu silmukka tai haarukakärkinen, jossa on ylöspäin kääntyneet korvakkeet. Näiden liittimien tulee olla sopivan kokoisia johtimille ja niiden tulee kiinnittää tiukasti sekä eriste että johdin.

Attention! Lorsqu'un câblage toronné est nécessaire, utilisez des terminaisons de câblage approuvées, telles que à boucle fermée ou de type fourche avec des cosses retournées. Ces terminaisons doivent être de taille appropriée pour les fils et doivent serrer fermement les fils d'isolation et le conducteur.

Warnung! Wenn Litzenverdrahtung erforderlich ist, verwenden Sie zugelassene Verdrahtungsabschlüsse, z. B. geschlossene Ringkabelschuhe oder Gabelkabelschuhe mit nach oben gerichteten Laschen. Diese Abschlüsse müssen die geeignete Größe für die Leitungen haben und sowohl Isolierung als auch Leiter sicher klemmen.

אזהרה! כאשר נדרש חיווט רב-גידי, השתמש בסיומות חיווט מאושרות, כגון לולאה סגורה או מסוג כף (Spade) עם זיזים מכופפים כלפי מעלה. סיומות אלה צריכות להיות בגודל המתאים לחוטים, ועליהן להדק היטב את הבידוד ואת המוליך.

चेतावनी! जब स्ट्रैंडेड वायरिंग की आवश्यकता हो, तो अनुमोदित वायरिंग टर्मिनेशन का उपयोग करें, जैसे कि क्लोज्ड-लूप या ऊपर की ओर मुड़े हुए लग्स वाले स्पेड-टाइप। ये टर्मिनेशन तारों के लिए उपयुक्त आकार के होने चाहिए और इंसुलेशन और कंडक्टर दोनों को सुरक्षित रूप से जकड़ने चाहिए।

警告! より線配線が必要な場合は、承認済みの配線終端(上向きの端子を備えたクローズループ型{2}またはU字型など)を使用してください。ワイヤーに適したサイズで、絶縁体および導体が両方ともしっかりとクランプされている終端でなければなりません。

경고! 꼬인 배선이 요구될 때에는 폐회로나 돌출부가 위로 튀어 나온 Spade형태의 승인된 배선 터미네이션들을 사용하세요. 이 터미네이션들은 배선들을 위해 적절한 크기여야 하고, 절연체와 도체 모두를 고정시킬 수 있어야 합니다.

Advarsel! Når man må bruke flertrådet kabling, brukes godkjente ledningstermineringer, for eksempel lukket sløyfe eller spadetype med oppoverbøyde kabelsko. Disse termineringene skal ha riktig størrelse for ledningene og skal klemme både isolasjonen og lederen sikkert.

¡Advertencia! Cuando se requiere cableado trenzado, utilice terminaciones de cableado aprobadas, como bucle cerrado o tipo horquilla con terminales hacia arriba. Estas terminaciones deben tener el tamaño adecuado para los cables y deben sujetar de forma segura tanto el aislamiento como el conductor.

Varning! När fintrådiga kablar krävs ska godkända kabelavslutningar användas, t.ex. sluten slinga eller gaffelkabelsko med uppvikta flikar. Dessa avslutningar ska vara av lämplig storlek för ledarna och ska klämma fast både isoleringen och ledaren ordentligt.

Power Disconnection Warning



Warning! The system must be disconnected from all sources of power and the power cord removed from the power supply module(s) before accessing the chassis interior to install or remove system components (except for hot-swappable components).

تحذير! يجب فصل النظام عن جميع مصادر الطاقة، وإزالة سلك الطاقة من وحدة/وحدات إمداد الطاقة قبل الدخول إلى الجزء الداخلي من الهيكل لت تركيب أو فك مكونات النظام (باستثناء المكونات القابلة للاستبدال السريع).

警告！在打开机箱并安装或移除内部器件(热插拔器件除外)前，必须将系统完全断电，并移除电源线。

警告！在您打開機殼安裝或移除內部元件(熱插拔元件除外)前，必須將系統完全斷電，並移除電源線。

Advarsel! Systemet skal afbrydes fra alle strømkilder, og strømkablet skal fjernes fra strømforsyningsmodulerne, før der gives adgang til kabinettet for at montere eller fjerne systemkomponenter (undtagen hot-swap-komponenter).

Waarschuwing! Het systeem moet worden losgekoppeld van alle voedingen en het stroomsnoer moet uit de voedingsmodule(s) worden gehaald voorafgaand aan toegang tot de binnenkant van het chassis voor installeren of verwijderen van systeemcomponenten (behalve hot-swap componenten).

Varoitus! Järjestelmä on irrotettava kaikista virtalähteistä ja virtajohto on irrotettava virtalähdemoduulista (moduuleista) ennen kotelon sisälle pääsyä järjestelmän komponenttien asentamista tai poistamista varten (lukuun ottamatta hot-swap-komponentteja).

Attention! Le système doit être déconnecté de toutes les sources d'alimentation et le cordon d'alimentation doit être débranché du/des modules d'alimentation avant d'accéder à l'intérieur du châssis pour installer ou retirer des composants du système (à l'exception des composants remplaçables à chaud).

Warnung! Das System muss von allen Stromquellen getrennt und das Netzkabel von den Netzteilmodulen entfernt werden, bevor auf den Innenraum des Chassis zugegriffen wird, um Systemkomponenten zu installieren oder zu entfernen (ausgenommen Hot-Swap-Komponenten).

אזהרה! יש לנתק את המערכת מכל מקורות הכוח ולהסיר את כבל החשמל ממודולי/אספקת החשמל לפני הגישה לחלק הפנימי של המארז לצורך התקנה או הסרה של רכיבי המערכת (למעט רכיבים הניתנים להחלפה חמה).

चेतावनी! सिस्टम के घटकों को इंस्टॉल करने या निकालने (हॉट-स्वैप घटकों को छोड़कर) के लिए चैसिस के आंतरिक भाग तक पहुँचने से पहले, सिस्टम को बिजली के सभी स्रोतों से डिस्कनेक्ट किया जाना चाहिए और बिजली की आपूर्ति मॉड्यूल से पावर कॉर्ड को निकाल दिया जाना चाहिए।

警告! システムコンポーネント(ホットスワップコンポーネントを除く)の取り付けまたは取り外しを行うために、シャーシ内部にアクセスするには、システムの電源はすべてのソースから切断され、電源コードは電源モジュールから取り外す必要があります。

경고! (핫스왑 구성품을 제외하고) 시스템에 부품들을 장착하거나 제거하기 위해서는 샤페 내부에 접근하기 전에 반드시 전원 공급장치로부터 연결되어있는 모든 전원과 전기코드를 분리해 주어야 합니다.

Advarsel! Systemet må kobles fra alle strømkilder, og strømledningen må fjernes fra strømforsyningsmodulen (e) før man går inn i kabinettet for å installere eller fjerne systemkomponenter (unntatt komponenter som kan byttes ut under drift).

¡Advertencia! El sistema debe estar desconectado de todas las fuentes de energía y el cable de alimentación debe retirarse de los módulos de fuente de alimentación antes de acceder al interior del chasis para instalar o quitar componentes del sistema (excepto los componentes reemplazables en caliente).

Varning! Systemet måste vara fränkopplat från alla strömkällor och strömsladden måste vara borttagen från strömförsörjningsmodulerna innan du öppnar chassit för att installera eller ta bort systemkomponenter (med undantag för hot-swap-komponenter).

Hazardous Voltage or Energy Present on DC Power Terminals



Warning! Hazardous voltage or energy may be present on DC power terminals. Always replace cover when terminals are not in service. Be sure uninsulated conductors are not accessible when cover is in place.

تحذير! قد توجد فولتية أو طاقة خطيرة على أطراف توصيل التيار المستمر. احرص دائماً على إعادة الغطاء عندما لا تكون الأجهزة الطرفية قيد الاستخدام. تأكد من عدم إمكانية الوصول إلى الموصلات غير المعزولة عند وضع الغطاء.

警告! 直流电源端子可能会产生危险电压或能量。端子不使用时, 务必合上防护盖。合上后, 请确保导体未绝缘部分不会被接触到。

警告! 直流電源終端可能產生危險的電壓或能量。終端不使用时, 請務必蓋上機蓋。當蓋上機蓋, 確認不絕緣導體無法使用。

Advarsel! Der kan være farlig spænding eller energi på jævnstrømsterminaler (DC). Sæt altid dækslet på igen, når terminalerne ikke er i brug. Sørg for, at uisolerede ledere ikke kan tilgås, når dækslet er monteret.

Waarschuwing! Gevaarlijke spanning of energie kan aanwezig zijn op DC-voedingsklemmen. Plaats de kap altijd terug wanneer klemmen niet in bedrijf zijn. Zorg ervoor dat niet-geïsoleerde geleiders niet toegankelijk zijn wanneer de kap is geplaatst.

Varoitus! DC-virtaliittimissä voi olla vaarallista jännitettä tai energiaa. Aseta kansi aina paikalleen, kun liittimet eivät ole käytössä. Varmista, että eristämättömät johtimet eivät ole käytettävissä, kun kansi on paikoillaan.

Attention! Une tension ou une énergie dangereuse peut être présente sur les bornes d'alimentation CC. Remettez toujours le couvercle en place lorsque les bornes ne sont pas utilisées. Assurez-vous que les conducteurs non isolés ne sont pas accessibles lorsque le couvercle est installé.

Warnung! An Gleichstrom-Netzanschlussklemmen kann gefährliche Spannung oder Energie anliegen. Bringen Sie die Abdeckung immer an, wenn die Klemmen nicht in Betrieb sind. Stellen Sie sicher, dass bei angebrachter Abdeckung keine nicht isolierten, stromführenden Leiter zugänglich sind.

אזהרה! מתח או אנרגיה מסוכנים עלולים להיות נוכחים בהדקי מתח DC. יש להחזיר תמיד את הכיסוי למקומו כאשר ההדקים אינם בשימוש. יש לוודא שמוליכים לא מבודדים אינם נגישים כאשר הכיסוי מונח במקומו.

चेतावनी! DC पावर टर्मिनलों पर खतरनाक वोल्टेज या ऊर्जा मौजूद हो सकती है। जब टर्मिनल उपयोग में न हों तो हमेशा कवर को वापस लगा दें। सुनिश्चित करें कि कवर लगे होने पर गैर-इंसुलेटेड कंडक्टरों तक पहुँच न हो।

警告! DC電源端子には危険な電圧やエネルギーが発生している可能性があります。端子を使用しないときは、必ずカバーを元に戻してください。カバーを取り付けた状態では、絶縁されていない導体に手が届かないことを確認してください。

경고! DC전원 단자들에 위험한 전압이나 에너지가 발생할 수 있습니다. 단말기들을 운영하지 않을 때에는 덮개로 다시 덮어 놓아 주십시오. 덮개가 제자리에 있어야만 절연되지 않은 도체들의 접근을 막을 수 있습니다.

Advarsel! Det kan være farlig spenning eller energi på likestrømsterminalene. Sett alltid på dekselet når terminalene ikke er i bruk. Sørg for at uisolerte ledere ikke er tilgjengelige når dekselet er på plass.

¡Advertencia! Puede haber voltaje o energía peligrosos presentes en los terminales de alimentación de CC. Vuelva a colocar siempre la cubierta cuando los terminales no estén en mantenimiento. Asegúrese de que los conductores no aislados no sean accesibles cuando la cubierta esté en su lugar.

Varning! Farlig spänning eller energi kan finnas på likströmsterminalerna. Sätt alltid tillbaka kåpan när terminalerna inte är i bruk. Se till att oisolerade ledare inte är åtkomliga när kåpan är på plats.

Product Disposal



Warning! Ultimate disposal of this product should be handled according to all national laws and regulations.

تحذير! يجب التخلص النهائي من هذا المنتج وفقاً لجميع القوانين واللوائح الوطنية.

警告！本产品的废弃处理应根据所有国家的法律和规章进行。

警告！本產品的廢棄處理應根據所有國家的法律和規章進行。

Advarsel! Dette produkt skal bortskaffes i henhold til alle nationale love og regler.

Waarschuwing! De uiteindelijke verwijdering van dit product dient te geschieden in overeenstemming met alle nationale wetten en voorschriften.

Varoitus! Tämän tuotteen lopullinen hävittäminen on suoritettava kaikkien kansallisten lakien ja määräysten mukaisesti.

Attention! La mise au rebut ou le recyclage de ce produit sont généralement soumis à des lois et/ou directives de respect de l'environnement. Renseignez-vous auprès de l'organisme compétent.

Warnung! Die endgültige Entsorgung dieses Produkts muss gemäß allen nationalen Gesetzen und Vorschriften erfolgen.

אזהרה! סילוק סופי של מוצר זה חייב להתבצע בהתאם לכל החוקים והתקנות הלאומיים.

चेतावनी! इस उत्पाद का अंतिम निपटान सभी राष्ट्रीय कानूनों और नियमों के अनुसार किया जाना चाहिए।

警告! この製品を廃棄処分する場合、国の関係する全ての法律・条例に従い処理する必要があります。

경고! 이 제품은 해당 국가의 관련 법규 및 규정에 따라 폐기되어야 합니다.

Advarsel! Når produktet til slutt skal kasseres, må det håndteres i henhold til alle nasjonale lover og forskrifter.

¡Advertencia! Al deshacerse por completo de este producto debe seguir todas las leyes y reglamentos nacionales.

Varning! Slutgiltigt bortskaffande av denna produkt ska ske i enlighet med alla nationella lagar och förordningar.

Appendix C:

System Specifications

Processors

Single Intel® Core™ Ultra 9/7/5 (Series 2) processor (in a Socket LGA-1851), supports up to 65 W TDP CPUs (air cooled)

BIOS

AMI 32 MB UEFI

Memory

Supports up to 96 GB of ECC or Non-ECC DDR5 SODIMM memory with speeds of up to 6400 MT/s with U9/U7 processor in two slots

Storage Drives

One M.2 PCIe 5.0 x4 NVMe slot (M-key 2280)

One internal fixed 2.5" SATA drive bay (SATA support required for additional storage controllers/cables)

PCI Expansion Slots

One M.2 PCIe 4.0 x2 slot (B-key 3052)

One PCIe 5.0 x16 (in x16) low-profile slot (additional parts required; see [Optional Parts](#) for details)

Input/Output

One RJ45 1 GbE dedicated BMC LAN port

Two RJ45 10 GbE LAN ports (Intel® X550)

Two RJ45 2.5 GbE LAN ports (Intel® I226-LM)

Four USB 3.2 Gen2 Type-A ports

One optional VGA port

One DisplayPort

One HDMI port

One TPM header

One TPM Onboard/port 80

Motherboard

X14SAV-TLN4F: 9" x 7.25" / 22.86 x 18.42 mm (W x L)

Chassis

CSE-E300: Mini-1U 10.43" x 1.69" x 8.89" / 264.8 x 43 x 8.89 mm (W x H x D)

System Cooling

One CPU heatsink with 80 x 15 mm fan

Two 4-pin PWM 40 x 40 x 28 mm fans

Power Supply

Optional 180 W or 240 W DC power adapter

Model: MCP-250-10133-0N

AC Input Voltages: 100-240 V, 2.4 A

Rated Input Frequency: 50–60 Hz

Rated Output Power: 180 W

Rated DC Output Voltages: 12 V, 15 A

Optional 240 W DC Power Adapter

Model: MCP-250-10139-0N

AC Input: 100-240 V, 3.5 A

Rated Input Frequency: 50–60 Hz

Rated Output power: 240 W

Rated DC Output Voltages: 12 V, 20 A

Operating Environment

Operating Temperature: 0°C to 40°C (32°F to 104°F)

Non-operating Temperature: -40°C to 70°C (-40°F to 158°F)

Operating Relative Humidity: 8% to 90% (non-condensing)

Non-operating Relative Humidity: 5% to 95% (non-condensing)

Regulatory Compliance

FCC, ICES, CE, VCCI, RCM, UKCA, NRTL, CB, BSMI

Certified Safety Models

Compliant with UL or CSA: E300-18, E300-A18X13 (for 180 W), and E300-24, E300-A24X13 (for 240 W).

Applied Directives, Standards

EMC/EMI: 2014/30/EU (EMC Directive)

Electromagnetic Compatibility Regulations 2016

FCC Part 15

ICES-003

VCCI-CISPR 32

AS/NZS CISPR 32

BS/EN55032

BS/EN55035

CISPR 32

CISPR 35

BS/EN 61000-3-2

BS/EN 61000-3-3

BS/EN 61000-4-2

BS/EN 61000-4-3

BS/EN 61000-4-4

BS/EN 61000-4-5

BS/EN 61000-4-6

BS/EN 61000-4-8

BS/EN 61000-4-11

Environment:

2011/65/EU (RoHS Directive)

EC 1907/2006 (REACH)

2012/19/EU (WEEE Directive)

California Proposition 65

Product Safety: 2014/35/EU (LVD Directive)

UL/CSA 62368-1 (USA and Canada)

Electrical Equipment (Safety) Regulations 2016

IEC/BS/EN 62368-1

Perchlorate Warning

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate"