

ENGLISH



VISTA 2

USER MANUAL

CONTENTS

WELCOME

In The Box..... **2**

Product Overview..... **3**

Fit **4**

Charging **5**

 Earbuds **5**

 Case **6**

 Wireless Charging..... **7**

Pairing **8**

DETAILED INSTRUCTIONS

Controls **9**

 On/Off..... **9**

 Music & Calls **10**

 Auto Pause **11**

 Case **12**

The Jaybird App..... **13**

 Overview..... **13**

 Dashboard..... **14**

 EQ Customization **15**

Smartwatches..... **16**

Connection Tips **17**

Troubleshooting..... **18**

Specifications **19**

Warranty, Warnings & Safety **20**

Care & Maintenance **21**

JAYBIRD VISTA 2

For detailed video instructions please visit jaybirdsport.com/support/vista2

SURROUNDSense WITH ANC

Amplify ambient sounds for safety or stay focused with Active Noise Cancellation

PREMIUM SOUND

6mm milled driver with fully adjustable equalizer using the Jaybird app

24 HOUR BATTERY

Up to 8 hours in earbuds, 5 min = 1 hr fast charge, wireless charging case

EARTHProof DURABILITY

IP68 waterproof earbuds with military-grade construction, IP54 weatherproof case


SPORT FIT

3 sizes of interchangeable eargels to find the most secure and comfortable fit

CLEAR CALL

4 mics with WindDefense fabric for high quality calls, voice assistant enabled

IN THE BOX




True Wireless Earbuds



Charging Case




USB Charging Cable



Silicone Eargels (Size 1 / 2 / 3)

PRODUCT OVERVIEW




For an assisted fit set up, please download the Jaybird App or visit www.jaybirdsport.com/support/vista2

- A** Your Vista 2 earbuds are fitted with size 2 (medium) eargels out of the box. They are marked 'L' and 'R' for the left and right ear.

- B** Place the earbuds firmly within your ears as shown in the illustration.

- C** If your earbuds are not comfortable, feel loose, or too tight try alternative sized eargels (size 1 or size 3).

Be patient, it may take some time to get the perfect fit.



It is quite common to use different sized eargels in each ear.

CHARGING

5


EARBUDS

Jaybird Vista 2 offers you up to 8 hours of playback when fully charged. The charging case gives you two additional recharge cycles or 16 hours additional playback.

Your earbuds will start charging as soon as you place them into the charging case and close the lid. The charging case LEDs will indicate the charging status:

Left / Right LED is pulsing white = Earbud is charging
Left / Right LED is solid white = Earbud is fully charged

A 5 minute charge gives you up to 1 hour of playback.
A full charge of the earbuds can take up to 2 hours if charging them from a discharged state.




CHARGING

CASE

It takes about 3 hours from a fully discharged state to charge your case.

With the case closed, connect the USB-C charging cable to the front of the charging case. The case LED will indicate the charging status:

Central LED is pulsing white = The case is charging
Central LED is solid white = The case is fully charged



WIRELESS CHARGING

7


CASE

It takes about 4 hours from a fully discharged state to charge your case.

With the case closed, place the case on the wireless charger mat with the LED light on the front of the case pointing towards you.

The case LED will indicate the charging status:

Central LED is pulsing white = The case is charging
Central LED is solid white = The case is fully charged




* Wireless charging pad is not included in the box. Use any wireless charger that functions as a Qi wireless charger.

PAIRING

To pair to a Bluetooth audio device follow the steps below

- A** Place both earbuds into the charging case and close the lid.



- B** Open the charging case and press and hold the case button until the case LED starts blinking white.

- C** On your Bluetooth audio device, go to Bluetooth settings and select 'Jaybird Vista 2'. Once connected, the charging case LED will turn off.



CONTROLS


ON/OFF

AUTO POWER OFF

Placing your earbuds into the charging case will automatically turn them off.

AUTO POWER ON

Removing your earbuds from the charging case will automatically turn them on.




USING CONTROLS

In the Jaybird app, you can customize the functionality of the multi-function buttons to power your earbuds ON and OFF.

CONTROLS

MUSIC/CALLS



Each earbud has:
One mechanical button
One accelerometer based interaction (double tap)

- 
SINGLE PRESS
- 
DOUBLE PRESS
- 
PRESS & HOLD
- 
DOUBLE TAP

PLAYING MUSIC	CALLS
Play / Pause <small>Customizable</small>	Accept / Hang Up Call
Next Song (R) Previous Song (L) <small>Customizable</small>	Reject Call
Volume + (R) Volume - (L) <small>Customizable</small>	Volume + (R) Volume - (L)
SurroundSense Switch <small>Customizable</small>	



*You can customize each of the multi-function button functions within the Jaybird App.


CONTROLS

11

AUTO PAUSE MUSIC

To pause the music, remove one of the earbuds from your ear.


To resume listening to music, place the earbud back into your ear.






Auto pause music settings can be disabled using Jaybird app

CONTROLS

CASE



	LEFT BUD	CASE	RIGHT BUD
Charging	 Pulsing White	 Pulsing White	 Pulsing White
Charged	 Solid White	 Solid White	 Solid White
Battery Low		 Solid Red	
Pairing Mode		 Blinking White	

THE JAYBIRD APP


OVERVIEW

The Jaybird App lets you do the following:

- Customize the sound profile of your Vista 2 earbuds.
- Change the language for your earbuds’ voice prompts.
- Customize the buttons functionality of your Vista 2 earbuds.
- Select SurroundSense and ANC.
- Set up the ‘Find Your Buds’ feature to track the location of your earbuds.
- Use the ‘Find Your Fit’ feature to find the right fit for your earbuds and charging case.
- Update your earbuds and charging case when new features and improvements are available.



Your new sound settings are saved on your earbuds, so you can take your custom sound with you no matter where you go with any device you use.



THE JAYBIRD APP

DASHBOARD

DEVICE

See your connected device and battery status.

SOUND

Customize your sound settings. Changes are saved to your Vista Pro earbuds.

SURROUNDSENSE & ANC


Adjust the settings of each mode.

FIND MY BUDS


Lost one of your earbuds? Find out where you left it in real time.

Jaybird Vista 2
Connected


Left




65%




Right




65%



Case




65%



Flat Acoustic Deep bass Discover

Tap here to customize the equalizer



Bass Mid Treble

Sound Management

ANC
Active noise canceling ☒


SurroundSense
Let ambient noise in ☐

Off
Saves battery life ☐

Find my buds


Find my buds

Settings




Last updated yesterday at 18:00


General




Button Controls
Adjust single press and more




Voice assistant
Set up voice assistant




More settings
Set language, auto off and much more



Support
Get support and detailed info



Shop Jaybird
Find accessories for your Vista 2





Jaybird stories
Keep up with the latest from Jaybird

BUTTON CONTROLS
Customize your earbuds' controls.

SETTINGS
Adjust your settings on your earbuds.

TUTORIALS
Find tips on how to optimize the use of your earbuds.

EQ CUSTOMIZATION




SAVE
Save your new preset to your dashboard for easy access to all your favorite sound settings.

HISTORY
Track through a history of your changes.


SMARTWATCHES

With the right smartwatch you can leave your phone at home. Just sync music to your smartwatch and pair Vista 2 to your smartwatch. Use your smartwatch user manual for instructions on how to pair a Bluetooth device.


Apple WatchOS




Samsung



Android Wear




Garmin



CONNECTION TIPS

Both right & left earbuds can connect to your audio device. The earbuds will automatically switch to get the best connection to the audio device.

For best Bluetooth performance, try to reduce the distance between your earbuds and your audio device. Try to have your audio device in an arm band, or in a belt pocket.




TROUBLESHOOTING


Soft reset: If your earbuds are not responding, place your Vista 2 in the charging case, close the lid and plug the case into charge. This will turn your earbuds off and perform a soft reset.

Factory reset: If that does not resolve your problem we recommend resetting your earbuds to their original factory settings. Before starting this process please **FORGET** or **REMOVE** your Vista 2 device from the Bluetooth menu on all your connected audio devices.


A Place both earbuds into the charging case and close the lid.



B Open the charging case and **press & hold** the **case button** until the case LED starts **blinking white**.



C While the charging case LED is **blinking white**, press the **button on the case twice**.




D The LED will **blink pink**. Once it stops close the case.

Your earbuds are reset and ready to pair. Go to your audio device Bluetooth menu and select “**Jaybird Vista 2**” to pair again.

Hard reset: If the battery has enough charge but the device does not turn on and you don’t hear any tones, press and hold the earbud button for 20 seconds and then release. Put the earbud back in the case, wait for 5 seconds, then take the earbud out of the case.

SPECIFICATIONS

Bluetooth Version	5.0
Codec	SBC, AAC
Profile	Handsfree, A2DP, AVCRP, SPP
Effective Range	10 meters (30 feet)
Play Time	8 Hrs*
Power	Bluetooth headset: 5.0V  , 1A
Charging Time	2 Hrs
Quick Charge	5 Min = 1 Hr play time
Dimensions	20.3 (W) x 15.3 (D) x 17.9(H) mm earbud size / 74 (W) x 36.4 (D) x 24.5(H) mm case size
Weight	Earbuds: Approx 4.8 g (without eargels). Case: approx. 32g (without earbuds)

*Playtime and standby time may vary due to usage conditions. Adding additional bass to your sound profile through the Jaybird app or using SurroundSense or ANC will reduce play time.

Full warranty, care & maintenance details at:
jaybirdsport.com/warranty

WARNING: Due to the isolating characteristics of these earbuds do not use while driving, riding a bike or where vehicular traffic is present, or in any other activity where failure to hear surrounding sounds could be dangerous. Use of these earbuds at excessive volumes may cause permanent hearing damage. Always turn the volume down before use. Take caution in regards to inserting objects into ear canal, use at own risk. Do not wear the device while it is connected to a power source driven from main 110V or 220V lines.

WATERPROOF

Your Jaybird Vista 2 earbuds feature an IP68 dust and waterproof rating. Vista 2 earbuds are designed to handle rain, mud and outdoor adventures.

Jaybird earbuds are not designed for swimming, showering or exposure to pool or ocean water. In case of exposure to salted or chlorinated water, rinse the earbuds gently with fresh water and air dry before use. The Vista 2 charging case features an IP54 rating, it is designed to handle rain and splashing but not submersion into water. Please ensure your earbuds are completely dry before charging.

EARGEL CLEANING

Keeping your Jaybird earbuds eargels clean is essential for safe, hygienic use.

IMPORTANT: DO NOT attempt to clean the eartips without first removing them from the earbuds.

1. Firmly grip the eargel with one hand and the earbud with the other. Carefully remove the eargel from the earbud.
2. Use warm water and mild soap on a damp cloth to remove dirt and earwax from the eargel. Do NOT use harsh cleaning agents.
3. Rinse and completely dry your eargel before placing them back on your earbuds.
4. Carefully push the eargel back onto the earbuds.



LISTEN RESPONSIBLY

Avoid excessive volume levels and prolonged periods of listening. Prolonged listening at excessive volume levels may cause permanent hearing disability.

Do not use around road traffic.

CARE AND MAINTENANCE

Clean eargels regularly of dirt and wax buildup. To clean, remove eargels from earbuds, then gently wipe away dust and oil with a dry cloth, and/or use warm water and mild soap to remove buildup. Rinse and completely dry before reattaching.

Before charging, ensure earbuds and charge case contact are completely dry of sweat and water.

Video instructions at jaybirdsport.com/support/vista2

Copyright 2021 Logitech. Logitech, Jaybird and the Jaybird logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the US and other countries. Apple, the Apple logo, iPhone, and iPad are trademarks of Apple, Inc., registered in the U.S. and other countries and regions. Amazon, Alexa, and all related logos are trademarks of amazon.com, inc., or its affiliates. Other trademarks and trade names are those of their respective owners. Any use of such marks by Logitech is under license or with permission.