





QUICK GUIDE




- 1** Webcam/Windows LED
Internal Microphone
- 2** Touch Screen Monitor
- 3** Power Key/Power LED
- 4** Fingerprint Sensor
- 5** Touchpad
- 6** Keyboard
- 7** Battery Lid
- 8** Caps Lock
- 9** BMSI protection lock
- 10** USB 3.2 Gen 1 Port (Type-C)
- 11** Audio Port Connectors
- 12** MicroSD Card Slots
- 13** Card Reader
- 14** Thunderbolt (Type-C)




- 1** Connect the AC Power
- 2** Press the Power Button
- 3** Power On the Notebook

- I- Connect the AC Power**
Be sure to connect the AC power adapter to the notebook and use the AC power when using the notebook for the first time since some ports may require the AC/DC adapter to be connected in order to power on the notebook safely and properly.
- II- Power On the Notebook**
When the AC power is connected, press the power button to turn the notebook on.



- 1** Webcam/Windows LED
Internal Microphone
- 2** Touch Screen Monitor
- 3** Power Key/Power LED
- 4** Fingerprint Sensor
- 5** Touchpad
- 6** Keyboard
- 7** Battery Lid
- 8** Caps Lock
- 9** BMSI protection lock
- 10** USB 3.2 Gen 1 Port (Type-C)
- 11** Audio Port Connectors
- 12** MicroSD Card Slots
- 13** Card Reader
- 14** Thunderbolt (Type-C)



- 1** Connect the AC Power
- 2** Press the Power Button
- 3** Power On the Notebook

Общие сведения об устройстве

1. Веб-камера, интегрированная веб-камера
2. Сенсорный экран
3. Клавиша питания/индикатор питания
4. Сенсорный датчик отпечатков пальцев
5. Сенсорный датчик отпечатков пальцев
6. Клавиатура
7. Аккумулятор

8. Клавиша Caps Lock
9. БMSI защита замка
10. USB 3.2 Gen 2 Port (Type-C)
11. Аудио Порт Коннекторы
12. MicroSD Карты
13. Кард Ридер
14. Thunderbolt (Type-C)

15. Веб-камера/LED Микрофон
16. Сенсорный экран
17. Клавиша питания/Power LED
18. Сенсорный датчик отпечатков пальцев
19. Сенсорный датчик отпечатков пальцев
20. Клавиатура
21. Аккумулятор

22. Клавиша Caps Lock
23. BMSI защита замка
24. USB 3.2 Gen 2 Port (Type-C)
25. Аудио Порт Коннекторы
26. MicroSD Карты
27. Кард Ридер
28. Thunderbolt (Type-C)

Русский

Общие сведения об устройстве

1. Веб-камера, интегрированная веб-камера
2. Сенсорный экран
3. Клавиша питания/индикатор питания
4. Сенсорный датчик отпечатков пальцев
5. Сенсорный датчик отпечатков пальцев
6. Клавиатура
7. Аккумулятор

8. Клавиша Caps Lock
9. BMSI защита замка
10. USB 3.2 Gen 2 Port (Type-C)
11. Аудио Порт Коннекторы
12. MicroSD Карты
13. Кард Ридер
14. Thunderbolt (Type-C)

English

Product Overview (for reference only)

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 1 Port
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Norsk

Produktoversikt

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 1 Port
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Suomi

Tuotekuvaus

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 1 Port
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Deutsch

Produktübersicht (dient nur als Referenz)

1. Webcam/Windows LED Mikrophon
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerabdruckscanner
5. Touchpad
6. Tastatur
7. Akkubatterie
8. Caps Lock
9. BMSI Eingabeschutz
10. USB 3.2 Gen 2 Port Anschluss (Type-C)
11. Multimediale Audioanschlüsse
12. MicroSD-Kartensteckplätze
13. Thunderbolt (Type-C)

Français

Vue ouverte (dient nur als Referenz)

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Finlandi

Produktöversikt

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Dansk

Produktoversigt

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Latviski

Produkta pārskats

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Lietuvių

Produko apžvalga

1. Webcam/Windows LED mikrofonas
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerabdruckscanner
5. Touchpad
6. Tastatur
7. Akkubatterie
8. Caps Lock
9. BMSI Eingabeschutz
10. USB 3.2 Gen 2 Port Anschluss (Type-C)
11. Multimediale Audioanschlüsse
12. MicroSD-Kartensteckplätze
13. Thunderbolt (Type-C)

Eλληνικό

Σύντομη προσιτοποίηση προϊόντος

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Svenska

Produktöversikt

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Português

Visão geral do produto

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Nederlandse

Productoverzicht

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Latviski

Produkta pārskats

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Eλληνικό

Σύντομη προσιτοποίηση προϊόντος

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Svenska

Produktöversikt

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Português

Visão geral do produto

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)

Nederlandse

Productoverzicht

1. Webcam/Windows LED
2. Touch Screen Monitor
3. Power Key/Power LED
4. Fingerprint Sensor
5. Touchpad
6. Keyboard
7. Battery Lid
8. Caps Lock
9. BMSI protection lock
10. USB 3.2 Gen 2 Port (Type-C)
11. Audio Port Connectors
12. MicroSD Card Slots
13. Card Reader
14. Thunderbolt (Type-C)