



Protective Case with Built-In 360 Degree Rotatable Grip Kickstand & Pen Slot


For Samsung Galaxy Tab S7

PAD-PCGKS7

INSTRUCTION - MANUAL



Features



Impact case to protect your iPad.

360° Rotation


Adjustable strap

Foldable stand


Latch designed to provide maximum safety

Installations


If your iPad has a previously installed screen protector, please remove it before continuing.




Remove the external silicone sleeve by peeling it away from the internal hard case.




Gently apply pressure to the small clips (as indicated by the arrows) and unclip all four sides. Once all the sides are unclipped, the internal hard case will open.



Insert the iPad into the rear cover.



Once the iPad is inside the rear cover, place the internal front cover on top and gently clip all four sides into position.



Reinstall the external silicone rubber sleeve.

Using the stand

