










## Getting Started: How to unlock the drive

 **EASY TO USE**  
YOUR datAshur SHIPS WITH DEFAULT PIN CODE 1-1-2-2-3-3-4-4


|                                                                                                                                                                                                        |                                                                                                                                                                                                                                                                                                                                          |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. *Press <b>KEY Button</b>                                                                                           |  &  will blink together                                                                                                                                                |
| 2. *Within 10 seconds enter <b>User PIN</b> (factory default <b>PIN</b> 1-1-2-2-3-3-4-4) and press <b>KEY Button</b>  |  &  will illuminate together for approximately 4 seconds and then change to blinking  |
| 3. Connect the datAshur into USB port within 30 seconds                                                                                                                                                |  will illuminate and remain solid<br> will illuminate and flicker                                                                                                      |
| 4. The datAshur can now be accessed as any other USB storage device                                                                                                                                    | Your computer assigns a new drive letter (e.g. F: or G:)                                                                                                                                                                                                                                                                                 |
| 5. To lock the datAshur, save all data and unplug the drive                                                                                                                                            | All indicators will turn off<br>Drive is now locked                                                                                                                                                                                                                                                                                      |

\*before connecting



iStorage datAshur is developed and manufactured by iStorage Ltd. and is based on DataLock® technology licensed from ClevX, LLC



  
**Please note:**  
The datAshur drive may need to be charged before use for 30-60 minutes by inserting into a powered USB port.

**CAUTION**  
**FOR SECURITY, CHANGE FACTORY DEFAULT PIN**  
**SEE OTHER SIDE FOR INSTRUCTIONS**

Quick Start Guide



85.5mm

54mm

Quick Start Guide shown at actual size




















Printing instructions:  
This is a tri-fold brochure to be printed on both sides with a finished folded dimensions of 85.5mm x 54.00mm

WHEN FOLDED THE QSG WILL LOOK LIKE THIS WITH A FINISHED FOLDED DIMENSIONS OF 85.5 mm x 54 mm




## How to change User PIN:

 **CAUTION**  
**FOR SECURITY, CHANGE FACTORY DEFAULT PIN**

PIN must not be sequential or all the same number e.g. 1-2-3-4-5-6-7 or 3-3-3-3-3-3-3

|                                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Press <b>KEY Button</b>                                                                                                                                                                                                                                                       |  &  will blink together                                                                                                                                                    |
| 2. Enter <b>User PIN</b> (factory default <b>PIN</b> 1-1-2-2-3-3-4-4) and press <b>KEY Button</b>                                                                                                                                                                               |  &  will illuminate together for approximately 4 seconds and then change to blinking  |
| 3. Press and hold <b>KEY Button</b>  for 3 seconds                                                                                                                                                                                                                              |  &  will illuminate together                                                                                                                                             |
| 4. While  &  are illuminated enter <b>New User PIN</b> (must be 7-15 digits) and press <b>KEY Button</b>  |  &  will blink in unison                                                                                                                                                 |
| 5. Re-enter <b>New User PIN</b> and press the <b>KEY Button</b>                                                                                                                                                                                                                 |  &  will illuminate and then change to blinking                                       |

Insert the datAshur into USB port

**NB**  blinks if 1<sup>st</sup> and 2<sup>nd</sup> entries match  
 &  blink alternately if PIN entry error

datAshur®



Quick Start Guide

**Step 1**  
**Enter your PIN**



**Step 2**  
**Plug & Play**



**Step 3**  
**Unplug to automatically lock**

Download a complete User Guide at [www.istorage-uk.com](http://www.istorage-uk.com) 

85.5mm

54mm

datAshur®



Quick Start Guide

**Step 1**  
**Enter your PIN**



**Step 2**  
**Plug & Play**



**Step 3**  
**Unplug to automatically lock**

Download a complete User Guide at [www.istorage-uk.com](http://www.istorage-uk.com) 