

MYKRONOZ

WEARABLE DESIGNED IN SWITZERLAND



ZeNeot+

- USER GUIDE -

TABLE OF CONTENTS

GET STARTED

- 1. What's in the box 03
- 2. Overview 03
- 3. Charging 04
- 4. Basic operations 05
- 5. Wearing 06
- 6. Shortcuts 06

PAIRING

- 7. Pairing 07
- 8. Firmware update 09

ACTIVITY TRACKING

- 9. Activity 09
- 10. Goals 10
- 11. Heart rate 11
- 12. Sleep 13
- 13. Body temperature 13
- 14. Timer 16

CONNECTED FEATURES

- 15. Calls 16
- 16. Voice command 17
- 17. Notifications 16
- 18. SMS 18
- 19. Weather 19
- 20. Find my phone 20
- 21. Camera remote 20
- 22. Music control 21
- 23. Anti-lost 21
- 24. Apps 22

CLOCK

- 25. Alarm 22
- 26. Reminders 23
- 27. Settings 24

MAINTENANCE

- 28. Unpair/update/reset/delete 25
- 29. Tech specs 26

REGULATORY & SAFETY NOTICES


26

1. WHAT'S IN THE BOX

ZENEO+



CHARGING CRADLE



GET STARTED GUIDE



2. OVERVIEW



Optical HR sensor & Body temperature sensor


3. CHARGING

Charge ZeNeo+ for one hour and a half before your first use.


1. Plug the charging cable into the USB port on your computer or a certified USB wall charger.
2. Place ZeNeo+ in the charging cradle.
3. A battery indicator will fill to indicate charging is in progress. While the watch charges, double tap the screen to check the battery level.
4. Once ZeNeo+ is fully charged, the battery indicator will be full.




It takes about 1 hour and a half to fully charge ZeNeo+. When the battery level gets low, a battery indicator will appear.



Check ZeNeo+ battery level at any time from the shortcuts interface or by going to the Watch Settings menu > Select Device icon > Click on Battery level icon.



A fully charged ZeNeo+ has a battery life of 3/4 days. Please note that battery life depends on usage and the features you enable.



4. BASIC OPERATIONS

I TURN ON/OFF THE DEVICE

Press and hold the button

I MOVE BETWEEN SCREENS

Slide to the right for activity menu

Slide to the left for main menus

Slide up for notifications

Slide down for shortcuts

I ENTER A MENU/SELECT/CONFIRM

Tap with one finger to open or select a menu item

I EXIT A MENU/GO BACK TO PREVIOUS SCREEN


Double tap the screen

I GO BACK TO HOME SCREEN

Press the button

I CHANGE THE WATCH FACE

To change your ZeNeo+ watch face, press firmly on the current watch face, swipe left or right to go through the different watch faces available and tap on the one you want to select and use.



To ensure ZeNeo+ is responding accurately to your taps, we recommend using your fingertip and not your nail.

5 . WEARING

I DAILY WEAR

For all-day wear, we recommend you to wear ZeNeo+ a finger's width above your wrist bone.


I EXERCISE & WORKOUT

During our workout, we suggest you to wear ZeNeo+ higher on your wrist for recording more accurate heart-rate reading.

- Make sure ZeNeo+ is in contact with your skin.
- Wear ZeNeo+ on your non-dominant hand.
- Do not fasten the wristband too tight for better comfort and not to restrict bloodstream.

6 . SHORTCUTS

Swipe down from the main watch face to access ZeNeo+ shortcuts.



7. PAIRING

Get the **MyKronoz App**

When turning On your ZeNeo+ for the first time, you'll be prompted to download the MyKronoz mobile app on your smartphone in order to proceed to its initial set up.



- iOS -



- ANDROID -

iOS9+ devices with Bluetooth® 4.0 BLE

iPhone 4s, 5, 5c, 5s, 6, 6 Plus, 7, 7 Plus, 8, 8 Plus, X, XR, XS, XS Max, SE, 11, 11 Pro, 11 Pro Max, 12, 12 mini, 12 Pro, 12 Pro Max

**Select Android 6.0+ devices
that support Bluetooth® 4.0 BLE**

I 1ST PAIRING (BLE)

Pair through the MyKronoz App to sync your data and receive notifications

1. Ensure the Bluetooth® is enabled on your mobile smartphone.
2. Search for the MyKronoz App in the App store or Google Play store, download and install the App on your mobile device.
3. Open the MyKronoz App on your mobile device. Sign up if you are a new member or login with your existing account. After entering your personal information, tap Set up.
4. Make sure ZeNeo+ is nearby and select ZeNeo+ model.
5. To connect the first Bluetooth® antenna, follow the on-screen instructions.



QR code pairing

- During the first setup, a QR code will appear on the watch screen
- To pair your device with your phone, put the QR code on ZeNeo+ into the viewfinder (MyKronoz App)
- When ZeNeo+ is successfully paired, you will be notified on your mobile phone's screen.

Tips & tricks

Normal pairing: Tap on the center of the watch face screen 3 times to reveal the QR code on the watch screen.



Alternative pairing (Manual mode)

- Make sure ZeNeo+ is nearby, select ZeNeo+ in the list of devices and confirm
- A pairing request will prompt up on your mobile device
- Tap on ✓ to accept the pairing
- When ZeNeo+ is successfully paired, you will be notified on your mobile device's screen



At the end of the setup process, a firmware update may start automatically. This will ensure that you have the most up to date software on your device and benefit from all the latest features.

I 2ND PAIRING (BT 3.0)

Pair from your mobile phone Bluetooth® settings to receive and make calls

6. To connect the second antenna, open the Bluetooth® settings of your phone and select ZeNeo+.

8. FIRMWARE UPDATE

MyKronoz will provide regular firmware updates which you will need to install in order to access our latest upgrades and features for your watch.

With ZeNeo+, all these updates need to be done by OTA (Over The Air) and through the mobile app. Updates are performed over the air using the mobile app.

Before updating, make sure your phone and your watch have more than 30% battery.

I IN ORDER TO UPDATE YOUR WATCH

- Connect your ZeNeo+ to the mobile app
- If a new update is available you will be prompted from the mobile app home page or the Paired watches section.
- You must click on the banner and confirm in order to start the updating process




During the whole update process you must keep your watch near to your smartphone and your application must be open. Avoid using your phone during the update process. After a successful update, the watch will shut down for 1 minute and restart automatically. Do not turn off the device manually during this time.

9. ACTIVITY TRACKING

Your watch has a built-in 3-axis accelerometer that allows you to track your daily activity based on your movements. This, together with your profile information, allows your tracker to calculate your steps, walking distance and calories burned.

In order to get the most accurate results we recommend you to wear your watch on your left wrist if you're remove a right handed and on your right one if you are remove a left handed.



I VIEW YOUR STATS

ZeNeo+ tracks throughout the day:

- Number of steps taken
- Distance travelled
- Calories burned
- Active minutes

You can view your daily activity in real-time from your device.

You can also monitor your activity data and history from the MyKronoz Mobile App. On the main activity screen, you can check your performance level against your daily goals. Click on any activity bar to get a detailed graph of your daily, weekly and monthly performance.



The activity tracker resets at midnight.

To save your latest activity, go to the Activity tab of the MyKronoz App. Your activity will sync automatically as soon as you open this page.

To sync your data manually, slide your finger down the screen.

ZeNeo+ has the ability to store up to 7 days of your activity data. Then, you will have to synchronize your ZeNeo+ with your mobile app in order to avoid loss of data.

10. GOALS


I SET GOAL FROM THE MOBILE APP

- Go to the **Settings tab**
- Select the **Goals section**

Set daily goals for steps taken, distance travelled, calories burned, active minutes and hours slept.

I SET GOALS FROM THE WATCH

- Go to the **Activity interfaces**
- **Long press the screen data** for which you want to **adjust** your goal and **confirm**



On each activity screen of your ZeNeo+, a progress bar will show how close you are to your daily goal.


Once you hit one of your daily goals, ZeNeo+ will gently vibrate and display a Goal achieved interface.



We recommend you to set ambitious but realistic goals in order to keep a healthy daily activity. You can obviously raise your goals over time to increase your performance. On average it is recommended to have at least 30 minutes of physical activity per day.

11. HEART RATE

Equipped with an optical heart rate sensor, ZeNeo+ measures manually or automatically your heart rate frequency throughout the day.



I MANUAL MODE

- Securely attach your ZeNeo+ around your wrist.
- Go to the **Heart rate** menu of your watch.
- Touch the **red button** to start measuring your heart rate.

It will take about 10 seconds to get the results displayed on your watch screen.

I AUTO HEART RATE TRACKING

- Go to the **Settings tab** of your mobile App
- Click on **Heart rate**
- Enable **Auto track** and set the frequency

Once activated, two green LED lights will start flashing on the back of the device.



Setting automatic HR monitoring on a very regular basis will impact the battery life.


I HEART RATE ALERT

ZeNeo+ can also alert you when your heart rate is going above or below preset limits. You can customize those limits directly from the watch > Go to the **Settings menu** > Click on **Activity** > Select **Heart rate** or in the mobile app settings.



12. SLEEP

ZeNeo+ tracks the hours slept and the quality of your sleep.



I START/EXIT SLEEP MODE MANUALLY

- Press the **sleep app icon** of the ZeNeo+ main menu
- Press on the **Start icon** to enable sleep monitoring
- Press on the **End icon** to stop sleep monitoring

I SLEEP GOALS FROM YOUR WATCH

- The sleep goal is 8 hours by default
- **Long press** the screen to set up your daily sleep goals to your most suitable length
- Set the hour first. Then validate.
- Set the minute and confirm.

I ENABLE PRESET SLEEP MODE


- Open the **MyKronoz App**
- Go to the **Settings menu**
- Click on **Advanced Settings**
- Select or Click on **Sleep** to enter your desired bed and wake up times.



By default, ZeNeo+ will track your sleep from 11pm until 7am.
You can also view your last saved data directly from the device

13. BODY TEMPERATURE

MEASURE YOUR BODY TEMPERATURE WITH ZENEO+



Thanks to its temperature sensor, ZeNeo+ can automatically measure and track your body temperature throughout the day and alert you if your temperature exceeds the normal range.

Using sophisticated algorithms and a precisely calibrated sensor, ZeNeo+ measures the wrist temperature and converts this temperature to display accurate body temperature.

I AUTO MODE

To monitor your body temperature throughout the day, turn on Auto Track from the MyKronoz app:

1. Tap on Settings tab
2. Tap on Body temperature
3. Turn on Auto Track

ZeNeo+ can also alert you when your body temperature is high.

I MANUAL MODE

To track your body temperature manually, access the body temperature screen on your activity tracker.

As soon as you reach this screen, the ZeNeo+ will start measuring your body temperature.

If your body temperature reaches the limit, a high temperature alert will prompt up on your activity tracker screen and you'll be notified by a notification on your phone's screen.

The MyKronoz app uses color coding to help you better understand the reading of your body temperature data :

- **Green** indicates that the temperature is in the normal range
- **Red** indicates a possible fever

HOW TO ANALYZE AND INTERPRET BODY TEMPERATURE DATA?

In spite of a norm that sets the body temperature between 37° (98.6°F) and 37.5°C, (99.6°F) it is important to know that our body regulates itself throughout the day.

In addition of that, the body temperature varies depending on where the measurement is taken and according to the equipment used to take the measurement.



Normal body temperature readings will vary within these ranges due to multi-factorial elements, such as taking medication, age, physical activity, time of day and even a menstrual cycle, can cause the body temperature to vary by one degree.

In adults, the following temperatures suggest that someone has a fever:

- at least 100.4°F (38°C) is a fever
- above 103.1°F (39.5°C) is a high fever
- above 105.8°F (41°C) is a very high fever

As explained in the table above, the indication of fever may vary depending on the measurement type.

A temperature of 38- 40°C (100.4–104°F) caused by short-term illnesses should not cause significant harm in otherwise healthy adults. However, a moderate fever can be more worrying for a person with existing heart or lung issues.

I WARNING

ZeNeo+ is not intended to diagnose or treat any health problem or disease. The measurement results are for reference only.

It is dangerous to make a self-diagnosis or self-treatment based on the obtained measurement results.

For such purposes, please use a medical thermometer, consult a physician or other medical professionals, please consult a physician for temperatures above 104°F or lower than 95° F, especially if there are other warning signs, such as confusion, headaches, or shortness of breath.

14. TIMER

HOW TO USE THE TIMER

- Open the **Timer app**
- **Set the countdown** length by tapping on the hours, minutes or/and seconds area. The selected area will turn purple
- **Swipe up and down** to adjust the countdown. Then press the start button to start the timer.
- At the end of countdown, your watch will alert you with sound and vibration.


15. CALLS

The ZeNeo+ calls features allow you to dial a number, see the caller ID & calls history, answer and reject an incoming call directly from your wrist.

In order to enjoy all these features, you must ensure that the BT 3.0 is connected with your smartphone (refer to 6. Pairing section for more details).

Once it is paired, you will be able to enjoy the following features

HOW TO ANSWER / REJECT / REPLY PHONE CALLS ON ZENEO+



When you hear or see the call notification, raise your wrist to see who's calling:

- **Reset a call and send to voice mail:** Tap the red Reject button in the incoming call notification
- **Answer on your ZeNeo+:** Tap the green answer button in the incoming call notification
- **Send a text message (Android only):** Tap on the top area to select one of the predefined replies



To see the caller ID, make sure that the contact is saved on your phone.

While you're on a call:

- **Adjust the call volume:** Tap on the - or + buttons
- **Hang up a call:** Tap on the red Hang up button
- **Mute the mic:** Tap on the Mute button

16. VOICE COMMAND

The voice command allows you to remotely control your phone, search for information or send a quick command.


To enjoy this feature, make sure that the BT 3.0 is connected with your smartphone (refer to 6. Pairing section for more details).

I SEND A VOICE COMMAND

- Open the **Voice command app**
- Tap on the **Voice control button** to enable the function
- Ask to **Google now** or **Siri** something
- Press the **Voice control button** to **speak** or send **another command**

Examples of what you can ask or do:


- Check the weather
- Set an alarm (on your phone)
- Send a text message



This feature is only functional with iOS 9+ devices compatible with Siri and some Android 6.0+ devices compatible with Google Now. To enjoy this feature, ensure that your smartphone has access to the internet (4G or Wi-Fi).

17. NOTIFICATIONS

ZeNeo+ shows notifications of incoming calls, SMS, email, social media activity & emails.



I SETTING UP NOTIFICATIONS FOR ANDROID USERS

- Open the **MyKronoz App**
- Tap on the **Settings tab**
- Select **Notifications** to select the notifications you want to receive onto your ZeNeo+. If you wish to disable certain notifications types, swipe the selection button to the left.

I SETTING UP NOTIFICATIONS FOR iOS USERS


- Go to the **Settings** of your iOS device
- Tap on **Notification Center**
- Select which type of notifications you wish to receive on ZeNeo+.
- Enable **"Show in Notification Centre"** to receive the notification on ZeNeo+.



ZeNeo+ shows the 20 most recent notifications and 3 screens of detailed information for each notification.

For some very popular applications, ZeNeo+ displays the original application icon. For other applications, ZeNeo+ displays a generic icon.

I POP UP NOTIFICATIONS



As soon as you receive a notification, you will be notified on your watch.

- **Tap** on the **notification preview** to open it
- **Slide left** to discard a notification
- **Slide right** to read it later

To ensure that you do not miss any notifications, the last notification received will remain on the screen until you perform one of these actions above.

18 . SMS

From the Messages menu, you can easily read and reply to your SMS.

I QUICK REPLY (ANDROID ONLY)

ZeNeo+ allows you to reply using emojis or preset short answers directly from your watch. The reply button appears at the end of the SMS. To delete all your SMS notifications, go on the **SMS list** and long press the screen. To erase a specific SMS, select the message and slide it to the left with your finger

19 . WEATHER

To check the current weather, go to the Weather interface on your ZeNeo+ or swipe down from the home screen and click on the weather widget at the top .

By default, the weather screen shows your current location.

I SET UP THE WEATHER FEATURE

- Go to the **Advanced settings** of the mobile app
 - Tap on **Weather**
 - Select **Auto track mode** to get weather forecasts based on your GPS position
- or
- Select **Manual mode** to choose your location

Following this procedure, your ZeNeo+ will display the weather forecast of your select location.


ZeNeo+ will display the weather forecasts of the present day and upcoming 3 days on a second page.



To change the temperature unit, go in the Watch settings > click on Activity > select Units or from the mobile app, go to the Settings menu > Change your weight or height unit. If the weather condition for your current location seems wrong or doesn't appear, make sure that the location services for the MyKronoz App are switched ON.

20. FIND MY PHONE

If you misplace your phone, the Find my phone function will make your phone ring or/and vibrate so you can easily find it. To use this feature, ensure your phone and watch are within range of each other (10m).




HOW TO ENABLE THIS FEATURE

- Press the **find my phone app icon** in the watch shortcuts or in the main menu page (or Apps menu), select **Find my phone app** and click on the screen to **enable** or disable it.

21. CAMERA REMOTE

ZeNeo+ can be used as a remote control to take pictures and selfies from your smartphone. This feature is useful when you want to take a group picture or when you want to take a selfie.



HOW TO USE ZENEO+ AS A CAMERA REMOTE


- **Open the native camera** of your smartphone
- Click on the **Camera app icon** on your watch
- You can then, **tap the camera icon** displayed on your watch screen to start the countdown and take photos



This feature only works with your native camera.
Each picture taken from your ZeNeo+ will appear in the image gallery of your smartphone.

22. MUSIC CONTROL

With ZeNeo+ you can take control of your favorite music player like Deezer, Spotify and YouTube on your smartphone.



HOW TO CONTROL MUSIC

- **First start the player** on your phone
- Go into the **Music app** on your ZeNeo+
- **Play, pause, skip tracks** and **adjust volume** straight from your wrist



On your ZeNeo+, you can see information about the track currently playing, like the artist or track name (Android only).

23. ANTI-LOST

This alert notifies you with a vibration or a sound (depending on your watch settings) when your ZeNeo+ is going out of range (BT range 10 m) of your phone.

Note that you can turn this function off by disabling the **Anti-lost alert** in the **Watch Settings** > Select **Device** > Click on **Anti-lost**.



By default, the anti-lost alert is Off.

24. APPS

Several applications can be found in this menu:




- Reminder
- Calendar

- Stopwatch
- Camera remote

- Timer
- Find my phone

25. ALARM

To wake you up in the morning, or alert you at a certain time of the day, you can set up alarms that gently vibrate and ring at the chosen time.



HOW TO SET AN ALARM FROM THE WATCH

- Go to the **Alarm app icon**
- Click on the **top area** to edit a new alarm
- **Set the alarm time, sound and day**
- Then **confirm**

To dismiss the alarm, **press the button**.



For each alarm, ZeNeo+ will vibrate and ring continuously for 1 minute. You can snooze your wake up alarms several times.


The snooze length can be set in the advanced settings from the mobile app or in the watch settings.

26 . REMINDERS

Several applications can be found in this menu:

HOW TO SET A REMINDER FROM THE WATCH

- Go to the **Reminder app** icon
- Click on the **top area** to edit a new reminder
- **Set the reminder time, type, sound and day**
- Then **confirm**



To dismiss the reminder, **press the button**.

ZeNeo+ will gently vibrate and display the corresponding reminder icon to alert you. A single press on the ZeNeo+ button helps dismisses the reminder. If not dismissed, the same alert will repeat every 2 minutes.

For each reminder, ZeNeo+ will vibrate and/or ring.

HOW TO SET A REMINDER FROM THE APP

- Tap on the **Reminders tab** of MyKronoz App to add daily life reminders
- **Set up reminders**, and choose the **type of reminder** and **preferred time and day**.

28. SETTINGS

Several settings can be found and set in this menu:



DEVICE

Bluetooth®
Enable or disable it

Battery level
Check the battery level

Anti-lost
Enable or disable it



ACTIVITY

Goals
Set your goals

Units
Metric or Imperial

Heart rate
Set your heart rate frequency



SOUNDS & VIBRATIONS

Sound
Set your sound mode

Vibration
Set your vibration mode

Do not disturb
Set a time frame when you don't want to be disturbed

Snooze
Adjust the snooze time

Ringtone
Set the ringtone (Android only)



DISPLAY

Brightness
Adjust the screen brightness

Watch face
Set your watch face

Menu style
Select a menu style



TIME & DATE

Time format
Change time format

Date format
Change date format



SYSTEM

Languages
Set your language

Watch info View the firmware version and serial number of the device


Regulatory
View the watch certification

Reset
Reset your watch to its default settings



You can also find other settings such as do not disturb mode, inactivity alert and time format setting in the MyKronoz App.

29. UNPAIR, RESET, UPDATE & DELETE



I UNPAIR

If you want to pair your ZeNeo+ with another smartphone, pair another MyKronoz device, give it to another person or return it, go to the MyKronoz App > **Settings** menu > Click on **Paired watches** > Click on **Unpair**.

For iOS users, make sure to forget the device from the **Bluetooth® settings** of your phone.

I UPDATE

Make sure to update your ZeNeo+ to get the latest improvements and device updates. When a new update is available, a notification appears in the MyKronoz App and the paired watches section. After starting an update, a progress bar appears in the MyKronoz App as well as an Upgrading message on ZeNeo+ until the update is fully complete. To avoid any issue, make sure to keep your tracker and smartphone close to each other during the process.

I RESET

Hard reset from the mobile app

To reset your device from the MyKronoz App > Click on the **Settings menu** > Select **Paired Watches** > Click on **Reset**

Hard reset from the watch

To reset your watch directly from the device > Go to the **Settings menu** > Click on **System** > Select **Reset**

This procedure will erase all content, data and settings on your watch and set your watch back to the setup mode.

I DELETE

To erase a device from your list of paired watches, go to the MyKronoz App > Click on the **Settings** menu > Click on **Paired Watches** > Click on **Delete**.

30. TECH SPECS

Dimensions	52,6 x 23,8 x 12,3 mm
Weight	32 g
Display size and resolution	IPS-LCD 1.14" / 134 x 240 px
Material	Polycarbonate, aluminium, silicone
Battery type	Lithium polymer 220 mAh
Battery life	Up to 4 days
Bluetooth®	BT 3.0 + BLE 4.2
Memory	7 days of activity
Sensors	3-axis accelerometer, Optical heart sensor & Body temperature sensor
Water resistance	Splashproof
Operating temperature	-10°C to + 60°C
Compatibility	iOS & Android
Accessories included	Charging cradle - Quick start guide
International warranty	1 year

WARNING

- Connecting the built-in USB port improperly may cause serious damage to the device. Any damage caused by misuse is not covered by the warranty. Unplug ZeNeo+ when it is fully charged.
- ZeNeo+ unit and charging dock contain strong magnets that may interfere with pacemakers, credit cards, watches and other magnet-sensitive objects. If you use a pacemaker or any other electronic medical device, please consult your physician before wearing or handling ZeNeo+.
- This product is not a medical device and should not be used to diagnose or treat any medical condition.
- This device is not waterproof so keep it away from all sources of heat or humidity. Do not use it near sink or other wet areas. Do not place it in water. ZeNeo+ is only splash resistant. It is protected against splashes or rain.

ABOUT THIS MANUAL

The features of **ZeNeo+** and the contents of the user manual are subject to change.

To get the latest instructions on how to use this product, please refer to the online user manual available on www.mykronoz.com

SUPPORT

If you have any question or require assistance regarding our product, please visit www.mykronoz.com/support/ submit a request at <https://support.mykronoz.com/hc/en-us/requests/new>

SAFETY INSTRUCTIONS

Before using the device, read these instructions carefully.

- ZeNeo+ has built-in batteries. Do not disassemble the battery on your own. KRONOZ LLC is not responsible for any damage or personal injury caused by the removal of the battery or any component.
- Do not expose your product to extremely high or low temperatures. Excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion. Do not expose the battery in the sun, excessive smoke or dust. Charge the battery in a cool, ventilated room.
- Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (do not rub the eye) or seek medical help.
- Do not short-circuit. Short-circuiting can occur when a metallic object, such as coins, causes direct connection of positive and negative terminals of the battery. Short-circuiting may damage the battery.
- Do not use batteries that have been damaged or have been exhausted.
- Keep the batteries out of children's reach and in a safe place to prevent danger.
- Do not place the batteries in the water. Do not expose your product to water at high pressure, such as ocean waves or waterfall. Do not use your product in a sauna or steam room.
- Do not dispose of batteries in fire as they may cause explosion. Dispose of used batteries in accordance with your local regulations (such as recycling). Do not dispose as household waste.
- Use only the USB cable supplied to charge this battery. Do not charge for more than 24 hours.
- Do not attempt to repair or maintain the watch by yourself, service and maintenance should be performed by authorized technicians.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to these instructions.

CAUTION

- This device has a recording function. Please be sure to comply with the relevant laws and regulations on the use of these features. In accordance with relevant regulations, without permissions any personal characteristic sound recording being copied and disseminated may be seen as an invasion of privacy. Inappropriate use of photography, video and photo, audio recording function records could violate the copyright owner's right. For this, the user must assume full responsibility. KRONOZ LLC is not responsible for any damage caused by improper use of the device.
- This device is not waterproof. Do not immerse the device in water or any other liquids.

REGULARY NOTICE

USA



FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTIONS

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC NOTICE

This equipment complies within the limits of a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protections against radio and TV interference in residential areas. However, even during normal operation, this equipment may cause TV or radio interference. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try one or more of the following corrective measures:

- Reposition the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF EXPOSURE STATEMENTS

This equipment complies with FCC radiation exposure requirement set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

IC: 12131A-ZNEOPL

CANADA

INDUSTRY CANADA (IC) STATEMENT

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions : (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil est conforme à la norme CNR d'Industrie Canada applicable aux appareils radio exempts de licence. Son utilisation est soumise aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un fonctionnement indésirable du dispositif.

IC: 12131A-ZNEOPL

RF EXPOSURE STATEMENTS

This device complies with the ISED RSS-102 RF exposure requirement set forth for an uncontrolled environment and are safe for intended operation as described in this manual.

Cet appareil est conforme aux exigences d'exposition RF de l'ISED RSS-102 définies pour un environnement non contrôlé et est sûr pour le fonctionnement prévu comme décrit dans ce manuel.

EUROPEAN UNION CE DIRECTIVE



Kronoz LLC hereby declares that the device is in compliance with the essential requirements and other relevant provisions of Directives 2014/53/EU & 2011/65/EU.

The original EU declaration of conformity may be found at : <https://www.mykronoz.com/assets/certifications-ce-zeneoplus.pdf>

Kronoz LLC déclare que cet appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 2014/53/EU 2011/65/EU. La déclaration de conformité originale de l'UE peut être consultée à l'adresse suivante: <https://www.mykrnnoz.com/assets/certifications-ce-zeneoplus.pdf>

RUSSIA CUSTOMS UNION CERTIFICATION



視力保護注意事項：

- (1) 使用30 分鐘請休息10 分鐘。
- (2) 未滿2歲幼兒不看螢幕，2歲以上每天看螢幕不要超過1 小時。

依據低功率電波輻射性電機管理辦法

第十二條

※經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

※低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

-前項合法通信，指依電信法規定作業之無線電通信。

-低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

ACCESS TO THE REQUIRED INFORMATION ON THE E-LABEL

Users can access the E-Label screen on ZeNeo+ by going to Settings > General > Regulatory. No special access codes or permissions are required to go through the above steps beyond entering a user-defined password to protect against unauthorized access to the device. Additional regulatory information are in « Regulatory notices » of this document. The information is stored on the device, no special accessories or supplemental plug-ins (e.g., a SIM/USIM card) are required to access the information.



DISPOSAL AND RECYCLING INFORMATION

After the implementation of the European Directive 2012/19/EU in the national legal system, the following applies : electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic device at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.

©2020 Kronoz LLC, all rights reserved.

Kronoz LLC, Avenue Louis-Casai 18 - 1209 Geneva - Switzerland

All brands or product names are or may be trademarks of their respective owners. Pictures and specifications are not contractual. Les marques citées sont des marques déposées par leur fabricant respectif. Photos et caractéristiques non contractuelles. Designed in Switzerland - Assembled in China.

MYKRONOZ 
WEARABLE DESIGNED IN SWITZERLAND

JOIN US @MYKRONOZ



— mykronoz.com —