


USB Type-C to 10G Ethernet Adapter - USB4 and Thunderbolt 3 Compatible


Product ID

USB4-10GBE-ETHERNET

Front View



Rear View



\*Product may vary from image

	Feature	Function
1	Host Connection	<ul style="list-style-type: none"><li>Connect to a <b>USB4</b> or <b>Thunderbolt</b> compatible <b>Host Computer</b></li></ul>
2	LED Indicator	<ul style="list-style-type: none"><li><b>Solid Green</b> = Indicates that the <b>USB4 Network Adapter</b> is connected to the <b>Host Computer</b></li></ul>
3	Ethernet Port & LED Indicators	<ul style="list-style-type: none"><li>Connect an <b>Ethernet Cable</b> <i>Use Cat6 or better cabling for 10 Gbps speeds</i></li><li><b>Left LED Indicator is Link Speed</b><ul style="list-style-type: none"><li><b>Solid Green</b> = 10 Gbps</li><li><b>Solid Orange</b> = 5 Gbps/2.5 Gbps/1 Gbps/100 Mbps</li></ul></li><li><b>Right LED Indicator is Link Status</b><ul style="list-style-type: none"><li><b>Solid Green</b> = Active link</li><li><b>Flashing Green</b> = Activity</li></ul></li></ul>

Package Contents

- USB4 Network Adapter x 1
- 20 in (50 cm) USB4 Cable x 1
- Quick-Start Guide x 1

Requirements

For the latest manuals, product information, technical specifications, and declarations of conformance, please visit: [www.StarTech.com/USB4-10GBE-ETHERNET](http://www.StarTech.com/USB4-10GBE-ETHERNET)

- USB4 or Thunderbolt compatible host computer
- Ethernet Cable (Cat6 or better)

## Installation

### USB4 Host

1. Connect the included **USB4 Cable** from a **USB4 port** on the **Host Computer** to the **Host Connection** on the front of the **USB4 Network Adapter**.
2. Connect an **Ethernet Cable** from the **Ethernet Port** on the back of the **USB4 Network Adapter** to a **Network Port** or **Device**.

### Install the Driver

**Note:** For the latest list of supported operating systems, please visit: [www.StarTech.com/USB4-10GBE-ETHERNET](http://www.StarTech.com/USB4-10GBE-ETHERNET)

1. Navigate to [www.StarTech.com/USB4-10GBE-ETHERNET](http://www.StarTech.com/USB4-10GBE-ETHERNET)
2. Click the **Drivers & Downloads** tab.
3. Under **Driver(s)**, download the **Driver** for your operating system.

### For Windows Systems

- a. Extract the contents of the **Driver Package** by **Right Clicking** the **Driver Folder** that was downloaded from the website and select **Extract All**. Follow the on-screen instructions to finish the **Extraction**.
- b. Follow the instructions on the accompanying PDF file for further **Installation Instructions**.

### For Linux Systems

- a. Extract the contents of the **Driver Package**.
- b. Follow the instructions on the accompanying **README.txt** file.



#### HQ Contact:

StarTech.com Ltd.  
45 Artisans Crescent,  
London, ON N5V 5E9,  
Canada

#### US Contact:

StarTech.com USA LLP  
4490 South Hamilton Rd,  
Groveport, OH 43125,  
United States

#### UK Contact:

StarTech.com Ltd.  
15 Gowerton Rd,  
Northampton, NN4 7BW,  
United Kingdom

#### EU Contact:

StarTech.com Ltd.  
Siriusdreef 17-27  
2132 WT Hoofddorp  
The Netherlands

#### JP Contact:

StarTech.com K.K.  
Atelier Yours Ogawamachi 7F  
1-10-2 Kanda Ogawamachi  
Chiyoda-ku, Tokyo 101-0052  
Japan

FR: startech.com/fr  
DE: startech.com/de  
ES: startech.com/es  
NL: startech.com/nl  
IT: startech.com/it  
JP: startech.com/jp