

Lenovo IdeaPad S9e and S10e Setup Poster









Read the safety notices and important tips in the included manuals before using your computer.



ideapad

Unpack

- | | | |
|--|---|--|
| <input type="checkbox"/> Computer
 | <input type="checkbox"/> Battery pack
 | <input type="checkbox"/> AC adapter
 |
| <input type="checkbox"/> Power cord
 | <input type="checkbox"/> Manuals
- Setup Poster
- User Guide
- Other publications
 | <input type="checkbox"/> Recovery discs
 |

- 1) Some models may contain items that are not listed.
- 2) If any item is missing or damaged, please contact your retailer.
- 3) If your computer does not come with recovery discs, everything for recovering factory-installed files and applications is on your hard disk.


For Barcode Position Only

P/N:45N3441
Printed in China


Initial setup instructions

1 Install the battery pack:


Unlock the right latch and insert the battery pack. After inserting the battery pack, make sure that the latch is in the locked position.



2 Connect to the power:




3 Turn on the power:



4 Configure the operating system following on-screen instructions:

Slide your finger across the touch pad surface to move the cursor. Select items by clicking the left button.



Supplied software

Product Recovery Program

Product Recovery Program enables you to restore the complete contents of your hard disk to the same state as it was when originally shipped from the factory. Product Recovery Program operates independently of the Windows® operating system, so you can perform a recovery operation even if you cannot start Windows. To learn more about the program, see the help for the program.

If recovery discs are shipped with your computer, the program is not supplied. Use the recovery discs for recovery instead.

Application Launcher

The Application Launcher provides quick access to common and frequently used applications.

Norton Internet Security

Norton Internet Security, the latest product of Symantec in 2008, is designed to protect your network against the latest threat. Also it has features, such as anti-virus, firewall, anti-spyware, privacy protection, and anti-phishing.

Adobe Reader

Adobe Reader is software for viewing PDF files. By using its snapshot tool and text selector, you can copy contents into various editing software.

IdeaPad™ features

Ultraportable style

Your computer is small and light enough to carry anywhere. It is perfect for education or a small business.

Multimedia features

Your computer includes multimedia features, such as an integrated camera, microphone, stereo speakers, and Multi-media reader slot.

Power-saving design

The energy-efficient design of your computer enables longer continuous operation on battery power. Your computer meets the European Union's Restriction of Hazardous Substances standards and Energy Star 4.0 standard.

Connectivity options


Your computer provides you with connectivity options such as Ethernet, wireless LAN, and the Bluetooth* technology.

*Select models


Lenovo, the Lenovo logo, and IdeaPad are trademarks of Lenovo in the United States, other countries, or both. Windows is a trademark of Microsoft Corporation in the United States, other countries, or both. Other company, product, or service names may be trademarks or service marks of others.

Buttons and functions


Power button


 Start the computer.


Fn key


 Use in combination with other keys to access special features.


Function key combination


 Turn on or off the integrated camera.


 Put your computer in the standby mode.


 Turn on or off the LCD screen.

 Shift to other connected display devices.


 Enable or disable the built-in wireless device feature.

 Enable or disable the touch pad.

 Enable or disable the Numeric keypad.

 Enable or disable the Scroll Lock.

 Adjust the volume.

 Adjust the display brightness.

Integrated camera


The integrated camera offers an improved notebook experience for video-centric applications.

Novo button

 Open Application Launcher.

Wireless device switch

 Turn on or off both wireless LAN and Bluetooth devices.



* The illustrations in this manual may differ from the actual product.