



## Step-by-Step Guide

### Setting up the Live Streamer CAM 313 for Zoom


To set your default output speaker, please do the following:

1. Open Settings
2. Click on System
3. Click on Sound

The Sound page includes two sections separating the output and input options:


In the section that states “**Choose your output device**” select the speaker (or headphone) option that suits your needs. If none are available in the dropdown, it will default to your standard speaker settings.

In the section that states, “**Choose your input device**”, select the “Microphone (Live Streamer CAM 313 MIC)” to begin using the Live Streamer CAM313.




# Launch the Zoom application


1. Click on **Start**.



2. In **Settings**, under the **Video** tab, you can edit some preferences. For example, you can click Rotate 90° until your camera is rotated correctly.



3. In **Settings**, under the **Audio** tab, please ensure that the Microphone dropdown has the Live Streamer CAM313 selected as default.



The screenshot shows the Zoom Settings application with the Audio tab selected. The left sidebar lists various settings categories: General, Video, Audio (highlighted), Share Screen, Chat, Virtual Background, Recording, Profile, Statistics, Keyboard Shortcuts, and Accessibility. The main content area displays the Audio settings for the Speaker and Microphone. The Speaker settings include a 'Test Speaker' button, a dropdown menu set to 'Z35 (NVIDIA High Definition Audio)', an 'Output Level' slider, and a 'Volume' slider. The Microphone settings include a 'Test Mic' button, a dropdown menu set to 'Microphone (2- Live Streamer CA...', an 'Input Level' slider, a 'Volume' slider, and a checked checkbox for 'Automatically adjust volume'. Below these settings are several checkboxes: 'Use separate audio device to play ringtone simultaneously', 'Automatically join audio by computer when joining a meeting', 'Mute my microphone when joining a meeting', 'Press and hold SPACE key to temporarily unmute yourself', and 'Sync buttons on headset'.