


SAMSUNG

Unpacking and Installation Guide



USB	USB +G	OPTICAL	
ARC	HDMI (eARC)		LAN
	HDMI		ANT

- a
- b
- c Wall Mount Adapter (x 2) Holder-Cable
- Power Cable
- Samsung Smart Remote



Scan this QR code with your smart phone to see helpful videos.

1

48"

55"

65"

2

3

a
 b






R ✓ L

L ✗ R

1


2





	A	B	C	D	E	F	G	H
48S9*F	42.1 inches (1069.3 mm)	24.4 inches (619.9 mm)	1.6 inches (39.6 mm)	27.0 inches (685.9 mm)	10.4 inches (265.2 mm)	47.5 inches	23.4 lbs (10.6 kg)	26.2 lbs (11.9 kg)
55S9*F	48.2 inches (1225.4 mm)	27.9 inches (708.6 mm)	1.6 inches (39.9 mm)	30.5 inches (773.6 mm)	10.4 inches (265.2 mm)	54.6 inches	35.3 lbs (16.0 kg)	38.1 lbs (17.3 kg)
65S9*F	56.9 inches (1444.3 mm)	32.7 inches (831.7 mm)	1.6 inches (39.9 mm)	35.3 inches (896.7 mm)	10.4 inches (265.2 mm)	64.5 inches	46.7 lbs (21.2 kg)	49.6 lbs (22.5 kg)

*: 0-9, A-Z



	VESA A x B (mm)	C (mm)	D	E x 4	F (mm)	G (inches)	H (inches)	I (inches)
48S9*F	300 x 200	28-30	C + ★	M8	1.25	12.8	15.1	3.8
55S9*F						16.3	18.2	3.8
65S9*F						21.1	22.5	3.8

*: 0-9, A-Z

★: Wall-Mount Bracket