



SPEAK2 75

Technology for life's new rhythm

© 2023 GN Audio A/S. All rights reserved. Jabra® is a trademark of GN Audio A/S. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by GN Audio A/S is under license.

Made in China
MODEL: PHS060W



Declaration of Conformity can be found on
www.jabra.com/doc

1. Welcome.....	5
2. Overview.....	6
2.1 Microsoft Teams version	
2.2 UC version	
2.3 Included accessories	
2.4 Optional accessories	
3. Position guide.....	9
3.1 Small meeting room	
3.2 Medium meeting room	
4. How to charge.....	11
4.1 USB charging	
4.2 Battery status	
5. How to connect.....	13
5.1 Connect to a computer (USB cable)	
5.2 Connect to a computer (Bluetooth adapter)	
5.3 Connect to a smartphone or tablet	
6. How to use	17
6.1 Button visibility	
6.2 Typical use	
6.3 Multiple call handling	
6.4 Smart button	
6.5 Microsoft Teams button	
6.6 Status LED ring	

6.7	Microphone Quality Indicator	
6.8	Audio notifications	
6.9	Auto-reconnect	
6.10	Factory reset	
7.	Applications and firmware update	36
7.1	Jabra Sound+	
7.2	Jabra Direct	
7.3	Update firmware	
8.	Support	38
8.1	FAQ and technical specifications	
8.2	How to care for your Jabra device	
8.3	How to clean your Jabra device	

1. Welcome

Thank you for using the Jabra Speak2 75. We hope you will enjoy it!

Here are some key features you will benefit from the Jabra Speak2 75:


- Super-wideband audio* and a full-range 65mm speaker
- Advanced full duplex audio powers natural conversations
- Four beamforming noise cancelling microphones
- Microphone Quality Indicator** so you know you are being heard
- Voice Level Normalization equalizes all voices
- Certified for leading virtual meeting platform

* Super-wideband audio experience requires UC client support, and device support.

** Initial activation is required via the Jabra Sound+ or Jabra Direct apps


2. Overview

2.1 Microsoft Teams version



* The USB-C adapter has been added to comply with EU regulations. This adapter allows increasing the cable length to charge the Jabra Speak 2 75.

2.2 UC version




* The USB-C adapter has been added to comply with EU regulations. This adapter allows increasing the cable length to charge the Jabra Speak2 75.

2.3 Included accessories



Carry pouch




Jabra Link Bluetooth adapter


Depending on the Speak2 75 version, the Jabra Link Bluetooth adapter may not be included. It can be purchased at [Jabra.com/accessories](https://www.jabra.com/accessories)

2.4 Optional accessories

Optional accessories are available at [jabra.com/accessories](https://www.jabra.com/accessories)



Jabra Speak2 75
Secure Mount




Jabra Kensington
Lock Adaptor

3. Position guide


3.1 Small meeting room

For the optimal audio quality, position the speakerphone in the center of the table, up to 2.3m/7.5ft from each participant, but no closer than 0.5m/1.6ft.




3.2 Medium meeting room

For meetings of up to 16 people in a single room (8.5 x 4.5m/27.8 x 14.7ft max.), position two Jabra Speak2 75 devices up to 4m/13ft apart, but no closer than 1.5m/4.9ft. For the optimal audio quality, position the speakerphones at either end of the table, up to 2.3m/7.5ft from each participant, but no closer than 0.5m/1.6ft.





To link the audio between two Jabra Speak2 75 devices, power on the speakerphones and place them close to each other (50cm/20in). Tap the **Smart** button on each speakerphone to link them.



4. How to charge

4.1 USB charging

Plug the speakerphone into a USB power source using the attached USB cable. Depending on the power output of the port, faster charging is available when using USB C. The battery lasts for up to 32 hours of wireless use.




To increase the cable length to charge the speakerphone, connect the USB-C adapter to the attached USB cable of the Jabra Speak2 75. Connect an additional USB cable and plug it into a power supply.

4.2 Battery status


To view the current battery status, tap the **Battery** button. The LED ring will flash to indicate the status.

When the battery status is critically low, the **Battery** button will flash red.

Medium battery



Critically low battery




5. How to connect

It is recommended to connect to a computer using the integrated USB cable or Jabra Link Bluetooth adapter since these connections are certified and ensure an optimal audio quality. A standard Bluetooth connection to a computer is not certified and may not have the same audio quality as a USB cable or Bluetooth adapter connection.

5.1 Connect to a computer (USB cable)

Plug the speakerphone into a USB C or USB A port on your computer.

You may need to set the Jabra Speak2 75 as the playback and recording device in your operating system audio settings and in the video conferencing tool (Microsoft Teams, Zoom, Cisco Webex, etc.) audio settings.




The speakerphone will automatically power on when connecting the USB cable. The speakerphone will automatically power off when the USB cable is disconnected and the speakerphone is not Bluetooth connected to another device.

The USB A adapter must not be removed from the cable and should not be used with other devices.

5.2 Connect to a computer (Bluetooth adapter)

Plug the Jabra Link Bluetooth adapter into a USB port on your computer. The speakerphone and the Jabra Link Bluetooth adapter are pre-paired and ready to use out of the box. The Bluetooth range is up to 30m/98ft.



For the speakerphone to work correctly, you may need to set the Jabra Link Bluetooth adapter as the playback and recording device in your operating system audio settings and in the video conferencing tool (Microsoft Teams, Zoom, Cisco Webex, etc.) audio settings.

If you need to re-pair the speakerphone with the Jabra Link Bluetooth adapter, use Jabra Direct.


5.3 Connect to a smartphone or tablet

Hold the **Bluetooth** button for 3 seconds and follow the voice-guided instructions to pair to your smartphone or tablet. The Bluetooth range is up to 10m/33ft.



To disconnect or reconnect, tap the **Bluetooth** button again.

6. How to use










*Microsoft Teams version only

6.1 Button visibility

The buttons are backlit and only visible when the speakerphone is powered on, except for the **Power** button, which is always visible. After 1 minute of inactivity the buttons will fade, and can be reactivated by tapping the area where the buttons are located.

The **Microsoft Teams** button, **Smart** button and **Mute** button will only be visible under certain conditions.



6.2 Typical use

	WHAT	HOW
	Power on/off	Hold (2 sec) the Power button
	Answer call	Tap the Answer call button
	End/reject call	Tap the End/reject call button
	Increase/decrease volume	Tap (or hold) the Volume up or Volume down button
	Mute/unmute microphone	Tap the Mute button (only visible when the microphone is active)
	Battery status	Tap the Battery button
	Bluetooth pairing	Hold (3 sec) the Bluetooth button and follow the voice-guided instructions
	Connect to a previously paired Bluetooth device	Tap the Bluetooth button

	WHAT	HOW
	Bring Microsoft Teams to foreground on computer	Tap the Microsoft Teams button* (only visible when signed into Microsoft Teams)
	Join active Microsoft Teams meeting	Tap the Microsoft Teams button* (only visible when signed into Microsoft Teams)
	View Microsoft Teams missed calls and voicemails	Tap the Microsoft Teams button* (only visible when signed into Microsoft Teams)
	Raise/lower your hand during a Microsoft Teams meeting	Hold (2 sec) the Microsoft Teams button* (only visible when signed into Microsoft Teams)
	Play/pause music (default), speed dial or mobile device voice assistant	Tap the Smart button
	Manually link to another Speak2 75	Hold (8 sec) the Smart button

* Button functionality depends on the Microsoft Teams desktop application. Certified for USB connection or Jabra Link Bluetooth adapter connection. Standard Bluetooth connections are not certified.

6.3 Multiple call handling

	WHAT	HOW
	Put current call on hold and answer incoming call	Tap the Answer call button
	Switch between held call and active call	Tap the Answer call button
	Reject incoming call and continue current call	Tap the End/reject call button


6.4 Smart button

The **Smart** button can be customized using Jabra Direct or Jabra Sound+.

The options available are:

- Play/pause music (default)
- Speed dial
- Mobile device voice assistant
- None


If None is selected, the **Smart** button will not be visible.




Likewise, the **Smart** button allows you to link two Speak2 75 devices.

Linking two Jabra Speak2 75

To link the audio between two Jabra Speak2 75 devices, power on the speakerphones and place them close to each other (50cm/20in). When the distance between both speakerphones is 50cm/20in or less, the **Smart** button LED will flash yellow on both devices.





Tap the **Smart** button on each speakerphone to link them. The LED ring on each device will light up yellow and you will hear a voice notification confirming the link. The **Smart** button LED will turn yellow to indicate that there is an active link to another Jabra Speak2 75.





All call and audio controls will be available on both speakerphones.

The link between the speakerphones will remain after powering off the devices. When the speakerphones are powered on and are in range, they will automatically link.

If it is not possible to place the speakerphones close to each other to automatically start the link, you can manually start it by holding (8 sec) the **Smart** button on both devices.




The LED ring on each device will light up yellow and you will hear a voice notification confirming the link.



The Smart button LED will turn yellow to indicate that there is an active link to another Jabra Speak2 75.

To unlink the speakerphones, hold (8 sec) the **Smart** button on one of the speakerphones. The **Smart** button LED on the device will flash yellow.





A voice notification will confirm that the speakerphones are unlinked.

6.5 Microsoft Teams button

The **Microsoft Teams** button is only visible when the speakerphone is connected to your computer and you are signed in to Microsoft Teams. The button behaves differently depending on the current status of Microsoft Teams.

To quickly locate the Microsoft Teams button by touch, there is a small tab on the underside of the Microsoft Teams button.





WHAT YOU SEE

WHAT IT MEANS



Solid purple
LED

Connected to Microsoft
Teams




Flashing
purple
Microsoft
Teams
button

Microsoft Teams meeting
ready to join


Join a Microsoft Teams meeting

When a scheduled Microsoft Teams meeting has started, the **Microsoft Teams** button will flash purple. Tap the **Microsoft Teams** button on the speakerphone to join the meeting.




Bring Microsoft Teams to foreground

When Microsoft Teams is running but is minimized, tap the **Microsoft Teams** button on the speakerphone to maximize and bring it to the foreground on your computer.













Raise/lower your hand during a Microsoft Teams meeting

During a Microsoft Teams meeting, hold (2 sec) the **Microsoft Teams** button on the speakerphone to raise/lower your hand. This action will be indicated by a yellow hand icon next to your name.



6.6 Status LED ring

LED RING	STATUS
	In call
	Muted
	Incoming call
	Incoming call during a call
	Incoming call while muted
	Factory reset

LED RING	STATUS
	Firmware update
	Standby LED status
	Media streaming
	Link to another Speak2 75

6.7 Microphone Quality Indicator

The speakerphone LED will light up to indicate how clearly the speakerphone is picking up voices around it.

LED RING

VOICE PICKUP



Optimal voice pickup. When the speaker is detected, the speakerphone will flash green towards their direction.



Poor voice pickup. Move closer to the speakerphone or speak louder/clearer.



Very poor voice pickup. Move closer to the speakerphone and speak louder/clearer.

The Microphone Quality Indicator is disabled by default and can be enabled using Jabra Direct or Jabra Sound+.

6.8 Audio notifications

The speakerphone indicates factory reset, battery level, pairing and Bluetooth connection status. You can select tone or voice notifications using Jabra Direct or Jabra Sound+.

The language of the voice notifications can be changed using Jabra Direct and Sound+. The supported languages are English, Chinese Mandarin, German, French, Japanese, Korean and Spanish.

6.9 Auto-reconnect

When Auto-reconnect is enabled (default), the speakerphone will automatically connect to a previously paired Bluetooth device.

If the speakerphone is used in a meeting room or by several people, it is recommended to disable auto-reconnect to avoid unintentional connections. If Auto-reconnect is disabled, the speakerphone will only allow one Bluetooth connection at a time, and all previously paired Bluetooth devices will be unpaired and need to be paired with the speakerphone again.


Auto-reconnect can be configured in Jabra Direct or Jabra Sound+.

To pair a device with the speakerphone, hold (3 sec) the **Bluetooth** button on the speakerphone and follow the voice-guided instructions.

6.10 Factory reset

Resetting the speakerphone clears the list of paired Bluetooth devices and also clears all personalized settings. After a factory reset, it is necessary to re-pair the Jabra Speak2 75 to your Bluetooth devices.

To factory reset, hold the **Answer call** button and the **End/reject call** button for 4 seconds until 'restore to factory default' is announced by the speakerphone.



7. Applications and firmware update

7.1 Jabra Sound+

Jabra Sound+ is a mobile application that allows you to configure the Jabra Speak2 75 based on your needs.



7.2 Jabra Direct

Jabra Direct is a desktop application designed to support, manage and enable optimal functionality for Jabra devices.



Download the latest free version from jabra.com/direct

7.3 Update firmware

Firmware updates improve performance or add new functionality to Jabra devices. Jabra Direct or Sound+ will notify you when a firmware update is available.

- With Jabra Direct, connect the Jabra Speak2 75 to a computer using the USB cable or the Jabra Link Bluetooth adapter.
- With Jabra Sound+, connect the Jabra Speak2 75 via Bluetooth to your phone.

8. Support

8.1 FAQ and technical specifications

The Jabra Speak2 75 FAQ, certifications, and technical specifications at jabra.com/support

8.2 How to care for your Jabra device

- The Jabra Speak2 75 is for indoor use only.
- Avoid storage at extreme temperatures (above 45°C/113°F or below -20°C/-4°F).
- Avoid operation at extreme temperatures (above 40°C/104°F or below 0°C/32°F).
- Do not expose the speakerphone to rain. Avoid immersing the speakerphone in liquids.
- Do not cover the speaker mesh and buttons with stickers or labels.

8.3 How to clean your Jabra device

Keep your product clean by following these best practices for hygiene.

1. Apply normal dish soap and water to a cloth, making sure you wring out excess liquid so the cloth is not dripping wet. Use soap and water only – do not use strong cleaning agents.
2. Gently wipe the product, making sure there is not a layer of suds on the surface.
3. Let it rest for at least one minute.
4. Rinse the surface by wiping it with a slightly damp cloth using water only.
5. Let it dry.
6. When the product is not in use, keep it clean by avoiding contact with dirty surfaces and storing it in the carry pouch.