


MAXHUB Mic Pod



Quick Start Guide

V1.0

MAXHUB

Table of Contents

I. Package Contents	03
II. Product Introduction	04
III. Installation	06
IV. Wiring Diagram	09

Product Series: Mic Pod

Product Model: DM30, DM3***** (*: 0~9, A~Z, or Blank)

Regulatory Notices

Hereby, Guangzhou Shirui Electronics Co., Ltd. declares that the equipment type DM30, DM3***** (*: 0~9, A~Z, or Blank)

is in compliance with Directive General Product Safety Regulation (GPSR) (EU) 2023/988 and 2014/30/EU

The full text of the EU declaration of conformity is available at the following internet address: www.maxhub.com.



This symbol, affixed to the product or its packaging, indicates that the product must not be processed with household waste. It must be brought to an electric and electronic waste collection point for recycling and disposal. By the appropriate disposal of this product you also help in preventing potentially negative consequences for the environment and human health. The recycling of materials helps preserve our natural resources. For further information regarding the recycling of this product, please contact your municipality, local waste disposal centre or the store where the product was purchased.

Warning:

Operation of this equipment in a residential environment could cause radio interference.

Federal Communication Commission Interference Statement

◆ This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

◆ This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

◆ Non-modification Statement:

◆ Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

◆ FCC SDOC SUPPLIER'S DECLARATION OF CONFORMITY

Guangzhou Shirui Electronics Co., Ltd. hereby declares that this equipment is in compliance with the FCC Part 15 Subpart B.

The declaration of conformity may be consulted in the support section of our Web site www.maxhub.com.


ISED Statement:

This Class A digital apparatus complies with Canadian ICES-003.


Cet appareil numérique de classe A est conforme à la norme canadienne ICES-003.

I. Package Contents


Please check that the following items are included in the package:



DM30 x1



Bracket-A x 1



Bracket-B



Bracket-B nut

Bracket-B Kit x1



TV-Clip Screw x4
(KM3x6)

II. Product Introduction




No.	Item	Description
1	Mute Button	To mute or unmute the DM30.
2	LED Indicator	Note: Make sure all required cables are connected properly. LED Indicator Status • Flashing Red: Disconnected • Solid White: In a teams meeting , Connected and idle In a non-teams meeting, Connected (idle or in use) • Solid Green: in a teams meeting , Connected and in use • Solid Red: Connected and muted • Flashing White: During firmware upgrade
3	Power Out	To connect to the next DM30 in daisy-chain mode.
4	Power In	To connect to the Ext/Mlink port of the host device, or to the previous DM30 in daisy-chain mode


III.Installation

Option 1. Placing the DM30 on the desktop


Step 1: plug the ethernet Cable into the DM30.



Step 2: Put the Bracket-A on the DM30.




Step 3: Secure the Bracket-A to the DM30 with screws..




Option 2. Mount to a desktop


Step 1: Thread the cable through the bracket-B.




Step2 : Plug the Cat cable into the microphone.




Setp 3 : Tighten the screws to secure the bracke-B to the device.



Step 4: Align Bracket-B with the 40–45mm desk opening, then feed the bracket-B through the hole.




Step 5 : Tighten the bracket-B nut and lock it securely in place.



IV. Wiring Diagram

Connect one or multiple DM30 to the EXT or Mlink Port of a host device.



Note: For more detailed connection between DM30 and the host device, please refer to deployment guide of DM30 on MAXHUB Website.

<https://www.maxhub.com/en/resource-center/>

MAXHUB

