






TOSHIBA QSG

BX420T-GS02-QM-S/BX420T-TS02-QM-S
BX420T-GS02-CN-S/BX420T-TS02-CN-S



1

https://www.toshibatec.com/download_overseas/printer/printer_driver/

2

3

4

5

1


2

3


4

5


6




7




8




9




10




11





12




13




14




1




2




3




4




5




6




7




8




9




10



11



12



13

