


Webcam




- 1. LENS
- 2. MOUNT
- 3. MICROPHONE
- 4. POWER LED
- 5. SIGNAL LED
- 6. BASE SCREW
- 7. SHUTTER


- 1. LENTE
- 2. MONTAJE
- 3. MICROFONO
- 4. LED DE ALIMENTACIÓN
- 5. LED DE SEÑAL
- 6. TORNILLO DE LA BASE
- 7. OBTURADOR

- 1. OBJECTIF
- 2. SUPPORT
- 3. MICROPHONE
- 4. LED D'ALIMENTATION
- 5. LED SIGNAL
- 6. VIS POUR LA BASE
- 7. OBTURATEUR

- 1. LINSE
- 2. HALTERUNG
- 3. MIKROFON
- 4. STROM-LED
- 5. LED ANZEIGE
- 6. SOCKELSCHRAUBE
- 7. ABDECKUNG

- 1. LENTE
- 2. MONTAGGIO
- 3. MICROFONO
- 4. LED ALIMENTAZIONE
- 5. LED SEGNALE
- 6. VITE BASE
- 7. OTTURATORE





- Plug the cable into a USB port. The computer will complete the installation.
- Branchez le câble dans le port USB. L'ordinateur lancera l'installation.
- Inserire il cavo in una presa USB. Il computer completerà l'installazione
- Schließen Sie das Kabel an einen USB-Port. Der Computer installiert automatisch.
- Conecte el cable a un puerto USB. El ordenador completará la instalación

Max Res:	1080P HD
Video Res:	1920x1080@30fps, 1280x720@30fps, 640x480@30fps
Format:	MJPEG/YUV
Focus Type:	Fixed
Range:	30cm to infinity
FoV	110°
Mic:	Built-in omnidirectional