







Dell Pro 24 Adjustable Stand Monitor with Speakers
E2426HS
Quick Start Guide





* Included cables vary by country








2


3


4


1















1







2




3







Dell Display and Peripheral Manager
[Dell.com/support/ddpm](https://dell.com/support/ddpm)



[Dell.com/support/E2426HS](https://dell.com/support/E2426HS)