
Lenovo

ThinkCentre M70s/M70t

Setup Guide


Initial Setup




^{*} For selected models I For visse modeller I Tietyissä malleissa I Utvalgte modeller I Vissa modeller

Overview

M70s



M70t



- * 1. Optical drive eject/close button
- * 2. Optical drive activity indicator
- * 3. SD-card slot
 - 4. Power button
 - 5. Storage drive activity indicator
 - 6. ThinkCentre® LED
 - 7. Microphone connector
 - 8. Headset connector
- 9. USB-C[™] (3.2 Gen 1) connector
- 10. USB 3.2 connectors Gen 1
- 11. USB 3.2 connectors Gen 2
- Internal speaker
 Audio line-out connector
- 14. HDMI™ out connector

- 15. DisplayPort® out connectors
- 16. USB 2.0 connectors
- 17. USB 2.0 connector
- 18. Security-lock slot19. PS/2 keyboard and mouse connector
- 20. Serial connector
- 21. Ethernet connector
- 22. Padlock loop
- 23. PCI-Express card area
- 24. Power cord connector
- 25. Smart cable clip slots26. Serial connector
 - 27. E-lock slots
- Read the statement on USB transfer rate in the User Guide. Refer to the Safety and Warranty Guide for accessing the User Guide.

^{*} For selected models I For visse modeller I Tietyissä malleissa I Utvalgte modeller I Vissa modeller

Customer Replacement Units (CRUs)

- Computer cover
- Front bezel
- Keyboard
- Mouse
- Optical drive
- * Optical drive bracket
- Primary storage drive
- Primary storage drive bracket
- * Secondary storage drive
- * Secondary storage drive bracket
- Memory module
- M.2 solid-state drive

Refer to the User Guide for CRU definition.

- * Heat sink for the M.2 solid-state drive
- * M.2 solid-state drive bracket
- * Storage converter
- * PCI-Express card
- * PCI-Express connector cable
 - Power cord
- * Vertical stand
- * Smart cable clip
 - · Coin-cell battery
- E-lock
 - Power supply assembly

^{*} For selected models I For visse modeller I Tietyissä malleissa I Utvalgte modeller I Vissa modeller

Additional information

European Union — compliance with the Radio Equipment Directive

Hereby, Lenovo (Singapore) Pte. Ltd., declares that the radio equipment type ThinkCentre M70s/M70t is in compliance with Directive 2014/53/EU.

The full text of the system EU declaration of conformity is available at the following Internet address:

https://www.lenovo.com/us/en/compliance/eudoc

This radio equipment operates with the following frequency bands and maximum radio-frequency power:

| Technology | Frequency band [MHz] | Maximum transmit power |
|-------------------------|-------------------------|------------------------------|
| WLAN 802.11b/g/n/ax | 2400 - 2483.5 | < 20 dBm |
| WLAN 802.11a/n/ac/ax | 5150 - 5725 | < 23 dBm |
| WLAN 802.11a/n/ac/ax | 5725 - 5875 | < 13.98 dBm |
| Bluetooth BR/EDR/LE | 2400 - 2483.5 | < 20 dBm |

Usage of all the radio devices is limited to indoor in the band 5150 MHz to 5350 MHz (channels 36, 40, 44, 48, 52, 56, 60, 64).

M70s



M70t



First Edition (March 2020)

© Copyright Lenovo 2020.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce I Reuse I Recycle

