

Wireless USB-C Vlogging Lapel Mic with Charging Case

Quick Start Guide




model AWLMC01F

qsg Q10620 Copyright © 2022 Aluratek, Inc. All Rights Reserved.


Package Contents

Your order has been carefully packaged and inspected. The following accessories should be included in your package. Please inspect the contents of the package to ensure that you have received all items and that nothing has been damaged. If you discover a problem, please contact us immediately for assistance.




USB-C to USB-A Cable Charging Case Transmitter Receiver

Product Highlights



- ① Windproof mic screen
- ② Indicator LED
- ③ Mic USB-C charging port
- ④ Mic clip
- ⑤ MFB (multi-function button)

Product Highlights




- ⑥ USB-C connector
- ⑦ Indicator LED
- ⑧ Pass -thru USB-C charging port
- ⑨ Charging case USB-C charging port
- ⑩ Charging case Indicator LED

Operation

Product Instructions


STEP 1: Smartphone or tablet with a USB-C port



Operation

Product Instructions

STEP 2: Press the MFB button for three seconds to power on the microphone. Once connected with the receiver, the status indicator light will turn green.



Operation

Charging The Battery Case

The battery is not fully charged and it is highly recommended that you charge AWLMC01F before you begin using it.

Note: Using AWLMC01F “out of the box” will not harm the device. You will experience reduced battery life as the unit will not be fully charged.

Connect the larger USB end of the cable provided to your PC or USB power adapter (not included). Plug the USB-C end to the charging port on the bottom of the case. The red LED will be flashing while charging. Please charge the case for 2 hours. When charging is complete, the LED will be solid red.

Note: there is no built-in battery for the receiver. The Type-C charge port on the receiver is used to charge the connected Smartphone or tablet.

Operation

Control Functions

Function	Operation	LED Status
Power ON	Press and hold the MFB button for 3 seconds	Off to solid green
Power OFF	Press and hold the MFB button for 3 seconds	Solid green to off
Noise Reduction Level	Press the MFB button to cycle through 3 levels	Level 1: flash once Level 2: flash twice Level 3: flash three times
Mute / Unmute	Press the MFB button twice to mute / unmute	Flashing Green (muted)
Low Battery		Red light flashes every 10 seconds

Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

Technical Support

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: support@aluratek.com
 Web: www.aluratek.com/helpdesk
 Local (Irvine, CA): 714-586-8730
 Toll free: 1-866-580-1978

Warranty

Aluratek warrants this product against defect in material or workmanship for **1 YEAR** from the date of purchase.

For more information, please visit:
<https://aluratek.com/warranty-return-policy>

You can register your product online at:
<https://aluratek.com/product-registration>