



Logitech Casa Pop-Up Desk



With Casa Pop-Up Desk, get comfy, focused work done anywhere in the home. Once you're done? Fold it out of sight, out of mind.

FEATURES

- **My Work. My Life. My Home:** With Casa Pop-Up Desk, you decide where comfy, focused work happens in the home; when the workday is done, place this folding desk out of sight, out of mind
- **Make More Room for the Things You Love:** With a keyboard, touchpad, laptop riser and storage all in one compact kit, you can enjoy every inch of your home office space
- **Great Work On Any Surface:** Reach your full potential from anywhere in the home - be it a dining table, high countertop, or simply a corner that catches the sunrays
- **Laptop Days, 40% Comfier(1):** The book-like case unfolds into an ergonomic laptop stand, raising your screen to eye level for noticeably better posture, however long you need it
- **A Familiar Experience:** Enjoy the laptop-like feel you know and love on Casa Keys and Casa Touch, the minimalist wireless keyboard and smooth wireless touchpad
- **For a Wide Range of Laptops:** The laptop holder supports most laptops from 10" to 17"(2); plus, each device connects to multiple OS (Windows, macOS, iPadOS, ChromeOS) via Bluetooth Low Energy
- **Sustainability:** Plastic parts in Casa Pop-Up Desk include certified post-consumer recycled plastic (3) (Touchpad: minimum 62%; Keyboard: minimum 47%; Book: minimum 44%)
- **Disclaimer:** Uses FSC-certified paper for responsible packaging; certified carbon neutral

(1)Source: Study by the Logitech ErgoLab on 12 persons in Switzerland (Dec 21)

(2)Excludes tablet laptops and laptops with non-square edges above 12mm.

(3)Excludes plastic in battery, printed wiring assembly (PWA), FFC cable, and packaging.

(4)Battery life may vary based on user and computing conditions.

(5)Wireless range may vary depending on operating environment and computer setup.

(6)Customize device by installing the Logi Options+ app for Windows or macOS.

(7)Touchpad gestures enabled by installing the Logi Options+ app.

(8)Logi Options+ app is currently not supported.

(9)Dictation feature is provided by Windows® and macOS and currently available only in select languages and geographies. Learn more: logitech.com/support/OSdictation. Requires LogiOptions+ App.

WHAT'S IN THE BOX

- Casa Keys: Keyboard
- Casa Touch: Touchpad
- Casa Book: Book-like case that transforms into a laptop stand
- USB-C charging cable (USB-C to USB-C)
- User documentation



PACKAGE SPECIFICATIONS

	Primary pack	Master shipper carton
Part #	920-011237	N/A
Bar code	097855181084 (EAN-13)	10097855181081 (SCC-14)
Weight gr	1450	6600
Length cm	31.8	32.8
Width cm	23.6	18
Height/depth cm	4.3	24.8
Volume	3 dm ³	0m ³
1 primary pack	1	N/A
1 master shipper carton	4	1
1 pallet EURO	336	84
1 container 20 ft	8136	2034
1 container 40 ft	16884	4221
1 container 40 ft HQ	18760	4690

nordic calm CAN-215
Part #: 920-011238
EAN/UPC: 097855181091
Bar code: 10097855181098

bohemian blush CAN-215
Part #: 920-011237
EAN/UPC: 097855181084
Bar code: 10097855181081

classic chic CAN-215
Part #: 920-011236
EAN/UPC: 097855181077
Bar code: 10097855181074

TECHNICAL SPECS

- Dimensions
- CASA KEYS
 - Height: 17 mm, including keycaps and rubber feet
 - Width: 112 mm
 - Length: 280 mm
 - Weight: 375 g
- CASA TOUCH
 - Height: 14 mm
 - Width: 88 mm
 - Length: 125 mm
 - Weight: 160 g
- CASA BOOK
 - Height: 29 mm (closed), 160 mm (opened as a laptop stand)
 - Width: 230 mm
 - Length: 290 mm
 - Weight: 690 g without devices nor cable
- Connection Type: Bluetooth[®] Low Energy technology or Logi Bolt - not included
- Easy-switch: connect up to 3 devices and switch between them
- Wireless range: 10 m (33 ft) (5)