


K845 MECHANICAL ILLUMINATED CORDED ALUMINUM KEYBOARD

Complete Setup Guide

完整设置指南




CONTENTS

English3

简体中文5


K845 MECHANICAL ILLUMINATED CORDED ALUMINUM KEYBOARD




logitech.com/support/k845

SHORTCUT KEYS

+	F1 	F2 	F3 	F4 	F5 	F6 	F7 	F8 	F9 	F10 	F11 	F12
FN	Decrease key brightness	Increase key brightness	Search	Calculator	Open Media	Previous	Play/ Pause	Next Media	Mute	Reduce Volume	Increase Volume	Change Lighting Pattern Five onboard patterns





CHANGE LIGHTING PATTERNS






1. Static max brightness
2. Serpent
3. Reactive
4. Random Lights
5. Breathing

TO CHANGE SPEED OF LIGHTING EFFECTS



K845 机械背光键盘


有线铝制键盘




logitech.com/support/k845

快捷键

+	F1 	F2 	F3 	F4 	F5 	F6 	F7 	F8 	F9 	F10 	F11 	F12
FN	降低按键 亮度	提高按键 亮度	搜索	计算器	播放媒体	上一曲目	播放/暂停	下一曲目	静音	降低音量	增加音量	改变灯光 模式 (五 种板载模 式)



改变灯光模式



1. 静态最高亮度
2. 贪食蛇
3. 反应
4. 随机灯光
5. 呼吸灯

改变光效速度

