



















SAMSUNG




Unpacking and Installation Guide
 Guide de déballage et d'installation
 Guía de desembalaje e instalación
 Manual de desempacotamento e instalação
 Auspacken und Installationsanleitung
 Guida al disimballaggio e all'installazione
 Руководство по распаковке и установке
 Қаптамадан шығару және орнату нұсқаулығы
 Посібник з розпаковки та встановлення
 Qadoqdan chiqarish va o'rnatish qo'llanmasi





	A	B	C	D	E	F	G	H
98QN9*D	86.0 inches	49.2 inches	1.2 inches	51.4 inches	14.4 inches	97.5 inches	135.4 lbs	155.6 lbs
98QND9*	(2185.1 mm)	(1249.3 mm)	(31.1 mm)	(1305.9 mm)	(364.9 mm)	(247 cm)	(61.4 kg)	(70.6 kg)
98QN9*F	(2185,1 mm)	(1249,3 mm)	(31,1 mm)	(1305,9 mm)	(364,9 mm)	(247 cm)	(61,4 кг)	(70,6 кг)
98QNF9*	(218.51 cm)	(124.93 cm)	(3.11 cm)	(130.59 cm)	(36.49 cm)	(247 cm)	(61,4 кг)	(70,6 кг)

*: 0-9, A-Z



	VESA A x B (mm) VESA A x B (MM)	C (mm) C (MM)	D x 4
98QN9*D 98QND9* 98QN9*F 98QNF9*	600 x 400	11-13	M8

*: 0-9, A-Z