

INSTRUCTION MANUAL ENCLOSED

ATTENTION

**IF YOU HAVE ANY PROBLEMS OR QUESTIONS, EMAIL OR CALL
CUSTOMER SERVICE BEFORE YOU RETURN THIS PRODUCT TO THE
STORE WHERE IT WAS PURCHASED.**

For Customer Service:

USA: Email: support@orderhelp.com /Call: 1-877-897-1222

CANADA: Email: sirio@orderhelp.com / www.sirio.ca

/Call: 1-866-666-0421


****When emailing Customer Service, please include your **Order Number** and **platform of purchase** in the email subject for quicker assistance.**

INSTRUCTION MANUAL ENCLOSED






OUTDOOR SOFA SET

MS406

OUTDOOR SOFA SET ASSEMBLY INSTRUCTION



PARTS LIST		
Part	Description	Quantity
<i>HARDWARE</i>		
A	Bolts 1/4*45mm	16
B	Allen Key	1
<i>PARTS</i>		
C	Long legs	4
D	Leftram seat	1
E	Rightarm seat	1

A  1/4*45mm x16	B  x1	C  x4
D  x1	E  x1	

For Customer Service:

Email: support@orderhelp.com
sirio@orderhelp.com / www.sirio.ca
Call: 1-877-897-1222 / 1-866-666-0421

PLEASE READ AND FOLLOW ALL SAFETY TIPS


GETTING STARTED

1. Before assembly, CAREFULLY use scissors or utility knife to cut and unwrap all parts. Make sure you do not discard the hardware.
2. Make sure that you have all the parts listed. If you are missing any parts, please email Customer Service: USA: support@orderhelp.com or call 1-877-897-1222. Canada: sirio@orderhelp.com / www.sirio.ca or call 1-866-666-0421. Please identify the parts you need and model number. Make sure to include your name and address.
3. Please include your **Order Number** and **platform of purchase** in the email subject, and one of our customer service representative will get back to you.


Warm Tips:

1. The plastic covers on some metal parts are just for product protection. Please remove it before assembly.
2. Please follow the sequence of AI during assembly.
3. Do not tighten the screws until all of them are in right positions.

1. Position each Long Leg(C) to the Leftarm Seat(D) by the pre-drilled threads. Use Allen Key(B) to fasten Bolts(A). It should have 8 bolts fastened. (Photo 1)



2.Repeat the above steps to fasten Rightarm Seat(E).It should have 8 bolts fastened.(Photo 2)



You have completed assembling the furniture – enjoy!

INSTRUCTION MANUAL ENCLOSED

ATTENTION

**IF YOU HAVE ANY PROBLEMS OR QUESTIONS, EMAIL OR CALL
CUSTOMER SERVICE BEFORE YOU RETURN THIS PRODUCT TO THE
STORE WHERE IT WAS PURCHASED.**

For Customer Service:

USA: Email: support@orderhelp.com /Call: 1-877-897-1222

CANADA: Email: sirio@orderhelp.com / www.sirio.ca

/Call: 1-866-666-0421


****When emailing Customer Service, please include your **Order Number** and **platform of purchase** in the email subject for quicker assistance.**

INSTRUCTION MANUAL ENCLOSED

OUTDOOR SOFA SET







MS406

OUTDOOR SOFA SET ASSEMBLY INSTRUCTION



PARTS LIST

Part	Description	Quantity
HARDWARE		
A	Bolts 1/4*45mm	10
B	Allen Key	1
PARTS		
C	Long leg	1
F	Short leg	1
G	Corner leg	1
H	Corner seat	1

A  1/4*45mm ×10	B  ×1	C  ×1
F  ×1	G  ×1	H  ×1

For Customer Service:

Email: support@orderhelp.com
sirio@orderhelp.com / www.sirio.ca
Call: 1-877-897-1222 / 1-866-666-0421

PLEASE READ AND FOLLOW ALL SAFETY TIPS


GETTING STARTED

1. Before assembly, CAREFULLY use scissors or utility knife to cut and unwrap all parts. Make sure you do not discard the hardware.
2. Make sure that you have all the parts listed. If you are missing any parts, please email Customer Service: USA: support@orderhelp.com or call 1-877-897-1222. Canada: sirio@orderhelp.com / www.sirio.ca or call 1-866-666-0421. Please identify the parts you need and model number. Make sure to include your name and address.
3. Please include your **Order Number** and **platform of purchase** in the email subject, and one of our customer service representative will get back to you.

Warm Tips:

1. The plastic covers on some metal parts are just for product protection. Please remove it before assembly.
2. Please follow the sequence of AI during assembly.
3. Do not tighten the screws until all of them are in right positions.

1. Position Long Leg(C) to the Corner Seat(H) by the pre-drilled threads. Use Allen Key(B) to fasten Bolts(A). It should have 4 bolts fastened.
2. Position Short Leg(F) by the pre-drilled threads. Use Allen Key(B) to fasten Bolts(A). It should have 4 bolts fastened.
3. Position Corner Leg(G) by the pre-drilled threads. Use Allen Key(B) to fasten Bolts(A). It should have 2 bolts fastened. (Photo 1)



INSTRUCTION MANUAL ENCLOSED

ATTENTION

**IF YOU HAVE ANY PROBLEMS OR QUESTIONS, EMAIL OR CALL
CUSTOMER SERVICE BEFORE YOU RETURN THIS PRODUCT TO THE
STORE WHERE IT WAS PURCHASED.**

For Customer Service:

USA: Email: support@orderhelp.com /Call: 1-877-897-1222

CANADA: Email: sirio@orderhelp.com / www.sirio.ca

/Call: 1-866-666-0421


****When emailing Customer Service, please include your **Order Number** and **platform of purchase** in the email subject for quicker assistance.**

INSTRUCTION MANUAL ENCLOSED





OUTDOOR SOFA SET

MS406

OUTDOOR SOFA SET ASSEMBLY INSTRUCTION



PARTS LIST		
Part	Description	Quantity
<i>HARDWARE</i>		
A	Bolts 1/4*45mm	16
B	Allen Key	1
<i>PARTS</i>		
C	Long legs	4
I	Middle seat	2

<div>A</div> <div></div> <div>1/4*45mm</div> <div>×16</div>	<div>B</div> <div></div> <div>×1</div>
<div>C</div> <div></div> <div>×4</div>	<div>I</div> <div></div> <div>×2</div>

For Customer Service:

Email: support@orderhelp.com

sirio@orderhelp.com / www.sirio.ca

Call: 1-877-897-1222 / 1-866-666-0421

PLEASE READ AND FOLLOW ALL SAFETY TIPS

GETTING STARTED


1. Before assembly, CAREFULLY use scissors or utility knife to cut and unwrap all parts. Make sure you do not discard the hardware.
2. Make sure that you have all the parts listed. If you are missing any parts, please email Customer Service: USA: support@orderhelp.com or call 1-877-897-1222. Canada: sirio@orderhelp.com / www.sirio.ca or call 1-866-666-0421. Please identify the parts you need and model number. Make sure to include your name and address.
3. Please include your **Order Number** and **platform of purchase** in the email subject, and one of our customer service representative will get back to you.

Warm Tips:

1. The plastic covers on some metal parts are just for product protection. Please remove it before assembly.
2. Please follow the sequence of AI during assembly.
3. Do not tighten the screws until all of them are in right positions.

1. Position each Long Leg (C) to the Middle Seat (I) by the pre-drilled threads. Use Allen Key (B) to fasten Bolts (A). It should have 8 bolts fastened. (Photo 1)

2. Repeat the above steps to fasten the other one. It should have 8 bolts fastened. (Photo 1)



You have completed assembling the furniture – enjoy!

INSTRUCTION MANUAL ENCLOSED

ATTENTION

**IF YOU HAVE ANY PROBLEMS OR QUESTIONS, EMAIL OR CALL
CUSTOMER SERVICE BEFORE YOU RETURN THIS PRODUCT TO THE
STORE WHERE IT WAS PURCHASED.**

For Customer Service:

USA: Email: support@orderhelp.com /Call: 1-877-897-1222

CANADA: Email: sirio@orderhelp.com / www.sirio.ca

/Call: 1-866-666-0421


****When emailing Customer Service, please include your **Order Number** and **platform of purchase** in the email subject for quicker assistance.**

INSTRUCTION MANUAL ENCLOSED

OUTDOOR SOFA SET







MS406

OUTDOOR SOFA SET ASSEMBLY INSTRUCTION



PARTS LIST

Part	Description	Quantity
<i>HARDWARE</i>		
A	Bolts 1/4*45mm	16
B	Allen Key	1
<i>PARTS</i>		
C	Long legs	2
J	Ottoman legs	2
I	Middle seat	1
K	Ottoman	1

A  1/4×45mm ×16	B  ×1	C  ×2
J  ×2	I  ×1	K  ×1

For Customer Service:

Email: support@orderhelp.com
sirio@orderhelp.com / www.sirio.ca
Call: 1-877-897-1222 / 1-866-666-0421

PLEASE READ AND FOLLOW ALL SAFETY TIPS


GETTING STARTED

1. Before assembly, CAREFULLY use scissors or utility knife to cut and unwrap all parts. Make sure you do not discard the hardware.
2. Make sure that you have all the parts listed. If you are missing any parts, please email Customer Service: USA: support@orderhelp.com or call 1-877-897-1222. Canada: sirio@orderhelp.com / www.sirio.ca or call 1-866-666-0421. Please identify the parts you need and model number. Make sure to include your name and address.
3. Please include your **Order Number** and **platform of purchase** in the email subject, and one of our customer service representative will get back to you.


Warm Tips:

1. The plastic covers on some metal parts are just for product protection. Please remove it before assembly.
2. Please follow the sequence of AI during assembly.
3. Do not tighten the screws until all of them are in right positions.

1. Position each Long Leg (C) to the Middle Seat (I) by the pre-drilled threads. Use Allen Key (B) to fasten Bolts (A). It should have 8 bolts fastened. (Photo 1)



2.Repeat the above steps to fasten Ottoman(K).It should have 8 bolts fastened.(Photo 2)



You have completed assembling the furniture – enjoy!

INSTRUCTION MANUAL ENCLOSED

ATTENTION

**IF YOU HAVE ANY PROBLEMS OR QUESTIONS, EMAIL OR CALL
CUSTOMER SERVICE BEFORE YOU RETURN THIS PRODUCT TO THE
STORE WHERE IT WAS PURCHASED.**

For Customer Service:

USA: Email: support@orderhelp.com /Call: 1-877-897-1222

CANADA: Email: sirio@orderhelp.com / www.sirio.ca

/Call: 1-866-666-0421


****When emailing Customer Service, please include your **Order Number** and **platform of purchase** in the email subject for quicker assistance.**

INSTRUCTION MANUAL ENCLOSED


OUTDOOR SOFA SET

MS406

OUTDOOR SOFA SET ASSEMBLY INSTRUCTION



PARTS LIST		
Part	Description	Quantity
<i>HARDWARE</i>		
L	Bolts 1/4*15mm	16
B	Allen Key	1
<i>PARTS</i>		
M	Table legs	4
N	Table top	1



For Customer Service:

Email: support@orderhelp.com

sirio@orderhelp.com / www.sirio.ca

Call: 1-877-897-1222 / 1-866-666-0421

PLEASE READ AND FOLLOW ALL SAFETY TIPS


GETTING STARTED

1. Before assembly, CAREFULLY use scissors or utility knife to cut and unwrap all parts. Make sure you do not discard the hardware.
2. Make sure that you have all the parts listed. If you are missing any parts, please email Customer Service: USA: support@orderhelp.com or call 1-877-897-1222. Canada: sirio@orderhelp.com / www.sirio.ca or call 1-866-666-0421. Please identify the parts you need and model number. Make sure to include your name and address.
3. Please include your **Order Number** and **platform of purchase** in the email subject, and one of our customer service representative will get back to you.

Warm Tips:

1. The plastic covers on some metal parts are just for product protection. Please remove it before assembly.
2. Please follow the sequence of AI during assembly.
3. Do not tighten the screws until all of them are in right positions.

1. Position each Table Leg (M) to the Table Top (N) by the pre-drilled threads. Use Allen Key (B) to fasten Bolts (L). It should have 16 bolts fastened. (Photo 1)



You have completed assembling the furniture – enjoy!