

User Guide for the DocCAM Remote

August 2022

The remote provides zoom control and presets, focus, and laser pointer control. In multi-camera environments, it also enables you to select which camera to control.

Before you can use the remote, you will need to install the batteries.

Installing the Batteries

The remote uses two AAA batteries.

1. Remove the cover from the back of the remote. You may need to press down on the upper edge while sliding it off.
2. Install the batteries as shown in the diagram in the battery opening.
3. Slide and snap the cover back into place.













Tips for Using the Remote

Presets: The remote provides access to camera presets. Your camera's web interface may provide access to additional camera presets.

Camera selection: The remote has three IR channels, so it can control up to three cameras independently. Check your camera's manual for information on setting it as camera 1, camera 2, or camera 3. By default, Vaddio cameras respond as camera 1

Troubleshooting tip: If the camera does not respond to the remote, press the Camera 1 button and try again. If that doesn't fix the problem, try the other camera selection buttons.

DocCAM Remote Quick Reference

	Data Screen button – Press to display the camera’s IP and MAC addresses on the video output(s); press again to dismiss the information display.
	Backlight button – Adjusts for excess light behind the camera’s subject.
	Power button and indicator – Set the camera to standby mode, or return to full-power mode.
	Camera buttons – Select IR channel 1, 2, or 3. Vaddio cameras default to camera 1.
	Laser On button – Turns on the camera’s laser pointer. Press again to turn off the laser pointer. Laser Mom button – Turns on the laser pointer momentarily (about 5 seconds).
	Home button – Returns the camera to the zoom level defined as Home.
	Auto Focus button – Use automatic focus. Overrides manual near and far buttons.
	Zoom T and W buttons – Zoom in (T , telephoto) or out (W , wide-angle).
	Manual Focus, Near (-), and Far (+) buttons – Select manual focus mode and adjust the focal distance.
	Position Preset buttons – Set, clear, or select preset shots.



Storing and Clearing Presets

Your camera may have additional presets available through its web interface.

To store a preset:

Set up the shot. Then hold down the **Preset** button and press one of the numbered preset buttons.

To clear a preset:

Press and hold the **Reset** button while pressing the preset number you want to clear.

Vaddio is a brand of Legrand AV Inc. · www.legrandav.com · Phone 800.572.2011 / +1.763.971.4400 · Fax +1.763.971.4464 · Email av.vaddio.support@legrand.com

Vaddio is a registered trademark of Legrand AV Inc. All other brand names or marks are used for identification purposes and are trademarks of their respective owners. All patents are protected under existing designations. Other patents pending.

©2022 Legrand AV Inc.