

USB 3.0 to Dual HDMI Adapter Supports Windows Only

Full-Product Manual USB32HD2



Actual products may vary from photos

For the latest information and specifications visit www.StarTech.com/support

Manual Revision: 01/04/2024



Table of Contents

Requirements	2
Package Contents	2
Product Diagram	3
Installation	4
Hardware Installation	5
Software Installation	6
Operation	11
Display Configuration	11
Audio Configuration	29
Troubleshooting	31
Compliance Statements	39
Safety Statements	40



Requirements

- USB Enabled Host Computer (Only Windows Platforms Supported)
 - Requires USB 5Gbps or Faster
- Display Device

Package Contents

- USB Display Adapter x1
- Quick-Start Guide x1

For the latest drivers/software, technical specifications, and declarations of conformance, please visit: <u>www.StarTech.com/USB32HD2</u>



Product Diagram



	Component	Function
1	Built-In USB Host Cable (USB-A)	 Connect to a USB Port on a Host Computer USB 5Gbps
2	Video Output Port (HDMI)	 Connect to an HDMI Display 1080p (1920x1200) 60Hz Resolution
3	Video Output Port (HDMI)	 Connect to an HDMI Display 4K (3840×2160) 30Hz Resolution



Installation


IMPORTANT PRE-INSTALLATION STEPS FOR AUTO DRIVER OR MANUAL SETUP

- This **USB Display Adapter** is intended for Windows operating systems only.
- Driver installation for the USB Display Adapter may be automatic on Host Computers running Windows 10 and up. Before connecting the USB Display Adapter to the Host Computer, please take the following steps to optimize the Host Computer for automatic driver installation:
 - Make sure any outstanding Windows updates are installed to ensure the Host Computer is running the most up-todate version of Windows.
 - Ensure that the **Host Computer** has an active Internet connection.
 - Verify that the active user account has administrator privileges.
- This Manual provides two methods for driver installation: Automatic Driver Installation and Manual Driver Installation. If the Automatic Driver Installation fails please disconnect the USB Display Adapter from the Host Computer, and follow the steps for Manual Driver Installation.




Hardware Installation

 Connect the Display Device(s) to the Video Output Ports on the USB Display Adapter, using the required cables (sold separately).



2. Connect the **Built-In USB Cable** on the **USB Display** Adapter to an available **USB Port** on the **Host Computer**.






Software Installation

Automatic Driver Installation

1. Once the **USB Display Adapter** has been connected to the **Host Computer**, Windows will attempt to download and install the drivers automatically.



 Installation may take several seconds to complete. During the installation process the connected **Display Device(s)** might flicker, this is normal. Once the installation has completed, the Windows desktop will appear on the connected **Display Device(s)**.





Manual Driver Installation

If after 3 minutes the Windows desktop does not appear on the connected **Display Device(s)**, it's likely that Windows has failed to automatically install the Driver, and it will be necessary to follow the below steps for Manual Driver Installation:

1. Disconnect the **USB Display Adapter** from the **Host Computer**.



2. Navigate to <u>www.StarTech.com/USB32HD2</u> and click the **Drivers/Downloads** tab on the Product Page.





 Under Driver(s), download the [trigger] usb display adapter.zip driver package.


+ + C + Man.Comm.Th	r Tech.com/Million01				Q (2) \$	
	C as a second se	en k Dowlaats This tracter fast aan as anterstoldy This tracter fast tracter fast	50	P Booled de Naciona (Dere Carer () Beacher pricing Orweite an account		
	Overview Technical Specification	ns Assessmen	Drivers & Dovrdseeh	Product Support		
	Drivers & Downloads Warwite with Nervi Arg analysis equal usages (* Drivers) Drivers Markine (* Constructions) Drivers Markine (* Constructions) Drivers Markine (* Constructions) Drivers Markine (* Constructions) Drivers Markine (* Constructions) Drivers Markine (* Constructions) Drivers Drive	-		Taria to an Advitor the net allows many to a net of the set of the appendix of the set of the set of the appendix of the set to the set of the set Oppose the	d	

4. Right-click the zip folder that was downloaded and select **Extract All**, then follow the on-screen instructions.

File Explorer								-	- D >
⊙ New - 🔏			19 🙂 19 Set - 🖸	Ver	V Filer				
< → < ↑	n - H	lone >	Open Open in new window			× 0	Q. Search	Home	
r 🏫 Horee		~ Quick a	Educt AL.						
Desitop	',		7-2p Pin to Start Scan with Microsoft Defender				-		_
Documents	- 21		8 Sare					_	
Pictures		© Des ~ Favorite	Open with		O Pictures	papeersu bes	walipapers	MyShareFiles	() valipaper
🚞 between, pci	-	Viavonte	Give-access to Restore previous versions	>					
🚞 valpapes	1	X	Send to	>					
🍰 MyShareFiles		<u>^</u>	04						
🚑 valpapes		O A Rea	Copy						
📥 OneDrive - Perso	-	> Recent	Greate shortcut Delete						
🔲 This PC			Rename						
DVD Drive (D) CR		-	Properties						
(Citerra	~~~	(higger) all adapter	Sector .						=



5. In the list of extracted files, right-click the **Setup(.exe)** file and select **Run as Administrator**.




Note: If the **Run as Administrator** option is not available, it's likely that the installation file is attempting to be ran from within the zipped file. Please extract the files using the instructions in Step 5.

6. Follow the on-screen prompts to install the device drivers and restart the computer when prompted.






 Once Windows has restarted, connect the Built-In USB Host Port on the USB Display Adapter to an available USB Port on the Host Computer.



 Installation may take several seconds to complete. During the installation process the connected **Display Device(s)** might flicker, this is normal. Once the installation has completed, the Windows desktop will appear on the connected **Display Device(s)**.





Operation

Once the USB Display Adapter has been installed on the Host Computer, the Display Device(s) (and audio controller, if applicable) will operate within Windows the same as a Display Device connected directly to the Host Computer's Graphics Controller.

This section of the manual outlines the full array of Windows configuration options associated to the USB Display Adapter.

Display Configuration

Identifying Display Devices Within Windows Display Settings

Windows assigns Display Numbers to each connected Display Device, so that users can identify and differentiate each monitor. This is useful to understand the order and arrangement of each connected monitor, especially when multiple Display Devices are connected to the Host Computer.

The numbers assigned to the monitors indicate their position in the monitor arrangement. The primary monitor is typically assigned the number "1," and additional monitors are assigned subsequent numbers like "2,""3," and so on. These numbers help Windows identify which monitor users are referring to when making changes or adjustments in display settings.



To identify which number is assigned to each connected Display Device within Windows:

1. Right-Click anywhere on the Windows Desktop and select **Display Settings**.



 This will open the Windows Settings app to the Display tab. Below Select a display to change the settings for it, you will see a diagram representing the current monitor arrangement and the Display Number assigned to each monitor.

Inducating D	Select a display to change the	settings for it. Drag displays to	rearrange them.	
System Bluetooth & devices Network & internet		1	2	
Personalization Apps Apps Accounts Time & language Gaming	Bulliple displays Occurs for presentatio	on mode for your displays	Mently End	nd these displays 🗠
* Accessibility	🗌 Make this my m	ain display dow locations based on monitor	r connection	



3. To identify a specific monitor, click on the **Identify** button located just below the monitor arrangement diagram.

Find a setting D	System > Display Select a display to change the settings for it. Diag displa	eys to rearrange them.	
System Bluetooth & devices Network & internet Personalization	1	2	
 Accounts Time & language 	Bhiliple ciqlaps	Mently Extend these displ	nys -
 Gaming Accessibility Privacy & security Windows Update 	Coose the presention mode for your display Make this my main display Entermine window locations based on my	onitor connection	
Windows Update	Minimize windows when a monitor is diso	connected	

 Windows will display a large number on each monitor briefly. Watch for the numbers to appear on the screens. Each number that appears will correspond to a specific monitor.



The number that is associated to each connected Display Device are now identified within Windows.



Configuring Display Devices for an Extended Windows Desktop

Extending the Windows Desktop provides users with the ability to expand their workspace across multiple monitors. The mouse cursor can edge-scroll between each monitor and use them as an extension of the primary monitor.

With extended desktops, users have more screen real estate to work with and can have different applications, documents, or windows open on each monitor. This makes it easier to multi-task, compare information, or work on multiple projects simultaneously.

To configure a Display Device as an extended Windows Desktop:

1. Right-Click anywhere on the Windows Desktop and select **Display Settings**.





- This will open the Windows Settings app to the Display tab. Below Select a display to change the settings for it, you will see a diagram representing the current monitor arrangement and the Display Number assigned to each monitor.
- 3. Click the Display Number that corresponds to the monitor that will be configured for Extended Windows Desktop. The selected monitor will become highlighted.

<- Settings				- 0 ×
all minutes	System > Dis	play		
	Select a display to change th	e settings for it. Drag displays I	to rearrange them.	
Rind a satting D				
🖬 System				
0 Bluetooth & devices		1	2	
 Network & internet 			-	
/ Penanalization				
📓 Acos				
Accounts			Identity	Extend these displays ~
3 Time & language				
Gaming	D Multiple displays Crosse the presented	tion mode for your displays		^
X Accessibility	Make this my	main display		
Privacy & security	Remember wit	ndow locations based on monit	w consultion	
 Windows Update 	-	tows when a monitor is disconn		
	Detect other displa	a		Detect
	Brightness & color			

Note: It's possible that two numbers may appear within the same monitor block. This indicates that the monitors are currently configured for a mirror configuration. If the desired Display Number appears within the same monitor block as another number, simply select that monitor block which contains the desired Display Number.





 Select the drop-down menu within the section below Select a display to change the settings for it and select Extend these displays.

n Seriega	- o x
1 8 8 8 8 S S S	System > Display
	Select a display to change the settings for it. Drag displays to rearrange them.
Find a satting D	
System	
0 Bluetooth & devices	1 2
 Network & internet 	
/ Penanalization	
Acos	
Accounts	Mentify Extend these displays -
Time & language	
Gaming	Multiple displays Coose the presentation mode for your displays
* Accessibility	Make this my main display
Privacy & security	
S Windows Update	Remember window locations based on monitor connection
	Minimize windows when a monitor is disconnected
	Detect other clopiny Detect

Note: On Windows 10 and earlier versions, it will be necessary to scroll to a lower location within the **Display tab** of the **Windows Settings** app ,to a section called **Multiple Displays** to access the drop-down menu. However, the remaining steps are the same.

Settings		-	•	×
命 Display				
Advanced scaling settings				
Display resolution				
1920 × 1080 (Recommended) V				
Display orientation				
Landscape \vee	6			
Multiple displays				1
Multiple displays	-			
Extend these displays				
Make this my main display				
Connect to a wireless display				



5. The settings will apply and a notification will appear on the screen, with a timer requesting that the new settings be confirmed. To confirm the settings click **Keep changes** before the timer expires.

> Keep these display settings? Reverting to previous display settings in 13 seconds. Keep changes Revert

The Display Device has now been configured as an extended Windows Desktop.



Arranging Display Devices in an Extended Windows Desktop

When Display Devices are configured for an Extended Windows Desktop, the mouse cursor can edge-scroll between each monitor, by moving the mouse off one screen and onto another.

In order for the cursor edge-scrolling function to be intuitive it's important that the Display Device arrangement in windows matches the physical arrangement of each monitor on the workstation.

To arrange Display Devices in Extended Windows Desktop:

1. Right-Click anywhere on the Windows Desktop and select **Display Settings**.





 This will open the Windows Settings app to the Display tab. Below Select a display to change the settings for it, you will see a diagram representing the current monitor arrangement and the Display Number assigned to each monitor.

	Select a display to change the setti	ngs for it. Drag displays to	reamange them.			
Find a satting D						
System						
Bluetooth & devices		1	2			
 Network & internet 						
/ Penanalization						
Acce						
			Identify	Extend these	displays -	
Acos			MentPy	Extend these	displays -	
Accounts	Multiple displays Ocore the presentation rec	de for your displays	Identify	Extend these	dişikçi -	
Apps Accounts Time & language	Multiple displays Cross for presentation mo Multiple displays Cross for presentation mo Multiple five my main d		Mexity	Extend these	displays -	
Apps Accounts Time & language Gaming	Docie the presiduation no	iqilay		Extend these	displays -	
Acos Accounts Trime & language Gaming Accountility	Orosie the presintation mo Orosie the presintation mo		connection	Extend these	displays -	

3. Observe the physical location of the monitors as they're setup on the workstation.



Note: You can click the Identify button to see which number corresponds to each physical display. See_Identifying Display Devices Within Windows Display_Settings (p.11) for more information.



4. Click and drag the Numbered Displays (within the **Display** tab of **Windows Settings**) so that the diagram matches the physical location of the monitors as they're setup on the workstation.

dinan.	- a × System > Display Seters - finance of the artiflings for it. Displayed and the model from	dinne.	- System → Display Select a dipolo for A. Drag dipolo to rearrange them.	0 ×
End a setting (2) E as System D Bustnoth & devices P Notech & Datamet P Promulization E Apps Answerk	1 2	Pend a setting P System D Rustroth & devices V Hotoch & devices Hotoch & devices Hotoch & devices Hotoch & devices Agen Agen	2 1 Bach Beet has shake	
 Time & language Gaming 	Multiple displays crosse the presentation mode for your displays ^	 Time & language Gaming 	Multiple displays Choice the presentation mode for your displays	^
X Accessibility	Dide this my main display	X Accessibility	Make this my main display	
Privacy & security Windows Update	Remember window locations bused on monitor connection	Privacy & security Windows Update	Remember window locations based on monitor connection	
 windows upeaks 	Minimize windows when a monitor is disconnected	windows upparts	Minimize windows when a monitor is disconnected	
	Dataset other display Betact		Defect other display Defect	
	Brightness & color		Brightness & color	






5. Once the arrangement has changed, **Apply** and **Cancel** buttons will appear. Click the **Apply** button to implement the changes.

er en	p	System > D	e the settings for it. Drag displays (is menange them.	
System Disetsoth & devices Network & internet / Personalization			2	1	
Apps Accounts Time & language Gamma		Avery D March Congress	Canad S	Identify	Datend these displays ~
 Accessibility Privacy & security Windows Update 		e this	ny main display window locations based on monit indows when a monitor is discore		

6. The settings will apply and a notification will appear on the screen, with a timer requesting that the new settings be confirmed. To confirm the settings click **Keep changes** before the timer expires.



The Display Devices have now been arranged in Windows.

Configuring Display Devices for a Mirror Configuration

Mirroring the Windows Desktop provides users with the ability to duplicate their screen onto another monitor or display.

With a Mirror Configuration, users can easily duplicate the content on screen to multiple displays for presentations or demonstrations. It allows the presenter to display their screen on a larger monitor or projector, ensuring that the audience can see exactly what is being shown on the presenter's screen.

To configure a Display Device for a Mirror Configuration:

- 1. Right-click anywhere on the Windows Desktop and select **Display Settings**.
- This will open the Windows Settings app to the Display tab. Below Select a display to change the settings for it, you will see a diagram representing the current monitor arrangement and the Display Number assigned to each monitor.





3. Click the Display Number that corresponds to the monitor that will be configured for a Mirror Configuration. The selected monitor will become highlighted.

🗱 ann 📖	System > Display	p for it. Drag displays to	leanange them.	
End a unting D System System Bluetorth & devices Network & internet Personalization Apps		1	2	
Accounts Time & language Gaming	Multiple displays Occur the presentation mode	for your displays	Identify	Extend these displays -
Accessibility Privacy & security Windows Update	Malas this my main dis	play ations based on monitor	connection	
	Minimize windows whe	n a monitor is disconnes	cted	Detert

Note: It's possible that two numbers may appear within the same monitor block. This indicates that the monitors are currently already configured for a mirror configuration. However, it may not be in the desired mirror configuration. If the desired Display Number appears within the same monitor block as another number that's not the desired configuration, the monitors will need to be separated into an Extended Configuration. To separate the monitors into an Extended Configuration, follow the steps outlined in the <u>Configuring Display Devices for an Extended Windows</u> <u>Desktop (p.14)</u> section of this manual.





 Select the drop-down menu within the section below Select a display to change the settings for it and select Extend these displays.

n senge	- c × System > Display Ment a display to reway the retries for 1, Day display to rewayer twee.
System System Biustooth & devices Network & internet Presonalization	1 2
Apps Accounts Time & language Gaming	Monthly Deploy These Signings Operating sequences in making your drivings A
Accessibility Privacy & security Windows Update	Mala Nin my wain diplay Marante window location location Manual Annual Annua
	Comments and/or where a monitor is and/ordered Detect other duplay Detect

Note: On Windows 10 and earlier versions, it will be necessary to scroll to a lower location within the **Display tab** of the **Windows Settings** app ,to a section called **Multiple Displays** to access the drop down menu. However, the remaining steps are the same.

Settings		-	×
ŵ Display			
Advanced scaling settings			
Display resolution			
1920 × 1080 (Recommended) V			
Display orientation			
Landscape \vee	D		
Multiple displays			1
Multiple displays			
Duplicate these displays			
Make this my main display			
Connect to a wireless display			



5. The settings will apply and a notification will appear on the screen, with a timer requesting that the new settings be confirmed. To confirm the settings click **Keep changes** before the timer expires.



The Display Device has now been configured for a Mirror Configuration.

Configuring Resolution for Display Devices in Windows

The output resolution for the Display Devices connected via the USB Video Adapter can be adjusted within Windows.

To configure resolution for Display Devices in Windows:

- 1. Right-click anywhere on the Windows Desktop and select **Display Settings**.
- This will open the Windows Settings app to the Display tab. Below Select a display to change the settings for it, you will see a diagram representing the current monitor arrangement and the Display Number assigned to each monitor.





3. Click the Display Number that corresponds to the monitor that will be configured for a Mirror Configuration. The selected monitor will become highlighted.

at the second	System > Display Select a display to change the settings for it. Drag display	s to rearrange them.
Ind a unting D System Elustrooth & devices Network & internet Personalization	1	2
Accounts		Mertify Extend these displays ~
	Multiple displays Oncore the presentation mode for your displays	
	Multiple singlary Crose the presentation mode for your display Malae this may main display Zemember window locations based on more	

Note: You can click the Identify button to see which number corresponds to each physical display. See Identifying Display Devices Within Windows Display Settings (p.11) for more information.



 Scroll down the screen to the Scale & Layout section and click the drop down menu titled Display Resolution, and select the desired resolution.

Note: Only resolutions supported by the Display Device, or USB Display Adapter will be available.

serings	System > Display	- 0 ×
ind a setting P	Night light Use warner colors to help black blue light	or
System Bluetooth & devices	HDR More about HDR	>
Network & internet Personalization	Scale & layout	
Apps	Scale Change the size of test, apps, and other items	100% (Recommended)
Accounts Time & language	ID: Display resolution Adjust the resolution to fit your connected display	1680 × 1050 ~
Garring Accessibility	EP Display orientation	Landscape 🔍
Privacy & security	Multiple displays Choose the presentation made for your displays	~

5. The settings will apply and a notification will appear on the screen, with a timer requesting that the new settings be confirmed. To confirm the settings click **Keep changes** before the timer expires.

everting to previous displa	ay settings in 13 seconds
Kana akanana	Revert
	Keep changes

The Display Device has now been configured to the desired resolution.



Audio Configuration

The HDMI output port on this product features an audio controller to output audio via the HDMI output.

Selecting a Playback Device in Windows

Once the USB Display Adapter has been installed on a Hot Computer, Windows will recognize it's audio controller as a playback device, which will give the Host Computer the ability to output audio via the HDMI output on the USB Display Adapter. The audio controller on the USB Display Adapter is separate and distinct from other audio controllers installed on the computer (such as the Host Computer's onboard audio controller), and Windows can only designate one controller at a time as it's active playback device.

To Select an Audio Controller as a playback device in Windows:

1. Right-click on the Volume icon in the quick settings panel and select **Open Volume Mixer**.





2. This will open the **Windows Settings** app to the **Sound** and **Volume mixer** tabs. Click the drop menu titled **Output Device**, and select the desired audio output device.

← Settings	System > Sound	- • × Volume mixer
Find a setting ${\cal P}$	Volume	d) 88 <u> </u>
 System Bluetooth & devices 	(마) Output device	BenQ GW2780 (NVIDIA High Definition Audio)
Network & internet Personalization	Q Input device	Speaker (Realtek(R) Audio) Microphone Array (Realtek(R) Audio)
Apps	Apps	
 Accounts Time & language Gaming 	System sounds	• ~

The selected Audio Controller is now set as the active playback device.



Troubleshooting

This section of the manual aims to provide a comprehensive troubleshooting guide for this USB Display Adapter. The purpose is to assist users in resolving common issues that may occur during operation. The guide will present solutions to address common issues. Each solution will be clearly outlined to ensure a straightforward troubleshooting process.



Setup Notes & Recommendations:

- This device is only supported in Windows operating systems.
- This device provides video output only, and cannot be used to input or capture video to the Host Computer.
- USB Display Adapters require an existing video card or integrated graphics chip from Intel, AMD, or NVIDIA. A WDDM (Windows Display Driver Model) compatible driver must already be installed prior to installing the driver for this product. Most computers from 2007 or newer will meet this requirement.
- Make sure any outstanding Windows updates are installed to ensure the **Host Computer** is running the most up-to-date version of Windows.
- The following only applies to computers running Windows 8.1 and earlier operating systems. The software from other USB display adapters, and some laptop docking stations, can interfere with the installation and operation of this USB Display Adapter. It's recommended that software from DisplayLink/Synaptics, Silicon Motion, and Fresco Logic be removed prior to installing the driver for this product.
- It's recommended that all available onboard video output ports are exhausted before adding a USB Display Adapter.
- USB32HD2 will not work at 4K if connected to a USB 2.0 port.

The Driver Will Not Install

This issue typically indicates that the installer file did not obtain the elevation required to install within the Windows operating systems.

To resolve this issue:

- Make sure the Setup(.exe) file has been extracted before running the application.
- Verify that the active user account has administrator privileges.

The USB Display Adapter Does Not Output Video

This issue typically indicates that the computer cannot access the device, or the driver for the USB Display Adapter is not fully installed.

To resolve this issue:

- 1. Please review the <u>Setup Notes and Recommendations (p.32)</u> within this troubleshooting section, and ensure all criteria outlined has been action on the Host Computer.
- 2. Unplug the USB adapter from the computer and reconnect it, using a different USB port.
- 3. Re-install the driver by following the steps outlined in the <u>Manual Driver Installation (p.6)</u> instructions of this manual.

Video Performance is Slow Compared to Other Displays

This issue typically indicates that there is not enough bandwidth available for the USB Display Adapter to perform optimally, or that the application requires greater resources than the USB Display Adapter can support.

To resolve this issue:

- Ensure that the USB port, that the USB Display Adapter is connected to, supports 5Gbps or faster. USB 480Mbps (USB 2.0) ports do not supply enough bandwidth for the USB Display Adapter to achieve full performance.
- 2. Make sure the latest driver for the product is installed.

Notes:

- Some applications (ex. AutoCAD, or other 3D design software) will not function properly when used on a USB connected display. These applications should be used on displays connected to the computer's video card or its onboard video outputs.
- The Host Computer may be at it's performance capacity. Testing the USB Display Adapter on a more powerful computer can confirm this.



The HDMI Output on the USB Display Adapter Does Not Output Audio

This issue typically indicates that the Audio Controller on the USB Display Adapter is not set as the active playback device in Windows.

To resolve this issue:

Follow the Steps outlined in the <u>Selecting a Playback Device in Windows (p.29)</u> instructions of this manual.

The USB Adapter Does Not Play Content From a Streaming Service, Blu-ray Disc or Other Media.

This issue typically indicates that the content playing is encrypted with High-bandwidth Digital Content Protection (HDCP). This USB Video Adapter does not fully support HDCP. As a result, some protected content will playback at lower quality while other content may not play at all. Similar products from other manufacturers will also have this limitation.

To resolve this issue:

It's recommend that the protected content be viewed on displays connected to the computer's video card or its onboard video outputs.

The Desired Output Resolution is Not Available

If the USB Display Adapter is spec'd to support the desired resolution, this issue typically indicates that there is not enough bandwidth available for the USB Display Adapter to establish maximum performance.

To resolve this issue:

- Ensure that the USB port, that the USB Display Adapter is connected to, supports 5Gbps or faster. USB 480Mbps (USB 2.0) ports do not supply enough bandwidth for the USB Display Adapter to achieve full performance.
- 2. Review the maximum supported resolution for this USB Display Adapter available on the <u>Product Diagram (p. 3)</u> section of this manual.

The USB Display Adapter Does Not Work With Certain

USB-A to USB-C Adapters

While properly pinned USB-A to USB-C Adapters will work with this USB Video Adapter, many of these USB-A to USB-C Adapters will drop pins which can prevent the USB Video Adapter from establishing a proper connection with the Host Computer.

To resolve this issue:

We recommend using our <u>USB31CAADP</u>. Alternatively, a direct USB-C Video Adapter to be used, such as <u>107B-USB-HDMI</u>.

The USB Display Adapter Does Not Power a USB-C Monitor

This device does not feature a USB-C video output and will not provide enough power to power a USB-C monitor.

To resolve this issue:

It's recommended that a dedicated USB-C output, with sufficient power, be used to power the USB-C monitor instead of the USB output on a USB Video Adapter, or any other buspowered downstream USB device.

The USB Display Adapter Will Not Work with an Adapter Cable That's Connected to it

This issue typically indicates that the Adapter Cable that's being used is not the correct orientation for the video output port on the USB Display Adapter. DisplayPort, HDMI and VGA Adapter cables will typically only work in one direction, and it's necessary that their input and output ports are the correct orientation for the respective video output and video input.

To resolve this issue:

Use an Adapter Cable that's the correct orientation for the video output port on the USB Display Adapter and the video input port of the Display Device.



The USB Display Adapter Does Not Capture a Video Input

This device provides video output only, and cannot be used to input or capture video to the Host Computer.

To resolve this issue:

Use a dedicated USB Capture Device such as the <u>StarTech.com USB3HDCAP</u>.



Compliance Statements

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- · Consult the dealer or an experienced radio/TV technician for help

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

PHILLIPS® is a registered trademark of Phillips Screw Company in the United States or other countries.



Safety Statements

Safety Measures

- Wiring terminations should not be made with the product and/or electric lines under power.
- Cables (including power and charging cables) should be placed and routed to avoid creating electric, tripping or safety hazards.

Mesures de sécurité

- Les terminaisons de câblâge ne doivent pas être effectuées lorsque le produit et/ou les câbles électriques sont sous tension.
- Les câbles (y compris les câbles d'alimentation et de chargement) doivent être placés et acheminés de façon à éviter tout risque électrique, de chute ou de sécurité

安全対策

- ・ 電源が入っている状態の製品または電線の終端処理を行わないでください。

Misure di sicurezza

- I terminiali dei fili elettrici non devono essere realizzate con il prodotto e/o le linee elettriche sotto tensione.
- I cavi (inclusi i cavi di alimentazione e di ricarica) devono essere posizionati e stesi in modo da evitare pericoli di inciampo, rischi di scosse elettriche o pericoli per la sicurezza.

Säkerhetsåtgärder

- Montering av kabelavslutningar får inte göras när produkten och/eller elledningarna är strömförda.
- Kablar (inklusive elkablar och laddningskablar) ska dras och placeras på så sätt att risk för snubblingsolyckor och andra olyckor kan undvikas.



Warranty Information

This product is backed by a three-year warranty.

For further information on product warranty terms and conditions, please refer to <u>www.startech.com/warranty</u>.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product.

Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.



Hard-to-find made easy. At StarTech.com, that isn't a slogan. It's a promise.

StarTech.com is your one-stop source for every connectivity part you need. From the latest technology to legacy products — and all the parts that bridge the old and new — we can help you find the parts that connect your solutions.

We make it easy to locate the parts, and we quickly deliver them wherever they need to go. Just talk to one of our tech advisors or visit our website. You'll be connected to the products you need in no time.

Visit www.startech.com for complete information on all StarTech.com products and to access exclusive resources and time-saving tools.

StarTech.com is an ISO 9001 Registered manufacturer of connectivity and technology parts. StarTech.com was founded in 1985 and services a worldwide market.

Reviews

Share your experiences using StarTech.com products, including product applications and setup, what you love about the products, and areas for improvement.

StarTech.com Ltd.

45 Artisans Cres London, Ontario N5V 5E9 Canada StarTech.com LLP 4490 South Hamilton Road Groveport, Ohio 43125 U.S.A. StarTech.com Ltd. Unit B, Pinnacle 15 Gowerton Rd, Brackmills Northampton NN4 7BW United Kingdom

StarTech.com Ltd.

Siriusdreef 17-27 2132 WT Hoofddorp The Netherlands

- FR: startech.com/fr DE: startech.com/de
- ES: startech.com/es
- NL: startech.com/nl
- IT: startech.com/it
- JP: startech.com/jp