Fiche Produit

Spécifications

Licence numérique, PowerChute Network Shutdown pour virtualisation et HCI, licence de 6 ans

SWPCNS6Y-DIGI

Présentation

Présentation	6-year license for PowerChute Network Shutdown. Contact your Partner to purchase this license.
Lead time	Généralement disponible en stock

Principal

gamme de produits	PowerChute Network Shutdown
fonction produit	Licence logicielle
Période de souscription	6 years
format	Clé digitale
Type de souscription	Payant
type de logiciel	License
licence	Digital
compatibilité de gamme	Easy UPS On-Line Smart-UPS Smart-UPS Ultra Smart-UPS Online Smart-UPS Modular Ultra
Nombre de phases d'entrées	1 3
Operating system requirement	VMware ESXi VMware vSAN Nutanix ESXi Nutanix AHV Dell VxRail HPE SimpliVity Cisco HyperFlex
langue utilisateur	Anglais

Complémentaire

Logiciel de programmation	PowerChute Network Shutdown software
fonction du logiciel	Activate PowerChute Network Shutdown

Disclaimer: This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications

Image of product / Alternate images

Alternative


PowerChute
WIN-RE6IKAHH8BD
Logout
Event Log
Delete Log File
Export Log
Date
Time
Event

PowerChute

PowerChute

PowerChute


PowerChute
Logout
Configuration
Virtualization
UPS Configuration
Help
Return License
Update

License Details

This section contains information about your current license.

License	
Quantity	1
Activation Date	Wed Dec 08 00:00:00 IST 2021
Renewal Date	Sun Mar 31 23:59:59 IST 2024
Device ID	
Activation ID	

Update License

Quantity: 1
Proxy IP Address:
Proxy Port: 80
Proxy Username:
Proxy Password:

Looking for a license?
Find licenses on Schneider Electric Exchange


PowerChute
robot-vxrail-vm
Logout
Home
Configuration
Virtualization
UPS Configuration
Help
High
RHEL8_3
Medium
Low
Group 1
Group 2
Remove
Set VM Migration Duration
Set VM Shutdown Duration
Set VM Startup Duration
Apply
Undo

VM Prioritization

Define the order in which VMs in the cluster are migrated, shut down and started according to their priority.

Warning - Zero second duration set for some groups below.

Enable VM Prioritization ☑

Prioritize VMs

Set VM Priority by selecting VMs from the list on the left and drag them to a group on the right.


PowerChute
robot-vxrail-vm
Logout
Home
Configuration
Virtualization
UPS Configuration
Help
vCenter Server Details
VxRail Manager Details
PowerChute Access
PowerChute Security
Check Details
Undo