




45"-50" Triple Screen Ceiling Mount




650374

VESA Compatible

200x200/300x200
300x300/400x200
400x400/600x400





INSTALLATION MANUAL

 **Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact your local distributor for assistance.**

CAUTION

- Use with products heavier than the rated weights indicated may result in instability causing possible injury.
- Please closely follow the assembly instructions. Improper installation may result in damage or serious personal injury.
- Safety gear and proper tools must be used. This product should only be installed by professionals.
- This product is designed to be installed on concrete ceiling only.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Use the mounting screws provided and **DO NOT OVER TIGHTEN** mounting screws.
- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Required for Installation



Component Checklist

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact your place of purchase for a replacement.



mounting rail (x2)
A



collar (x3)
B



connecting bar (x3)
C



TV bracket (x6)
D



end cap (x2)
E

Component Checklist



pole (x3)
F



ceiling plate (x3)
G



end cap (x3)
H



end cap (x3)
I



end cap (x3)
J



cable clip (x6)
K



sliding nut (x14)
L



M8x12 (x18)
M



M8x80 (x9)
N



M8x10 (x2)
O



M8 (x9)
P



M6 (x12)
Q



D8 washer (x2)
R



locking piece (x6)
S



Double Ended
Crescent Wrench (x1)
T



3mm Allen Key (x1)
U



4mm Allen Key (x1)
V




5mm Allen Key (x1)
W




mounting template (x1)
X


Package M x3




M-A (x4)
M6x14



M-B (x4)
M8x16



M-C (x4)
M6x30



M-D (x4)
M8x35



M-E (x4)
D8




M-F (x4)
Ø15xØ8x5




M-G (x4)
Ø15xØ8x15

Package W x3







expansion bolt (x6)
W-A

1. Assemble the Pole




2. Attach Ceiling Plate to the Concrete Ceiling





Mark the exact location of mounting holes


Drill pilot holes





Insert the expansion bolts into the hole as shown. Once inserted, remove the washers and hex nuts.



Attach the hex nuts to the expansion bolts corresponding to the keyhole pattern found on the ceiling plate. Do not overtighten and leave a small gap so the ceiling plate will slide into the keyhole slots.







⚠ WARNING

Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.

3. Extend the Mounting Rail




4. Attach Collar to the Mounting Rail






Note: • Keep the mounting direction of collars are the same.
• Ensure the gap between the collar halves on both sides are equal.

5. Install the End Cap





6. Attach Mounting Rail to Pole




Once the rail has been determined, firmly tighten the bottom rail to the mounting poles as shown prior to mounting the displays.

7. Install the Plastic Cover





8. Tilt Adjustment






-20° is the natural angle and the safety pin is unnecessary.

9. Attach TV Bracket





Position the adapter brackets as close as possible to the center of the display.




9a. Attach TV Bracket to Flat Back Screen




9b. Attach TV Bracket to Irregular Back Screen



Note: Choose the appropriate screws, washers and spacers (if necessary) according to the type of screen.


 **Do not overtighten screws.**

10. Hang the Screen





11. Secure with Padlock

Note: Leave at least 1mm gap between screens.




Note: Padlock is not included.

12. Level Adjustment



13. Cable Management



Maintenance

- Check that the bracket is secure and safe to use at regular intervals (at least every three months).