THERMAL PRINTER TSP700II SERIES

Hardware Manual



Radio Equipment Information:

Informations relatives à l'équipement radioélectrique :

Radiogeräteinformationen:

Informatie over de radioapparatuur:

Informazioni sulle apparecchiature radio:

Información sobre equipos de radio:

Informações de equipamento de rádio:

Radyo Ekipmanı Bilgileri:

Πληροφορίες περί ραδιοεξοπλισμού:

Informacije o radijski opremi:

Informacije o radijskoj opremi:

Information vedr. radioudstyr:

Radioaaltoja lähettävän laitteen tiedot:

Informasjon om radioutstyr:

Information om radioutrustning:

Informacja o urządzeniach radiowych:

Informace o rádiovém vyzařování přístroje:

Rádióhullám-kibocsátási adatok:

Informácie o rádiovom zariadení:

Informații privind echipamentele radio:

Informācija par radio iekārtu:

Radijo ryšio įrangos informacija:

Raadioseadme teave:

Informazzjoni tat-Taghmir tar-Radju:

Eolas faoi Threalamh Raidió:

2402 - 2480 MHz

max. 20 dBm (E.I.R.P.)

EU Declaration of Conformity

Konformitätserklärung

Déclaration de conformité

Declaración de conformidad

Dichiarazione di conformità

Verklaring van conformiteit

Izjava o sukladnosti

Izjava o skladnosti

Prohlášení o shodě

Uyumluluk Beyanı

Megfelelőségi nyilatkozat

Overensstemmelseserklæring

Försäkran om överensstämmelse

Vaatimuksenmukaisuusvakuutus

Konformitetserklæring

Declaração de Conformidade

Δήλωση συμμόρφωσης

Deklaracja zgodności

Vyhlásenie o zhode

Vastavusdeklaratsioon

Atbilstības deklarācija

Atitikties deklaracija

Dikjarazzjoni ta' Konformità

Declarație de conformitate

Декларация за съответствие

https://download.starmicronics.com/manual/CE_DoC/TSP700_CE_DoC_Newest.pdf

Italia: l'uso pubblico e soggetto ad autorizzazione generale da parte del rispettivo provider di servizi.

 $Noorwegen: \ Gebruik\ van\ radioapparatuur\ is\ niet\ toegestaan\ in\ het\ geografische\ gebied\ binnen\ een\ straal\ van\ 20\ km$

vanaf het centrum van Ny-Ålesund, Svalbard.

This statement will be applied only for the printers marketed in Europe.

UK Declaration of Conformity

https://download.starmicronics.com/manual/CE_DoC/TSP700_UK_DoC_Newest.pdf

FCC/IC Statement

https://download.starmicronics.com/manual/FCC/FCC_IC_Statement_Type4.pdf

Mexico Statement

LA OPERACIÓN DE ESTE DISPOSITIVO ESTA SUJETA A LAS SIGUIENTES CONDICIONES:

- a) Es posible que este equipo o dispositivo no cause interferencia perjudicial.
- b) Este equipo o dispositivo debe aceptar cualquier tipo de interferencia, incluyendo la que pueda causar su operación no deseada.

Caution Symbol

<u>^</u>	Caution for connections: This is an external device drive connector. Connecting to a telephone line may result in electric shock or malfunction. Do not connect to a telephone line.
	Caution for static electricity: Do not touch the print head as it may be damaged by static electricity accumulated in the human body.
	Caution for burns: The print head may be hot. Do not touch the print head. There is a risk of burns.
A	Caution for electric shock: The device contains high-voltage parts. Touching these parts may result in electric shock. Do not remove the fixed screw if you are not a service person.
	Caution for injury: Do not touch sharp parts. There is a risk of injury.

Trademark acknowledgments

TSP700II: Star Micronics Co., Ltd.

Notice

- All rights reserved. Reproduction of any part of this manual in any form whatsoever, without STAR's express permission is forbidden.
- The contents of this manual are subject to change without notice.
- All efforts have been made to ensure the accuracy of the contents of this manual at the time of going to press. However, should any errors be detected, STAR would greatly appreciate being informed of them.
- The above notwithstanding, STAR can assume no responsibility for any errors in this manual.
- All company and product names are trademarks or registered trademarks of their respective owners. (https://www.star-m.jp/eng/trademarks.html)


TABLE OF CONTENTS

1. Unpa	acking and Installation	6
1-1.	Unpacking	6
	Notes about Installation	
2. Parts	s Identification and Nomenclature	7
3. Setuj	p	8
3-1.	Connecting the Interface Cable to the PC	8
3-2.	Connecting the Interface Cable to the Printer	9
	Connecting the AC Adapter	
	Turning the Power On	
	Connecting to a Peripheral Device	
3-6.		
3-7.	Bluetooth Settings (For Bluetooth Interface Models only)	18
3-8.	Setup Precautions	
4. Attac	hing the Accessories	25
4-1.	Attaching the Holder Plate	25
4-2.		
4-3.	Switch Blind Installation	
	r Indicators	
5-1.	Recoverable errors	29
	Unrecoverable errors	
6. Preve	enting and Clearing Paper Jams	30
6-1.	Preventing Paper Jams	30
	Removing Paper Jam	
7. Main	tenance	31
7-1.	Thermal Head	31
7-2.	Platen Rubber Roller	
7-3.		
	Paper Holder the Suurounding Areas	

1. Unpacking and Installation

1-1. Unpacking

After unpacking the unit, check that all the necessary accessories are included in the package.





Note: The ferrite core and fastener provided with your printer depend on your printer configuration.

1-2. Notes about Installation


- 1. Choose a firm, level surface where the printer will not be exposed to vibration.
- 2. Make sure that the printer is connected to a reliable power outlet. It should not be on the same electric circuit as copiers, refrigerators, or other appliances that cause power spikes.
- 3. The power outlet you plan to connect to for power should be nearby and unobstructed.
- 4. Make sure that the printer is not exposed to direct sunlight.
- 5. Make sure that the printer is well away from heaters and other sources of extreme heat.
- 6. Do not locate the printer in a badly ventilated or dusty environment.
- 7. Make sure that the room where you are using the printer is not too humid.
- 8. This device employs a DC motor and switches that have an electrical contact point. Avoid using the device in environments where silicon gas can become volatile.
- 9. Use the printer within the boundaries indicated in the environmental requirements. Even when the ambient temperature and humidity are within the specifications, avoid radical changes in environmental conditions. The suitable operating temperature range is as follows:


Operating temperature: 5°C to 45°C

10. When disposing of the printer, obey local regulations.

^{*} Accessories vary depending on the model and the region where the printer was purchased.

2. Parts Identification and Nomenclature






The ID label is on the bottom or rear of the product.

3. Setup

3-1. Connecting the Interface Cable to the PC


3-1-1. Parallel Cable

Connect the parallel cable to a parallel port on your PC.




3-1-2. RS-232C Cable

Connect the RS-232C cable to a RS-232C port on your PC.




3-1-3. USB Cable

Connect the USB cable to a USB port on your PC.



3-1-4. Ethernet Cable

Connect the Ethernet cable to a USB port on your PC.



3-2. Connecting the Interface Cable to the Printer

Printer cables are not included in the package.

Obtain an appropriate cable that complies with the specifications beforehand.


Because the appropriate interface cable differs depending on the system that you are connecting the printer to, contact the dealer that you bought the product from if you are unsure about what cable to use.

Before connecting or disconnecting an interface cable, be sure to disconnect the AC adapter's power cord from the outlet.


3-2-1. Parallel Interface Cable

To connect a parallel cable, follow the procedure given below.


- (1) Make sure the printer is turn off.
- (2) Affix the ferrite core onto the cable as shown in the illustration.




(3) Pass the fastener through the ferrite core.



(4) Loop the fastener around the cable and lock it. Use scissors to cut off any excess.




- (5) Connect the interface cable to the connector on the rear panel of the printer.
- (6) Fasten the connector clasps.



3-2-2. RS-232C Interface Cable


- (1) Make sure that the AC adapter's power cord is not connected to the outlet.
- (2) Connect the interface cable to the connector on the rear panel of the printer.
- (3) Tighten the connector screws.



3-2-3. USB Cable

To connect a USB cable, follow the procedure given below.

- (1) Make sure that the AC adapter's power cord is not connected to the outlet.
- (2) Connect the USB cable to the USB port.
- (3) As shown in the figure, pass the cable through the cable hooks to hold it in place.




3-2-4. Ethernet Cable


If a ferrite core is included, install the ferrite core onto the Ethernet cable according to the following procedure to prevent electrical noise.

If a ferrite core is not included, perform steps (1) and (5) only.


When using an Ethernet cable that is 10 cm or less, shielded cable is recommended.

- (1) Make sure the printer is turned off.
- (2) Install the ferrite core onto the ethernet cable as shown in the illustration below.
- (3) Pass the fastener through the ferrite core.
- (4) Loop the fastener around the cable and lock it. Use scissors to cut off any excess.





(5) Connect the interface cable to the connector on the rear panel of the printer.



■ Link disconnection detection feature

The Ethernet interface model is equipped with a link disconnection detection feature.

If the printer is turned on when an Ethernet cable is not connected to it, the POWER and ERROR lamps are simultaneously turned on and off at 4-second intervals to indicate the disconnection.

Be sure to connect the Ethernet cable from a PC or hub to the printer, and then turn the printer on.

3-2-4-1. Initialize Communication Settings


When disposing of the product, initialize it from the viewpoint of information protection. For the initialization procedure, refer to IFBD-HE07/08-BE07 User's Manual or IFBD-HI01X/02X Setup Manual..

3-3. Connecting the AC Adapter

Note: Before connecting or disconnecting the AC adapter, make sure that the printer and all the devices connected to it are turned off.

Then remove the power cord from the outlet.

- (1) Connect the AC adapter to the power cord.
- (2) Connect the AC adapter to the connector on the printer.
- (3) Insert the power cable plug into an AC outlet.



When disconnecting the cable, take hold of the cable connector to pull it out. Releasing the lock makes it easy to disconnect the connector:

Pulling the cable excessively could cause damage to the connector.

Note: We recommend that you use the standard AC adapter and power cord.


If you are not using the optional AC adapter (PS60A-24B1 series) and are instead preparing your own power supply, note the following points.

- Use a power supply that is 24 VDC \pm 10% and 2.1 A or more. (Select a power supply with current capacity that is appropriate for the actual printing ratio.)
- Use a power supply that supports with SELV output or LPS (Limited Power Source).
- Take into consideration the noise in the environment that the printer is installed in, and take appropriate measures to protect the printer from static electricity, AC line noise, etc.

3-4. Turning the Power On

Connect the power cord according to the procedure in section 3-3, "Connecting the AC Adapter".

Turn on the power switch, which is on the front side of the printer. The POWER lamp on the control panel will light.




3-5. Connecting to a Peripheral Device

You can connect a peripheral device to the printer using a modular plug. Follow the procedure given below.

- (1) Make sure that the AC adapter's power cord is not connected to the outlet.
- (2) Connect the modular jack plug to the peripheral drive connector on the rear panel of the printer. Connect the other end of the cable to the modular jack of the peripheral device.


CAUTION: Do not connect a telephone line to the peripheral drive connector. Doing so may cause the printer to malfunction. Also, for safety purposes, do not connect a wire that may carry excessive voltage to the peripheral drive connector.



3-6. Loading a Paper Roll


Use a paper roll that complies with the printer specifications.

(1) Push the cover open lever, and open the printer cover.




(2) If the thickness of the paper is 65 to 99 μ m, install the tension bar on the printer as shown. If the thickness of the paper is 100 to 150 μ m, it is not necessary to install the tension bar.


Note: A tension bar cannot be installed when a roll paper guide is installed in a printer. Please remove the roll paper guide and then install the tension bar.



- (3) Firmly press the tension bar until it clicks into place.
- (4) After the tension bar is installed, please install the roll paper guide again.




(5) Load the paper roll into the printer in the direction indicated by the figure, and pull the leading edge of the paper straight toward you.



Note: Make sure not to pass the paper under the tension bar. In the following condition, remove the tension bar unit and change the adjustment lever position in accordance with the procedures described in paragraphs 3-6-2 and 3-6-3:

* Paper thickness between 100 μm and 150 μm, or paper width of 57.5 mm on the vertical/wall-mount layout.

(6) Push on both sides of the rear cover to close it.



Note 1: Be careful not to pull the paper out at an angle, because doing so may cause the paper to jam or skew.

- 2: Be sure not to close the printer cover by pushing only one side.
- 3: Be careful not to get your fingers caught when opening or closing the printer cover.
- 4: After the printer cover is closed, the printer performs initial operations (from paper feeding to paper cutting). Do not open the printer cover until the initial operations are complete.

3-6-1. Compliant Paper Roll Specifications

Paper thickness		65 to 75 μm: \$\phi18\pm18\pm1mm(Core outer), \$\phi18\pm18\pm1mm(Core outer)\$	
	Thermal Paper	65 to 75 μm: \$\phi 32\pm 1mm(Core outer), \$\phi 25.4\pm 1mm(Core outer)	
		75 to 150 μm: \$\phi32\pm 1mm(Core outer),\$\phi25.4\pm 1mm(Core outer)	
	Thermal Label Paper	Max.150 μm	
Paper width	Thermal Paper	79.5 ± 0.5 mm or 82.5 ± 0.5 mm or 57.5 ± 0.5 mm	
	Thermal Label Paper	79.5 ± 0.5 mm or 82.5 ± 0.5 mm	
External dimensions			
• Roll diameter		Max. φ100 mm	
• Take up paper roll width		80 ^{+0.5} ₋₁ mm / 83 ^{+0.5} ₋₁ mm / 58 ^{+0.5} ₋₁ mm	
Printed surface		Outer edge of roll	

Note 1: Do not glue or tape the paper roll and shaft core together.

- 2: Do not fold the tail end of the paper.
- 3: For details on recommended thermal paper, see the following webpage.


https://www.star-m.jp/prjump/000089.html


3-6-2. Removing the Tension Bar

When using thermal paper roll, the tension bar unit may or may not be necessary, depending on the paper thickness, paper width, or the installation layout. If the tension bar unit is unnecessary, remove it in accordance with the procedure indicated below. The tension bar unit is unnecessary when using full-face thermal label paper roll or thermal label paper roll (tack label paper).


Installation layout	Horizontal			Vertical/wall-mount		
Paper width (mm)	82.5	79.5	57.5	82.5	79.5	57.5
Paper thickness between 65 μm and 100 μm	Necessary	Necessary	Necessary	Necessary	Necessary	Un- necessary
Paper thickness between 100 μm and 150 μm	Un- necessary	Un- necessary	Un- necessary	Un- necessary	Un- necessary	Un- necessary








Use a flat head screwdriver as shown to remove the clips at both ends of the tension bar. Then, remove the tension bar unit.




3-6-3. Changing the Adjustment Lever Position

The adjustment lever position must be changed in accordance with the paper thickness. It is factory-set to position 1. When using paper thickness between 100 and 150 μ m, change the adjustment lever position in accordance with the procedure below.




As shown, use a flat head screwdriver to move the adjustment lever inward. Then, lower the adjustment lever to the position in which the protrusion on the adjustment lever engages with the hole in the frame.

Note:Do not use position 2.



Position 1 Paper thickness between 65 μm and 105 μm




Position 3
Paper thickness
between 105 μm and 150 μm


3-6-4. Removing the Roll Paper Guide

When using a paper roll with an 82.5 mm width, remove the roll paper guide as shown.


When using a paper roll with a 57.5 mm width, remove the roll paper guide, and install the roll paper guide into the other groove. When you change the effective print width (paper roll width), change the printer utility's memory switch setting. For details, see the printer utility help.

Note: After using a paper roll with a width of 57.5 mm, do not change to a paper roll with a width of 79.5 or 82.5 mm. This is because the printer head has deteriorated as a result of a portion of the head having been in direct contact with the platen.





3-7. Bluetooth Settings (For Bluetooth Interface Models only)



<LED>Indicates the status of the Bluetooth interface.

Green (on): Not connected.

Green (flashing): Ready to start pairing.

Blue (on): Connected.


Purple (flashing): Auto connection ON.

Pair the printer with the master device by following the procedure below.


3-7-1. Pairing using SSP (Simple Secure Pairing) [Default]

(1) Working on the master device, tap [Settings] and set [Bluetooth] to ON.





(2) After turning the printer's power switch on, press and hold the PAIR button on the rear interface of the printer for 5 seconds or more, and then release it. The LED will flash green.



(3) Pairing will be possible for 60 seconds from when the LED begins flashing green. During this time, execute "Search for devices" from the master device and tap the relevant device from the displayed list.

Device name: Star Micronics (default)

- (4) In an iOS device, after pairing, the LED will automatically begin flashing blue, and the printer will be automatically connected. In an Android device, the LED turns blue only while data is sent.
- (5) Connect to the printer from the master device application and perform printing. If the printing is successful, the pairing process has been completed.

Note: The printer performs various processes immediately after connecting to or disconnecting from a master device.

Please wait approximately 0.1 seconds after connecting, and approximately 0.5 seconds after disconnecting, before beginning communications with the printer.

3-7-2. Pairing using PIN code

Enter the following information in the master device if it does not support SSP, or when otherwise necessary.

PIN: 1234 (default)

Device name: Star Micronics (default)

It is recommended that you change the PIN code for greater security.

For details regard changing the PIN code, please see the "Software Manual -Star Bluetooth Utility-".

3-7-3. Auto Connection Function (iOS only)

Each time the wireless connection is disconnected while communicating with upper-level iOS devices including iPad over Bluetooth, it is necessary to move back to the Bluetooth setting screen in the upper-level iOS device and tap the desired printer name again to build a connection. This is an iOS specification.


In order to save this labor, this printer is equipped with the Auto Connection function that automatically requests a connection from an upper-level iOS device that was connected to the printer last time.

The default setting of this function may differ according to the printer model you are using.

Confirm the default settings for your printer, as well as the use examples for ON/OFF settings, and then make the settings to match your purpose.

You can also check the current ON/OFF setting by performing self-printing.

< Confirmation procedure by self-printing >



- (1) While the printer cover is closed, hold down the FEED button on the operation panel, and then turn on the power switch.
- (2) Self-printing starts and the settings for F/W version, DIP switch, memory switch, and so on are printed.
 - Subsequently the interface information is printed and finally the current ON/OFF settings are printed.

Caution: If "Auto Connection function" is set to ON when using devices other than iOS, a Bluetooth communication with the printer may fail. To use devices other than iOS, such as the Android/Windows devices, make sure you turn off the "Auto Connection" function before using the printer.

For information on how to set up this function, see "3-7-4. Setting up Auto Connection".

See the table below for details of Auto Connection setting.

	Auto Connection ON	Auto Connection OFF
Reconnecting without changing the master device	After the printer is turned on, it automatically connects to the last master device that was connected.	After turning on the printer, tap this printer's name on the Bluetooth settings screen on the master device.
Changing the connected master device	Disconnect the Bluetooth connection in such a way as to turn OFF the power to the upper-level device automatically connected. Then, establish a pairing with a desired master device.	After turning on the printer, establish a pairing with a desired master device.
Example (recommended)	When connecting directly to the printer from one master device.	When using the printer with multiple master device.


3-7-4. Setting up Auto Connection

◆ Setting up from the Main Unit for the TSP700II

Note: The following procedure explains how to change the Auto Connection function setting from ON to OFF.

If you want to change it from OFF to ON, please follow the same procedure.

- (1) When paper is loaded in the printer and it is turned on, the [POWER] LED(green) on the front of the printer turns on.
- (2) If you hold down the [RST] button on the back of the printer for at more than five seconds, initial operations are performed in the same way as when the power is turned on, and the LEDs on the front of the printer flash. If you press the [RST] button when the printer is placed upright, place it horizontally again while the LED is flashing.



(3) The following information is printed. After that, turn the printer off and then back on again to set "Auto Connection" to OFF.

< Current Setting > Auto Connection : OFF

To enable this setting, turn Printer Power OFF and turn ON.

(4) To make sure "Auto Connection" is set to OFF correctly, perform self-printing as described in "3-7-3. Confirmation procedure by self-printing".

Note: Only Bluetooth Firmware Version 2.0 or later allows you to switch ON/OFF by pushing the [RST] button. The Bluetooth Firmware version can be confirmed by self-printing. (For more information, see "3-7-3. Confirmation procedure by self-printing".)

◆ Setting from the Software


After pairing your device and the TSP700II, change "Auto Connection" in the following application provided by our company. Please download and use the utility soft from the following URL.

- iOS: https://www.star-m.jp/prjump/000003.html
- Android: https://www.star-m.jp/prjump/000004.html
- Windows: https://www.starmicronics.com/support/

3-7-5. Resetting Bluetooth Settings

The following procedure explains how to initialize settings that you have changed such as the PIN code, device name, and so on.

- (1) While inserting a thin object such as the tip of a pen and holding down the RST button on the rear of the printer, turn on the printer's power switch. The POWER LED (green) and the ERROR LED (red) on the front of the printer start flashing.
- (2) Hold down the RST button for 4 seconds or more (note 1), and then release it.



- (3) After you release the RST button, if the LED stops flashing and the POWER LED remains lit green within 12 seconds, initialization is complete. If the LED continues to flash for longer than 12 seconds after releasing the RST button, this indicates that initialization was not successful. Turn off the printer's power and then try again from step 1.
- (4) Turn off the printer's power switch and delete the pairing setup with the higher ranked device.

Note1: In step 2, if you do not hold down the RST button for long enough, initialization will not complete correctly.

For F/W Ver2.0, Ver3.0a, and Ver3.0b interfaces

In step 2, you need to hold down the RST button for 8 seconds or more.

Also, after finishing steps 1 to 3, to check that initialization was completed correctly, perform self-printing. If the second sheet (*** Bluetooth Information ***) is not printed, initialization has not been completed correctly. If this happens, turn off the printer's power, and then try again from step 1.

(You can check the firmware version from the self-printing results. See page 14 for the self-printing procedure.)

- 2: Do not turn off the printer during initialization; otherwise initialization will not complete correctly.
- 3: If initialization is not completed correctly, turn off the printer's power and then try again from step 1.

3-8. Setup Precautions

! WARNING

- If you notice smoke or strange odors coming from this product, turn the power switch off immediately, and remove the power cord from the AC outlet. For repairs, contact the dealer that you bought the product from.
- Never attempt to repair the product yourself. Doing so can be dangerous.
- Never disassemble or modify the product. Doing so may result in injury, fire, or electric shock.
- On models that have cutters or tear bars, do not touch the cutter blade or the tear bar.
 - There is a cutter or tear bar inside the paper outlet slot. Never put your hand in the slot regardless of whether or not the printer is in operation.
 - You must open the printer cover to replace paper. However, because the cutter blade or tear bar is located inside of the cover, be careful not to bring your face and hands too close to the blade or tear bar when the cover is open.
- During and immediately after printing, the area around the print head is very hot. Don't touch it because you could be burned.
- Be sure to turn off the printer before performing maintenance on the cutter. Failing to do so is dangerous.

! CAUTION

- We recommend that you unplug the printer from the power outlet whenever you do not plan to use the printer for long periods.
 - Because of this, you should locate the printer so that the power outlet it is plugged into is nearby and easy to access.
- If an AC cord set is supplied with the product, the power cord that is included has been specially designed for the product.
- Make sure that the printer and the PC are turned off and unplugged from their AC outlets before you make connections.
- Do not connect a telephone line to the peripheral drive connector, which is used for devices such as cash drawers.
 Doing so may cause the printer to malfunction. Also, for safety purposes, do not connect a wire that may carry excessive voltage to the peripheral drive connector.
 Do not open the printer covers while the printer is printing or cutting.
- Do not pull out paper when the printer cover is closed.
- If liquid or foreign objects (such as coins and paper) enter the inside of the printer, turn the power switch off, disconnect the power cord from the AC outlet, and consult the dealer that you bought the product from. Continuing to use the printer may lead to a short-circuit, which may cause electric shock or fire.
- The heating element and the driver IC of the thermal print head are easily damaged. Do not touch them with metal objects, sandpaper, etc.
- Do not touch the thermal print head heating element. Doing so may make it dirty, which will decrease the printing quality.
- Static electricity can damage the driver IC and other components of the thermal print head. Avoid touching it directly.
- Do not operate the printer if there is moisture (which has been caused by condensation or another factor) on the front surface of the head.
- This device is not suitable for use in the vicinity of children.

• The printing quality and the thermal print head's service life cannot be guaranteed if paper other than the recommended paper is used.

In particular, thermal paper containing Na+, K+, or C1- may drastically reduce the service life of the thermal print head. We recommend that you use paper with the following maximum ion densities: 500 ppm of Na+, 150 ppm of K+, and 300 ppm of Cl-.

For details on recommended thermal paper, see the following webpage.

https://www.star-m.jp/prjump/000089.html

CAUTION

Wireless Communication

- Do not use the device where using wireless devices is prohibited or may cause interference or danger.
- The radio waves generated by the device may interfere with the operation of electronic medical devices. If you are using any electrical medical device, contact its manufacturer for the restrictions on the use of the device.
- A distance of at least 20 cm {7.87"} must be maintained at all times between the antenna of this product and people in the vicinity. May exert electromagnetic interference on, and cause malfunction of, cardiac pacemakers.
- Security functionality for Bluetooth is installed in this product. Configure the security settings according to the manual (available on the Star Micronics website) to reduce the risk of security issues.
- This device supports Bluetooth.
 - Since this functionality may be limited by local regulations, first review the radio laws specific to the country in which the product will be used.
- Below is a list of laws this device has been approved by. As Star Micronics is committed to constant innovation, revisions may be made without an announcement. Access the Star Micronics website for the latest listing of approvals.
- Please refer to Star Micronics website for the latest information and manuals.

4. Attaching the Accessories

The following accessories are necessary when mounting the printer to a wall.

• Holder plate and two flangeless screws


The following accessories do not necessarily have to be attached. Attach it if necessary.

- Cable cover
- Switch cover


4-1. Attaching the Holder Plate

<Pre>coutions>

- The holder plate is attached to the printer using the included screws and is hooked onto screws that are installed into the wall.
- The screws on the wall are not included. Use commercially available screws (4 mm diameter) that are suitable for the wall material (wood, steel beam, concrete, etc.).
- The printer's weight is approximately 2.4 kg when the largest diameter roll paper is loaded. Use screws on the wall that have both shear strength and pulling-out strength to withstand a force of at least 12 kgf (118 N).
- (1) Attach the shaft to the printer.



(2) Wipe the area into which the rubber feet will be affixed in order to remove any grime; then, affix the roll stoppers. The positions for affixing them will vary depending on the paper width.




82.5 or 79.5 mm width


57.5 mm width

(3) Use a regular screwdriver to remove the clips at both ends of the bar to remove the tension bar unit.


Note: If the paper witdth is 79.5 or 82.5mm and the paper thickness is less than $100\mu m$, you do not need to remove the tension bar unit.



(4) Attach the holding plate to the printer. Then tighten the two screws that were supplied to secure it in place. Position the printer over the screws, etc., on the wall and then slide it downward to set it in place.



- (5) Push the cover open lever, and open the printer cover.
- (6) Insert the paper roll as shown.



- (7) To change the Paper Near End Sensor setting from "Horizontal" to "Vertical", change the MSW (Memory Switch) A-9 from "OFF (0)" to "ON (1)" as shown below.
 - Open the printer cover, then turn the power on while holding the FEED button.
 Continue holding down the FEED button until the POWER lamp and the ERROR lamp begin flashing.
 - 2. The printer will change the MSWA-9 setting (Horizontal/Vertical) when these have flashed for three seconds.
 - 3. Run the Self-test Printing to make sure that MSWA-9 is "ON (1)"

Precautions regarding installation


△ CAUTION


This caution indicates information that, if ignored, could lead to personal injury or property damage.


- Be sure to have qualified personnel install the specified screws and printer to the wall.
 - Star is not responsible for any accidents or injuries that occur as a result of improper installation, misuse, or modifications.
 - Especially when installing the printer at a high location, make sure that the printer is securely installed to the wall.
 - If the printer is not installed securely and falls, personal injury or damage to the printer may result.
- Make sure that the mounting surface and installation screws are strong enough to install the printer.
 - Securely install the printer so that the weight of the printer and any connected cables will not cause the printer to fall.
 - Otherwise, personal injury or damage to the printer may result.
- Do not install the printer in an unstable location or a location that is exposed to vibration and shocks.
 - If the printer falls, personal injury or damage to the printer may result.

4-2. Attaching the Cable

Attach the cable cover as shown in the illustration.








4-3. Switch Blind Installation

It is not necessary to install the switch blind. Only install it if it is necessary for you. By installing the switch blind, the following become possible.

- Preventing the power switch from being operated by mistake.
- Ensuring that other people can not easily operate the power switch.

Install the switch cover as shown in the diagram below.



The power switch can be turned ON (|) and OFF (O) by inserting a narrow instrument (ball pen etc.) in the holes in the switch blind.

5. Error Indicators

5-1. Recoverable errors

Check the recovery conditions. The printer can be recovered while maintaining its current status.

Error description	POWER	ERROR	Recovery condition
Thermal head high temperature detection error	Flashes at 0.5 second intervals	OFF	The printer recovers automatically when the thermal head cools.
Cover open error	ON	ON (Red)	The printer recovers when you close the cover.
Near end error	ON	Flashes orange lamp at 1 second intervals	The printer recovers when you set a new paper roll and close the printer cover.
Black mark error	ON	ON (Orange)	The printer recovers when you set a new paper roll and close the printer cover.
Paper out error	ON	ON (Orange)	The printer recovers when you set a new paper roll and close the printer cover.
Ethernet link disconnection detection (*1 (Physical link disconnection)	Flashes at 4 seo-nd intervals.	Flashes at 4 seo-nd intervals.	Connect an Ethernet cable. For details, see section 3-2-4, "Ethernet Interface Cable."
Ethernet link disconnection detection (*1 (IP address lost)	Flashes at 0.25 seond intervals.	Flashes at 0.25 seond intervals.	Set the correct IP address and restart the printer.

(*1: IFBD-HE07 only

5-2. Unrecoverable errors

Turn the printer off, check the recovery conditions, and then turn the printer back on.

If the same error occurs after you turn the printer back on, the printer needs to be repaired.

Error description	POWER	ERROR	Cause	Recovery condition
Cutter error	Off	Flashes red lamp at 0.125-second intervals	Paper cutting in progress error	After you restart the printer, the printer recovers when the mobile cutter returns to its home position. (Note 3, 4)
Flash memory error	Off	Flashes orange lamp at 0.5 second intervals	Flash memory access error	-
EEPROM error	Off	Flashes red lamp at 0.75 second intervals	This is not a recoverable error.	-
SRAM error	Off	Flashes orange lamp at 1 second intervals	RAM access error	-
Head thermistor error	Off	Flashes red lamp at 1.5 second intervals	Detection of head thermistor error	-
Power voltage error	Off	Flashes orange lamp at 2 second intervals	Detection of power voltage error	Check the condition of the power supply, and restart the printer.

- Note 1: If an unrecoverable error occurs, turn the power off immediately.
 - 2: A power voltage error may be a result of a power supply malfunction.
 - 3: If the paper is jammed, turn the power off, clear the jammed paper, and then turn the power back on. For details, see section 6-2, "Removing Paper Jams".

If you find an error other than the above, try turning the power off, and then on.

If the same error is displayed even after the power is turned on again, it may be a printer malfunction. Contact the seller.

6. Preventing and Clearing Paper Jams

6-1. Preventing Paper Jams

The paper should not be touched during ejection and before it is cut.


Pressing or pulling the paper during ejection may cause a paper jam, paper cutting failure or line feed failure.

6-2. Removing Paper Jam

If a paper jam occurs, clear it as described below.

- (1) Set the power switch to off to turn off power to the printer.
- (2) Push the lever toward you to open the printer cover.
- (3) Remove the jammed paper.
 - Note 1: To prevent parts such as the thermal head or the rubber roller from damage or deformation, do not forcibly pull on the paper with the printer cover closed.
 - Note 2: If label paper gets jammed, the glue from the labels could stick to the parts. If this occurs, make sure to wipe them clean of the glue.
- (4) Position the paper roll straight and close the printer cover gently.
 - Note 1: Make sure that the paper is positioned straight. If the printer cover is closed with the paper skewed, a paper jam may result.
 - Note 2: Lock the printer cover by pressing down on the sides. Do not try to close it by pressing down on the centre. The cover may not lock properly.
- (5) Set the power switch to on to turn on power to the printer. Make sure that the ERROR LED is not lit.

Note: While the ERROR LED is lit, the printer will not accept any commands such as the print command, so make sure that the printer cover is locked properly.



Caution Symbol





This symbol is placed near the thermal head to indicate that it may be hot. Never touch the thermal head immediately after the printer has been used. Let the thermal head cool for a few minutes before touching it. Never touch the thermal head with your hands because it can generate static electricity, which can damage the device in the thermal head.



This symbol is placed near the peripheral drive connector.

Do not connect this to a telephone.

7. Maintenance

Accumulation of paper dust and dirt may cause the printer to not print portions of characters.


To prevent such problems, perform periodic maintenance, such as removing paper dust from the paper transport section and removing the blackened paper dust from the thermal head surface.

As a guideline, clean the printer every six months.

Note: Turn the printer's power switch off before performing maintenance.

7-1. Thermal Head

To remove the blackened paper dust that has accumulated on the thermal head surface, wipe it clean with a cotton swab (or soft cloth) dipped in alcohol (ethanol, methanol, or isopropyl).



Note 1: The thermal head is easily damaged.

Be sure to clean the thermal head with a soft cloth, and be careful not to damage the head.

- 2: Do not clean the thermal head immediately after printing, when the thermal head is hot.
- 3: Be careful of static electricity while cleaning the thermal head. Static electricity can damage the head.
- 4: Turn the power on only after the alcohol has dried completely.

7-2. Platen Rubber Roller

Using a dry, soft cloth, wipe off the dirt from the rubber roller. Clean the entire rubber roller by rotating it.

7-3. Sensors and the Surrounding Areas

Clean the sensors (mainly the reflector type sensors) of debris, dust, paper particles, glue, etc. that may have accumulated.

7-4. Paper Holder the Suurounding Areas

Clean the paper holder of debris, dust, paper particles, etc. that may have accumulated.

