



AC-6014

USB-C Headset

In-line volume & mute control

Lights

Red - Microphone muted

Green - Microphone unmuted



Controls



Press once to mute the mic input;
Press again to unmute.



Press once to increase the volume.
Press & hold to increase the volume
continuously until maximum level.



Press once to decrease the volume.
Press & hold to decrease the volume
continuously until minimum level.

If you have a question about your Cyber Acoustics Headset,
contact us at www.cyberacoustics.com/support/contact

© 2025 Cyber Acoustics or its subsidiaries. All rights reserved. Cyber Acoustics and other trademarks are trademarks of Cyber Acoustics or its subsidiaries. Other trademarks are the property of their respective owners.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Unique Identifier: (AC-6014)

Responsible Party - Cyber Acoustics, Inc.
3109 NE 109th Ave., Vancouver, WA 98682
cyberacoustics.com



California Residents

WARNING: Cancer and reproductive harm---

www.p65warnings.ca.gov

<https://www.cyberacoustics.com/prop-65>



Compliance Information Statement:

FCC Part 15

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiving device
- Connect the equipment into an outlet on a different circuit from the receiving device
- Consult the dealer or an experienced radio/TV technician for help
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.