

# 2-Port USB DisplayPort™ Cable KVM Switch w/ Audio and Remote Switch - 4K 60Hz

# **Product Diagram (SV211DPUA4K)**



| Component |                               | Function  |
|-----------|-------------------------------|---|
| 1         | DisplayPort Connector         | Connect a DisplayPort Enabled Computer  |
| 2         | Microphone Audio<br>Connector | Connect the Microphone Audio to the Computer  |
| 3         | USB-A Connector               | Transmit the signal of a <b>Keyboard</b> and <b>Mouse</b> from the <b>KVM Switch</b> to the <b>Computer</b>                   |
| 4         | Microphone Audio Port         | Connect a Microphone  |
| 5         | Stereo Audio Connector        | Connect the <b>Speaker Audio</b> from the <b>Computer</b>   |
| 6         | USB HID Ports                 | <ul><li>Connect a Keyboard and Mouse</li><li>(Optional) Connect USB Peripherals</li></ul>                                     |
| 7         | DisplayPort Port              | Connect a <b>DisplayPort Display</b>  |
| 8         | LED Indicators                | Indicates Computer selection and activity   |
| 9         | Stereo Audio Port             | Connect Stereo Speakers   |
| 10        | Remote Switch                 | A wired button used to switch between Computer 1 and 2 Press and Release the Remote Switch to switch between Computer 1 and 2 |

# Requirements

- DisplayPort Enabled Computers x 2
- DisplayPort Display x 1
- USB HID Devices (Keyboard and Mouse) x 2
- (Optional) USB Peripherals x 2
- (Optional) Microphone x 1
- (Optional) Stereo Speakers or Headphones x1
- (Optional) Headset x 1

**Note:** A Headset may require the use of a Headset Adapter. Check with the manufacturer of the Headset for more details.

• (Optional) 3.5 mm Audio Cables x 2

For the latest requirements and to view the full User Manual, please visit www.startech.com/SV211DPUA4K.

## Installation

## **Connect the Computers**

- Connect the built-in Computer 1 DisplayPort Connector to the DisplayPort Port on Computer 1.
- 2. Connect the built-in **Computer 1 USB-A Connector** to the **USB-A Port** on **Computer 1**.
- (Optional) Connect the built-in Computer 1 Stereo Audio Connector (green) to the 3.5mm Stereo Audio Port on Computer 1.
- 4. (Optional) Connect the built-in **Computer 1 Microphone Audio Connector** (pink) to the **3.5m Microphone Audio Port** on **Computer 1**.
- 5. Repeat steps 1-4 to install **Computer 2**.

## **Connect the Console**

- Connect the USB-A Devices (Keyboard, Mouse, or USB Peripherals) to the USB-A Ports on the KVM Switch using the built-in Keyboard and Mouse USB Cables or USB-A Cables (sold separately).
- (Optional) Connect a 3.5 mm Audio Cable from the Stereo Speakers or Headphones to the Speaker Audio Port (pink) on the KVM Switch.
- (Optional) Connect a 3.5 mm Audio Cable from the Microphone to the Microphone Audio Port (pink) on the KVM Switch.

# Operation

## About the LED Indicators

| LED Behavior                 | Significance  |
|------------------------------|---|
| LED is illuminated<br>orange | A <b>Computer</b> is selected and a link has been established |
| LED is flashing orange       | A <b>Computer</b> is selected but not detected                |

## **Hotkey Reference Guide**

- Windows® Keyboard: To switch Computers the hotkey combination is Scroll Lock + Scroll Lock
- Mac Keyboard (or a Windows Keyboard with no Scroll Lock): Use the Included **Software** to define the new hotkey sequence.

**Note:** Each hotkey sequence keystroke should be pressed within two seconds.

### **FCC Compliance Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

### **Industry Canada Statement**

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two

(1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of thirdparty companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which

this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

### **Warranty Information**

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

## Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

## **Safety Measures**

· If product has an exposed circuit board, do not touch the product under power.

## Mesures de sécurité

· Si l'un des circuits imprimés du produit est visible, ne pas touchez le produit lorsqu'il est sous tension.

### 安全対策

製品に露出した状態の回路基盤が含まれる場合、電源が入っている状態で製品に触らないでください。

### Misure di sicurezza

• Se il prodotto ha un circuito stampato visibile, non toccare il prodotto quando è acceso.

## Säkerhetsåtgärder

Rör aldrig vid enheter med oskyddade kretskort när strömmen är påslagen.

## 45 Artisans Cres London, Ontario N5V 5E9 Canada

## 2500 Creekside Parkwy Lockbourne, Ohio 43137 U.S.A.

#### StarTech.com Ltd. StarTech.com LLP StarTech.com Ltd. FR: startech.com/fr DE: startech.com/de Unit B. Pinnacle 15 ES: startech.com/es Gowerton Rd, NL: startech.com/nl Brackmills IT: startech.com/it Northampton JP: startech.com/jp NN4 7BW **United Kingdom**