


Quick Setup

Before using the projector, make sure you read these instructions and the safety instructions in the online *User’s Guide*.

**Note:** *Your product may differ from the illustrations on this sheet, but the instructions are the same. Some product features may not be available in all regions.*

Contents

Make sure your projector box includes all of these parts:



You can place the projector on almost any flat surface. See the online *User’s Guide* for more information.


Connect the projector

Android TV™

Your projector includes built-in Android TV with apps that can be launched when the remote control is paired to the projector. To stream content, make sure you have a wireless Internet connection and log-in as necessary for each app.

Chromecast™ built-in

You can stream content from devices using Chromecast-compatible apps. See the online *User’s Guide* for details.



Google® Search


You can send voice commands to the projector using the remote control or a Google Home™ speaker. See the online *User’s Guide* for details.

**Note:** *This feature may not be available in all regions.*

Video device or computer

You can connect video equipment or a computer. Connect one end of an HDMI cable (not included) to one of the projector’s **HDMI** ports and the other end to an HDMI port on your video device or computer. See the online *User’s Guide* for details.

**Caution:** *Do not turn on the video source before connecting it to the projector; you may damage the projector.*



**Note:** *If you are connecting an external audio/video receiver to the projector, use the projector’s HDMI2 (ARC) port. See the online User’s Guide for more information.*

Connect audio


Built-in speakers

The projector has built-in speakers that can play audio from the video source you are viewing.

You can also use the projector’s speakers to play sound from a device connected via Bluetooth®. Press the button on the remote control or projector, then select the projector from your device. See the online *User’s Guide* for details.

Optical audio out port


You can connect the projector to an amplifier or speakers through the **Optical Out** port. See the online *User’s Guide* for more information.




Turn on your projector

**Note:** *If you are projecting from an external video device or computer, make sure it is connected to the projector first and turn it on after the projector is turned on.*

- 1 Plug in the projector.



- 2 Press the power button on the projector or remote control. The status light flashes blue and then stays on.




- 3 Follow the on-screen instructions to pair the remote control and projector, select your language, connect to your wireless network, and sign in to your Google account. You only need to pair the remote the first time you use it.


**Note:** *To shut down the projector, press the power button.*

Adjust the image


- 1 To adjust the image position, move the projector in the appropriate direction while keeping it level and parallel to the screen. You can also extend or retract the front feet to correct horizontal tilt or vertical distortion, if necessary.



- 2 Open the focus lever cover.



- 3 Move the focus lever up or down to adjust the image sharpness.




- 4 Close the focus lever cover.
- 5 If the image shape still requires adjustment, press the button on the remote control and use the directional and **Enter** buttons to adjust each point as needed.
- 6 Press the button on the remote control to return to the point selection screen. Press the button again when you are finished.

**Note:** *For more adjustment methods, see the online User’s Guide.*

Using the remote control

Install two AAA batteries as shown below.



**Note:** *You must first pair the remote control to the projector to use Android TV and video-on-demand features. See the online User’s Guide for more information.*

Troubleshooting

- If you see a blank screen, check the following:
  - Make sure your computer or video device is properly connected.
  - Make sure the power light on the projector is blue and not flashing.
  - Press the power button or the button on the projector or remote control to wake the projector from standby or sleep mode, if necessary.
- If you see a blank screen when a computer is connected, check the following:
  - If you’re using a Windows® laptop, press the function key on your keyboard that lets you display on an external monitor. It may be labeled **CRT/LCD** or have an icon such as . You may have to hold down the **Fn** key while pressing it (such as **Fn + F7**). Wait a moment for the display to appear.

On Windows 7 or later, hold down the Windows key and press **P** at the same time, then click **Duplicate**.
  - If you’re using a Mac laptop, open **System Preferences** and select **Displays**. Click the **Arrangement** tab and select the **Mirror Displays** checkbox.
- If the projector does not respond to remote control commands, make sure the batteries in the remote control are installed correctly. Replace the batteries if necessary.

Registration

Register today to get product updates and exclusive offers. You can register online at [www.epson.com/webreg](http://www.epson.com/webreg).

Where to get help

Manual

For more information about using the projector, you can view or download the online manual from the Epson website, as described below.

Internet support

Visit [www.epson.com/support](http://www.epson.com/support) (U.S.) or [www.epson.ca/support](http://www.epson.ca/support) (Canada) and search for your product to download software and utilities, view the manual, get FAQs and troubleshooting advice, or contact Epson.

Telephone support services

To use the Epson® PrivateLine® Support service, call (800) 637-7661. This service is available for the duration of your warranty period. You may also speak with a support specialist by calling (562) 276-4394 (U.S.) or (905) 709-3839 (Canada).

Support hours are 6 AM to 8 PM, Pacific Time, Monday through Friday, and 7 AM to 4 PM, Pacific Time, Saturday. Days and hours of support are subject to change without notice. Toll or long distance charges may apply.

Optional accessories

For a list of optional accessories, see the online *User’s Guide*.

You can purchase screens or other accessories from an Epson authorized reseller. To find the nearest reseller, call 800-GO-EPSON (800-463-7766). Or you can purchase online at [www.epsonstore.com](http://www.epsonstore.com) (U.S. sales) or [www.epsonstore.ca](http://www.epsonstore.ca) (Canadian sales).



## Supplier's Declaration of Conformity

We: Epson America, Inc.  
 Located at: 3131 Katella Ave, Los Alamitos, CA 90720  
 Telephone: (562) 981-3840

Trade Name: Epson  
Type of Product: LCD Projector  
Model: HA07A  
Marketing Name: LS300BATV/LS300WATV

Contains wireless LAN with Bluetooth module model: STI6200-D101

Bluetooth remote controller model: RC4261804

Data transmission is always initiated by software, which is then passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it then turns off at the end of the packet. Therefore, the transmitter will be on only while one of the aforementioned packets is being transmitted. In other words, this device automatically discontinues transmission in case of either absence of information to transmit or operational failure.

This equipment is restricted to indoor operation only.

Contains FCC ID: BKMAE-STI6200

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## Industry Canada (IC) Notices

Contains IC: 1052D-STI6200

CAN ICES-3 (B)/NMB-3 (B)

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the IC radio frequency (RF) Exposure rules.

## Two-Year or 12,000-hour Projector Limited Warranty

- A. What Is Covered:** Epson America, Inc. ("Epson") warrants to the purchaser of the Epson product enclosed with this limited warranty statement that the product, if purchased and operated in the United States, Canada, or Puerto Rico, will be free from defects in workmanship and materials for a period of two (2) years from the date of original purchase or 12,000 hours of use, whichever occurs first.
- B. What Epson Will Do To Correct Problems:** If your product requires service during the limited warranty period, please call Epson at the number at the end of this statement and be prepared to provide the model, serial number, and, if required, date of original purchase. This line will be answered during Epson's regular support hours (currently 6:00 AM to 8:00 PM, Pacific Time, Monday through Friday, and 7:00 AM to 4:00 PM on Saturday — subject to change). You may also need to provide proof of purchase if warranty coverage cannot be verified by the serial number. If Epson confirms warranty service is required, Epson will, at its option, exchange or repair the product without charge for parts or labor. If Epson authorizes an exchange for the defective unit, Epson will ship a replacement product to you, freight prepaid, as long as you use an address in the United States, Canada, or Puerto Rico. The replacement product may be new or refurbished to the Epson standard of quality. (The replacement product may not include promotional materials, accessories, documentation, manuals, software, or cables.) You are responsible for securely packaging the defective unit and returning it to Epson within five (5) working days of receipt of the replacement. Epson requires a debit or credit card number to secure the cost of the replacement product in the event that you fail to return the defective one. If Epson authorizes repair instead of exchange, Epson will direct you to send your product to Epson or its authorized service center, where the product will be repaired and sent back to you. You are responsible for securely packaging the product and for all postage or shipping costs to and from the Epson authorized service center. When warranty service involves the exchange of the product or of a part, the item replaced becomes Epson's property. If service cannot be provided on the product for any reason and Epson no longer sells the same model, Epson will replace your product with a model of equal or superior value. Replacement products or parts assume the remaining warranty period of the original product covered by this limited warranty and are subject to its 12,000-hour use limitation.

### C. What This Warranty Does Not Cover:

1. Any damage caused by misuse, abuse, improper installation, or neglect; disasters such as fire, flood, or lightning; or improper electrical currents, software, or interaction with non-Epson products
2. Any damage caused by or any service for third-party software, applications, parts, components, or peripheral devices added to the product after its shipment from Epson, such as dealer- or user-added boards, components, or cables
3. Any damage caused by installing the product next to a heat source or directly in the path of an air vent or an air conditioner
4. Damage due to excessive, continual usage
5. Damage caused by failure to properly maintain the product (see your online *User's Guide* for details)
6. Service when the product is used outside the U.S., Canada, or Puerto Rico
7. Warranty service if the product label, logo, rating label, or serial number has been removed
8. Consumables such as filters or any items that are identified as being replaceable by the user in the product documentation (see your online *User's Guide* for details)
9. Loss of data
10. Installation or removal
11. Any damage from service performed by anyone other than an Epson Authorized Servicer
12. Damage resulting from operation or storage in areas with smoke, oil, high humidity, steam, corrosive gases or chemicals, excessive dust, vibration, or shock
13. Cosmetic damage caused by handling or normal wear and tear during use
14. Any product or parts purchased as used, refurbished, or reconditioned
15. Any damage caused by using improper packaging materials or improper packaging and shipping when returning a product for repair or replacement. You will be invoiced for such shipping damage to product.

This warranty is not transferable. Epson is not responsible for your data or applications, which cannot be restored and should be backed up by you. Postage, insurance, or shipping costs incurred in presenting your Epson product for carry-in warranty service are your responsibility. If a claimed defect cannot be identified or reproduced in service, you will be held responsible for costs incurred.

- D. DISCLAIMER OF WARRANTIES:** EPSON'S SOLE AND EXCLUSIVE LIABILITY AND YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY SHALL BE LIMITED TO EITHER, AT EPSON'S OPTION, REPAIR OR REPLACEMENT AS SET FORTH ABOVE. THE WARRANTY AND REMEDY PROVIDED ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENTS OR REPRESENTATION MADE BY ANY OTHER PERSON OR FIRM ARE VOID. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG IMPLIED WARRANTIES LAST, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

- E. EXCLUSION OF DAMAGES; EPSON'S MAXIMUM LIABILITY:** IN NO EVENT SHALL EPSON OR ITS AFFILIATES BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OR ANY LOST PROFITS, COST OF SUBSTITUTE EQUIPMENT, DOWNTIME, CLAIMS OF THIRD PARTIES, INCLUDING CUSTOMERS, OR INJURY TO PROPERTY, RESULTING FROM THE USE OR INABILITY TO USE THE EPSON PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY. IN NO EVENT SHALL EPSON OR ITS AFFILIATES BE LIABLE FOR DAMAGES OF ANY KIND IN EXCESS OF THE ORIGINAL RETAIL PURCHASE PRICE OF THE PRODUCT. SOME STATES DO NOT ALLOW EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

#### F. Disputes, Arbitration, Governing Laws:

1. Both you and Epson agree that any controversy or claim arising out of or relating to Epson products or services or this agreement, shall be resolved by arbitration on an individual, non-class, non-representative basis, rather than in court. The arbitration shall be governed by the rules of JAMS that are in effect when the arbitration is filed, excluding any rules that permit arbitration on a class or representative basis and under the rules set forth in this agreement. The arbitrator, and not any federal, state, or local court or agency shall have the exclusive authority to resolve any dispute relating to the interpretation, applicability, enforceability, or formation, including but not limited to, any claim that all or any part is void or voidable. JAMS rules are available at <http://www.jamsadr.com> or by calling 1-800-352-5267. Disputes shall be resolved by a single neutral arbitrator, and both parties shall have a reasonable opportunity to participate in the selection of the arbitrator. If you wish, you may appear at the arbitration by phone. The arbitrator is bound by the terms of this agreement.
2. **Pre-Arbitration Steps and Notice.** Before submitting a claim for arbitration, you agree to try, for sixty (60) days, to resolve any dispute informally by contacting us at [customer.inquires@ea.epson.com](mailto:customer.inquires@ea.epson.com). Please include your name, address and contact information, the facts giving rise to the dispute, and the relief requested. You agree to act in good faith to resolve the dispute, but if you and Epson do not reach a resolution within the sixty (60) days, you may commence an arbitration.
3. **Opt-out.** You may elect to opt-out (exclude yourself) from the final, binding, individual arbitration procedure and waiver of class and representative proceedings specified in this agreement by sending a written letter to Epson America, Inc., ATTN: Legal Department, 3131 Katella Ave., Los Alamitos, CA 90720, within thirty (30) days of your purchase of the Epson products and/or services that specifies (i) your name, (ii) your mailing address, and (iii) your request to be excluded from the final, binding, individual arbitration procedure and waiver of class and representative proceedings specified in this Section F. In the event that you opt-out consistent with the procedure set forth above, all other terms shall continue to apply, including the requirement to provide notice prior to litigation.
4. There is no judge or jury in arbitration and your grounds for appeal are limited, however, the arbitrator is empowered to grant relief and award you the same damages as a court could, including declaratory or injunctive relief. Judgment on the arbitration may be entered in any court having jurisdiction.
5. Notwithstanding the foregoing, you may bring an individual action in a small claims court of your state or municipality if the action is within that court's jurisdiction and is pending only in that court.
6. Notwithstanding the foregoing, we also both agree that you or we may bring suit in court to enjoin infringement or other misuse of trademark, patent infringement, copyright, or trade secret.
7. Any action must be brought within one (1) year of the expiration of the warranty.
8. If any provision in this Section F is found to be unenforceable, that provision shall be severed with the remainder of this agreement remaining in full force and effect. The foregoing shall not apply to the prohibition against class or representative actions. This means that if Section 9 (below) is found to be unenforceable, the entire Section 9 (but only Section 9) shall be null and void.
9. **We each agree that any dispute resolution proceedings will be conducted only on an individual basis and not in a class, consolidated, or representative action.**
10. This Section F is governed by the Federal Arbitration Act.

**G. Other Provisions:**

1. **Other Rights You May Have:** This warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction. Some jurisdictions do not allow limitations on how long an implied warranty lasts, or allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.
2. **Warranties in Canada:** In Canada, warranties include both warranties and conditions.
3. **Governing Law:** Except for any claims subject to arbitration pursuant to Section F, you and Epson agree that the law of the state where you reside shall govern.
4. **Venue:** Except for claims subject to arbitration pursuant to Section F, in the event of a dispute you and Epson both consent to the jurisdiction of your state of residence or, if none, then of the courts in Orange County, California.

To find the Epson Customer Care Center nearest you, please visit [www.epson.com/servicecenterlocator](http://www.epson.com/servicecenterlocator) in the U.S. or [www.epson.ca/servicecenterlocator](http://www.epson.ca/servicecenterlocator) in Canada.

To contact the Epson Connection<sup>SM</sup>, please call (800) 637-7661 or (562) 276-4394 in the U.S. and (905) 709-3839 in Canada.

