


Anti-Static Wrist Strap with 1MΩ Resistor - 6ft (1.8m) Cord

Product ID  
ESD-WRIST-STRAP



\*Product may vary from image

	Feature	Function
1	Wrist Strap	• Adjustable <b>Hook and Loop</b> design that ensures a secure fit and helps maintain skin contact for effective grounding
2	Pass-through Loop	• Helps guide the <b>Wrist Strap</b> around the user's wrist
3	Snap Connector	• Enables the <b>Coiled Ground Cord</b> to be securely attached or disconnected if needed • Enables 360° rotation of the <b>Coiled Ground Cord</b> • An <b>Inner Metal Plate</b> ensures direct contact with the skin to safely discharge static electricity
4	Banana Plug (Not Shown)	• Alternative grounding method • Connect to a <b>Grounded Point</b> on the workstation <b>Note:</b> Detach the Alligator Clip by pulling firmly to reveal the Banana Plug
5	Alligator Clip	• Connect to a <b>Grounded Point</b> on the workstation
6	Coiled Ground Cord	• Stretchable cord that connects the <b>Wrist Strap</b> to a <b>Grounded Point</b> on the workstation

Package Contents

- ESD Wrist Strap x 1
- Product Documentation x 1


Requirements

For the latest manuals, product information, technical specifications, and declarations of conformance, please visit:  
[www.StarTech.com/ESD-WRIST-STRAP](http://www.StarTech.com/ESD-WRIST-STRAP)

- Workstation / Bench grounded point
- (Optional) ESD tester or multimeter

## Usage

1. Inspect each individual component to ensure they are clean and undamaged before each use.
2. Verify that the **Snap Connector** attaches securely to the **Wrist Strap** so it won't become disconnected during use.
3. Wrap the **Wrist Strap** snugly around your wrist ensuring the **Inner Metal Plate** maintains full contact with bare skin.  
**Note:** Do not wear the Wrist Strap over clothing.
4. Connect the **Alligator Clip** or **Banana Plug** to an approved ground point such as an ESD mat ground snap connector, a grounded equipment chassis, or a dedicated grounded point on the workstation / bench.
5. (Optional) Verify continuity by using an **ESD Tester** or **Multimeter** to confirm the **Wrist Strap** is grounded.
6. Keep the **Wrist Strap** on at all times when working within the ESD-safe area and recheck the connection if you move around the workstation.

**HQ Contact:**

StarTech.com Ltd.  
45 Artisans Crescent,  
London, ON N5V 5E9,  
Canada

**US Contact:**

StarTech.com USA LLP  
4490 South Hamilton Rd,  
Groveport, OH 43125,  
United States

**UK Contact:**

StarTech.com Ltd.  
15 Gowerton Rd,  
Northampton, NN4 7BW,  
United Kingdom

**EU Contact:**

StarTech.com Ltd.  
Siriusdreef 17-27  
2132 WT Hoofddorp  
The Netherlands

**JP Contact:**

StarTech.com K.K.  
Atelier Yours Ogawamachi 7F  
1-10-2 Kanda Ogawamachi  
Chiyoda-ku, Tokyo 101-0052  
Japan

FR: startech.com/fr  
DE: startech.com/de  
ES: startech.com/es  
NL: startech.com/nl  
IT: startech.com/it  
JP: startech.com/jp