


## 2-Port PCIe 10GBase-T Ethernet Network Card, 2x RJ45

### Product ID

PR210B-NETWORK-CARD



\*Product may vary from image

	Feature	Function
1	Bracket	<ul style="list-style-type: none"> <li>• Secures the <b>Network Card</b> to the <b>Computer Case</b></li> <li>• The <b>Full-Height Bracket</b> comes pre-installed. The <b>Low-Profile Bracket</b> comes in the box</li> </ul>
2	LED Indicators	<ul style="list-style-type: none"> <li>• <b>Left LED Indicator</b> is Link Speed                             <ul style="list-style-type: none"> <li>• <b>Solid Green</b> = 10Gbps</li> <li>• <b>Solid Amber</b> = 1Gbps</li> </ul> </li> <li>• <b>Right LED Indicator</b> is Activity                             <ul style="list-style-type: none"> <li>• <b>Flashing Green</b> = Network port is active</li> </ul> </li> </ul>
3	Ethernet Port	<ul style="list-style-type: none"> <li>• Connect a <b>Network Cable</b> to the <b>Network Card</b></li> <li>• Supports <b>10Gbps</b> and <b>1Gbps</b></li> </ul>
4	PCIe x8 Connector	<ul style="list-style-type: none"> <li>• Insert into a <b>PCI Express Slot</b> on the <b>Host Computer</b></li> </ul>

### Package Contents

- Network Card x 1
- Low-Profile Bracket x 1
- Quick-Start Guide x 1

### Requirements

For the latest manuals, product information, technical specifications, and declarations of conformance, please visit: [www.StarTech.com/PR210B-NETWORK-CARD](http://www.StarTech.com/PR210B-NETWORK-CARD)

- Computer with an available PCI Express Slot (x8 or x16)

## Installation

### Install the PCI Express Card

#### WARNING!

**Static Electricity** can severely damage **PCI Express Cards**. Ensure that you are adequately Grounded before you open your **Computer Case** or touch the **PCI Express Card**. You should wear an **Anti-Static Strap** or use an **Anti-Static Mat** when installing any computer component. If an **Anti-Static Strap** isn't available, discharge any built-up static electricity by touching a large **Grounded Metal Surface** for several seconds. Only handle the **PCI Express Card** by its edges and don't touch the gold connectors.

1. Turn off the **Computer** and any **Peripheral Devices** that are connected to it (for example, **Printers, External Hard Drives**, etc.).
2. Unplug the **Power Cable** from the back of the **Computer**.
3. Disconnect any **Peripheral Devices** that are connected to the **Computer**.
4. Remove the **Cover** from the **Computer Case**. Consult the documentation that came with the **Computer** for details about doing this safely.
5. Locate an open **PCI Express Slot** and remove the corresponding **Slot Cover Plate** from the back of the **Computer Case**. Consult the documentation that came with the **Computer** for details about doing this safely. This card works in PCI Express **x8** or **x16** Slots.
6. Gently insert the **PCI Express Card** into the open **PCI Express Slot** and fasten the **Bracket** to the back of the **Computer Case**.

**Note:** If you install the **PCI Express Card** into a **Small Form Factor** or a **Low-Profile Desktop System**, it may be necessary to replace the pre-installed standard **Full-Height Bracket** with the included **Low-Profile Bracket**.

7. Return the **Cover** onto the **Computer Case**.
8. Reconnect the **Power Cable** to the back of the **Computer**.
9. Reconnect all of the **Peripheral Devices** disconnected in **Step 2**.
10. Turn on your **Computer** and **Peripheral Devices**.

### Install the Driver


1. Open an **Internet Browser** and navigate to:  
[www.StarTech.com/PR201B-NETWORK-CARD](http://www.StarTech.com/PR201B-NETWORK-CARD)
2. Click the **Drivers & Downloads** tab.
3. Under **Driver(s)**, download the **Driver** for your operating system.

#### For Windows Systems

1. Extract the contents of the **Driver Package** by **Right Clicking** the **Driver Folder** that was downloaded from the website and select **Extract All**. Follow the on-screen instructions to finish the **Extraction**.
2. Follow the steps in the **included file** for further Installation Instructions.
3. Navigate to the **Device Manager**.
4. Under **Network Adapters**, right-click **Broadcom P210tepNetXtreme-E Dual-port 10GASE-T Ethernet PCIe Adapter** and click the **Properties** option.
5. Confirm that the **Driver** is installed and working as expected.

#### For Linux Systems

1. Extract the contents of the **Driver Package**.
2. Follow the instructions on the accompanying **README.txt** file.
3. Run **lsmod | grep -i Broadcom** from the command line.
4. Verify that the **Driver** is present in the command line.



**StarTech.com Ltd.**  
45 Artisans Crescent  
London, Ontario  
N5V 5E9  
Canada

**StarTech.com LLP**  
4490 South Hamilton  
Road  
Groveport, Ohio  
43125  
U.S.A.

**StarTech.com Ltd.**  
Unit B, Pinnacle 15  
Gowerton Road  
Brackmills,  
Northampton  
NN4 7BW  
United Kingdom

**StarTech.com Ltd.**  
Siriusdreef 17-27  
2132 WT Hoofddorp  
The Netherlands

FR: startech.com/fr  
DE: startech.com/de  
ES: startech.com/es  
NL: startech.com/nl  
IT: startech.com/it  
JP: startech.com/jp